


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



# Royal 885 Owner's Manual

[Shop genuine replacement parts for Royal 885](#)


Models: 885



[Find Your Royal Vacuum Cleaner Parts - Select From 772 Models](#)

----- Manual continues below -----

Models: 885



## Models: 885

	NLA	Motor Unit Assy	66A	R-670844	Cor
2	NLA	Carbon Brush Assy	67	R-088732B	Upp
3	R-003008	Spring, rear fork	68	R-003884	Spr
4	R-670013	Screw, motor plate ret.	70	R-259318	Upp
5	R-618772	Baffle Spacer	70A	R-670844	Cor
6	R-672103	Brush Holder & Screw Assembly	71	R-801314	Har
7	R-311031	Screw & Washer Assembly	72A	R-597743	Scr
7A	R-065028	Oiler Cap	72B	R-884708	Eye
7B	R-380261	Drive Shaft	73	R-004723	Spr
8	R-618016	Screw, field retainer	74	R-133714	Har
9	R-608005	Fan, heavy duty	76	R-801708	Bo
10	R-780002	Field, 120v	77	R-801714	Nut
11	R-871101	Motor Housing Assembly	78	R-990104	Scr
12	R-801014	Set Screw, brush holder	79	R-028580	Har
13	R-801017	Baffle Plate	85	R-003311	Wa
14	R-801019	Brush Holder	86	R-005138	Wa
15	R-801034	Brush Holder Protector Cap	87	R-023309	Scr
16	R-801701	Screw, rear bearing retainer	90	R-230713	Car
	R-061805	Rear Wheel, Fork & Shaft Assy	91	R-2854270	Gas
19	R-880705	Wheel, 2 1/2" diam.	92	R-880705	Wid
20	R-801711A	Wheel Retainer	93	R-285720	Wir
21	R-028574	Rear Fork & Shaft Assembly	96	R-801711A	Wh
22	R-080126	Rear Bearing Assembly	98	R-980743	Scr
	R-068007	Motor Plate & Armature Assy	99	R-024961	Noz
24	R-175053	Washer, oil slinger	99A	NLA	Spr
25	R-680001	Armature, 120v	100	R-672260	Bel
	NLA	Motor Plate & Bearing Assy	102	R-183749	Sid
27	R-880046	Tolerance Ring	101	R-360753	Scr
28	R-880026	Ball Bearing	103	R-259762	Cor
29	R-884003	Motor Plate	104	R-672270	Noz
30	R-080226	Nozzle Assembly	105	R-673273	Bru
37	R-101161	Fancase Assembly	114	R-080169	Adj
	NLA	Handle & Cord Assembly	116	NLA	Ba
41	R-230324	Grommet	117	R-3067247	Pa
42	R-003311	Lockwasher	117	R-671075	Pa
43	R-023311	Lockwasher	117	R-66247	Pa
44	R-880707	Screw, switchplate	117	745	Pa
45	R-801710	Wingnut, small	118	R-880262	Bel
46	R-360713	Screw, adaptor clamp	119	R-110773	Ins
	NLA	Switch & Cord Assembly			
48	NLA	Cord & Plug Assembly			
50	R-259761	Wire Connector			
51	NLA	Cord Protecting Sleeve			
52	R-322305	Strain Relief, switch plate			
55	NLA	Short Cord			