



Index	Part No.	Description
1	R-088340	Cord, 40 ft, 3-wire black
2	R-230324	Grommet
3	R-133716	Handle stop plate
4	R-133737	Handle fork latch
5	R-259316	Cord hook, lower
6	R-259318	Cord hook upper
7	R-2854270	Gasket, nozzle sealing
8	R-4285704	Handle fork
9	R-380262	Shaft extension
10	R-608005	Fan, slip on
11	R-611101	Axle stud
12	R-322305	Strain relief, power cord
13	R-8012016	Bumper, black
14	R-133715	Adjuster release
15	R-870169	Adjust-o-rite plate, black
16	R-670844	Cord clip
17	R-671705	Wheel
18	R-672260	Belt
19	R-672270	Nozzle guard, 14"
20	R-880314	Handle grip, black
21	R-870006	Grommet, motor
22	R-870024	Motor housing o-ring
23	R-870130	Side plate
24	R-870201	Motor housing
25	R-880262	Belt lifter
26	R-880305	Strain relief, internal cord
27	R-880117	Fan case assembly
28	R-891051	Upper handle assembly, includes #6 and #20
29	R-028580	Handle form and latch assembly
30	R-163309	Switch
31	R-891061	Handle adaptor assembly, includes #5 and #16
32	R-066348	Gun metal gray scufftex bag, type B
33		Nozzle assembly, includes #13 and #43
34	R-673274	14" brush assembly w/speed indicator
35	R-996575	Wheel fork/axle assembly
36	R-701020	10 amp motor w/replaceable brushes (RY8300)
	R-970102	7 amp motor w/replaceable brushes (RY8400)
37	R-870040	Short cord, black
38	R-2870060	Headlight, bracket, socket, bumper assembly
39	R-725629	Headlight bulb, 12 volt
40	R-870060	Light socket and cord assembly
41	R-028563	Chemical chamber cover assembly
42	R-880118	Chemical chamber
43	R-802260	BSI assembly
44	R-028537	Switch and plate assembly
45	R-249303	Switch plate
46	R-153339	Strain relief stamping
47	R-601407	Rubber inlet gasket
45	R-38901050000	Carbon brush package, drop in motors
	R-970109	Carbon brush package, Johnson drop in motors
55	R-003008	Wheel fork spring
56	R-003009	Rod spring
57	R-003022	Latch retainer screw
58	R-003311	Washer adaptor clamp screw
59	R-003884	Spring
60	R-006318	Lockwasher

Index	Part No.	Description
61	R-004723	Handle fork spring
62	R-005138	Wheel retainer washer
63	R-023309	Screw
64	R-074330	Lockwasher
65	R-110773	Motor housing insert
66	R-110775	Rod adjustment sleeve (screw in)
67	R-133738	Handle latch spring
68	R-145734	Screw
69	R-186012	Self tapping screw
70	R-230713	Carriage bolt, handle
71	R-285720	Large wingnut
72	R-311031	Rear axle screw
73	R-074329	Square neck bolt
74	R-597743	Screw
75	R-601772	Latch spacer
76	R-606210	Headlight spring clip
77	R-670013	Motor plate screw
78	R-670705	Spring pin
79	R-672009	Release pedal spring
80	R-801701	Screw
81	R-801708	Handle fork bolt
82		Nut w/hylon insert
83	R-801711A	Wheel retainer cap
84	R-801714	Nut
85	R-802244	Screw
86	R-870013	Adjuster spring
87	R-880707	Screw
88	R-884708	Eye bolt
89	R-980743	Thread forming screw
90	R-990104	screw
91	R-996011	Adjuster rod
92	R-996101	Retaining pin
93	R-996711	E-ring
94	NLA	Screw
95	R-130008	Foot adjustment lever cover
ATTACHMENT KIT		
	R-304	Full attachment kit
	R-4028036	Extension wand
	R-502801	Crevice tool
	R-024585	Hose connector adaptor assembly
	R-051284	Hose assembly
	R-050282	Round brush
	R-097682	10" floor brush
	R-098584	Upholstery tool
ATTACHMENT KIT - DELUXE		
	R-305	Full deluxe attachment kit
	R-258801B	Crevice tool - dark gray
	R-024585	Hose connector adaptor assembly
	R-041076A	Lower wand assembly
	R-041077	Upper wand assembly
	R-995084B	7" hose and bleed valve assembly
	R-097282B	Round brush, gray
	R-415582B	6" upholstery tool
	R-415682B	10" floor brush