



Index	Part No.	Description
1	R-250100	Screw
2	R-720430	Screw
3	R-855185	Handle gasket
4	R-520415	Screw
5	R-520150	Screw
6	R-863130	Strain relief
7	R-855140	Pedal, switch
8	R-855155	Tab latch
9	R-855105	Pivot seal
10	R-920015	Cord hook
11	R-372031	Style 4/5 belt, 2 pack
12	R-720325	Motor grommet
13	R-720355	Pivot bushing
14	R-820351	Pivot clamp
15	R-855240	Power cord
16	R-860081	Switch assembly
17	R-520125	Brush roll assembly
18	R-520011	Air deflector
19	R-620147	Type D bag, 3 pack
20	R-855100	dirt passage cover
21	R-855135	Nozzle guard
22	R-855195U	Nozzle cover assembly (not for 085550)
	R-855195	Nozzle cover assembly (not for 085500)
23	R-855110	Nozzle base assembly

Index	Part No.	Description
24	R-855160	Handle assembly, upper
25	R-4028036	Extension wand
26	R-920035	Crevice tool
27	R-855500	Hose cup
28	R-855205	Wand cup
29	R-855290	Upper tool caddy assembly
	R-520625	Upper tool caddy assembly (only for 085550)
30	R-530200	Roller lifter assembly
31	R-855750	Hose assembly
32	R-855145	Back panel assembly
33	R-855150F	Front panel assembly, sage green (not for 085500)
34	R-920215	2-in-1 tool
35	R-855127	Internal black wire w/fuse
36	R-855330	Motor assembly*
37	R-985533	Motor housing, 2 halves
38	R-185517	Motor fan w/insert - slip on
	R-520145	Fan-3 1/4" diameter (only for 085480)
39	R-855175	Fan housing
40		
41	R-620070	Handle release pedal

*For "A" series models, when replacing the motor, it is necessary to replace the motor housing as well.