



Index	Part No.	Description
1	R-250100	Screw
2	R-720430	Screw
3	R-820351	Pivot clamp (088500 through 088650)
	R-920140	Pivot clamp (088750, 088760)
4	R-860027	Handle release pedal pin (088500 through 088650)
	R-690350	Handle release spring (088750, 088760)
	R-860530	Handle release spring (088500 through 088525)(E)
5	R-8600036	Air diverter
6	R-860012	Air inlet plug
7	R-860044	Airflow valve knob (088600, 088650)
	R-860444	Airflow valve knob
8	R-860046	Tool clip
9	R-860061	Knob spring
10	R-186007	Switch pedal
11	R-860081	Switch
12	R-8600900	Microfresh exhaust filter assembly(088500, 088520, 088525, 088650 through series C)
	R-8600570	HEPA exhaust filter assembly
13	R-860100	Handle release pedal (088500 through 088650)
	R-863060	Handle release pedal (088750, 088760)
14	R-860117	Height adjustment knob (088600, 088650)
15	R-860118	Height adjustment lever (088600, 088650)
16	R-860122	Bumper w/suff guard (088500 through 088650)
	R-865088	Bumper (088750, 088760)
17	R-860121	Height adjustment plate (088600, 088650)
18	R-860122	Latch plate
19	R-860130	Wand adapter
20	R-860140	Styl 10 belt, 2 pack (088500 through 088650)
	R-372031	Style 4/5 belt, 2 pack (088750, 088760)
21	R-860160	Lower hose (088600, 088650 series A)
	R-860460	Lower hose - clear (088500 through 088650)
	R-860161	Lower hose - clear (088750, 088760)
22	R-860180	Lower hose collar (088500 through 088650)
	R-8630886	Lower hose connector (088750, 088760)
23	R-860185	Airflow housing clamp
24	R-860200	Lid gasket
25	R-860225	Airflow housing gasket
26	R-860245	Roller lifter (088600, 088650)
27	R-860350	Motor housing
28	R-860360	Exhaust filter housing
29	R-860505	Roller lifter lever (088500 through 088650)
	R-860049	Roller lifter lever (08850 through 088525 series E)
30	R-860510	Lifter lever clamp (088500 through 088650)
31	R-863054	Caster pal nut
32	R-920906	Wedge base bulb #906
33	R-997125	25 foot power cord
34	R-860020	Airflow housing assembly (088600, 088650, 088750, 088760-series A)
	R-860418	Airflow housing assembly (088500, 088520, 088525, 088650) (088600 series E)
	R-099430A	Airflow housing assembly (088500, 088520, 088525 series E)
35	R-860440	Back panel assembly (088600, 088650 series A)
	R-860441	Back panel assembly (088750, 088760) and (088600 series C & D)
	R-860440	Back panel assembly (088600, 088650 series B)
	R-860445	Back panel assembly (088500, 088520, 088525, 088600 series E)
36	R-720120	Cord hook, black
37	R-860055	Motor cover assembly
	R-860455	Motor cover assembly (088500, 088520, 088525 series E)
38	R-860060	Motor air duct assembly
39	R-860015	Handle assembly (088500 through 088750)
	R-860016	Handle assembly (088760)
40	R-860116A	Nozzle cover assembly (088500)
	R-863570	Nozzle cover assembly (088520)

Index	Part No.	Description
		Nozzle cover assembly (088525)
	R-860116	Nozzle cover assembly (088600)
	R-860115W	Nozzle cover assembly (088650)
	R-86370A	Nozzle cover assembly (088750)
	R-863571	Nozzle cover assembly (088760)
41	R-860126	Nozzle base assembly (088500 through 088650)
	R-863044	Nozzle base assembly (088750, 088760)
42	R-720380	Belt guide clip
43	R-860145	Brush assembly (088500 through 088650)
	R-863005	Brush assembly (088750, 088760)
44	R-860175	Nozzle guard (088500 through 088650)
45	R-1860230	Belt seal (088500 through 088650)
46	R-860189	Dirt cup assembly
47	R-8602110	Microfresh perma filter assembly(088600 through 088760)
	R-8602110	Microfresh perma filter assembly (088500, 088520, 088525 series A,B)
	R-2JC0280	HEPA perma filter assembly (088500, 088520, 08855 series C and newer)
48	R-920035	Crevice tool
49	R-920215	2-in-1 floor tool assembly
50	R-860250	Roller wireform assembly (088500 through 088650)
51	R-860276	Hose assembly (088500 through 088750)
	R-860277	Hose assembly (088500, 088520, 088525 series E)
	R-860279	Hose assembly (088760)
52	R-860231	Dirt cup lid assembly (088500 series E)
		Dirt cup lid assembly (088500 series C)
		Dirt cup lid assembly (088500 series D)
		Dirt cup lid assembly (088520)
		Dirt cup lid assembly (088520 series C)
		Dirt cup lid assembly (088525)
		Dirt cup lid assembly (088520 series D)
	R-860231	Dirt cup lid assembly (088600, 088760)
	R-86023W00	Dirt cup lid assembly (088650)
	R-860230A	Dirt cup lid assembly (088750)
53	R-860365	External filter housing cover assembly
54	R-863038	Caster assembly
55	R-863360	Telescopic wand assembly (088600 through 088760)
	R-4028036	Extension wand, 1.25" (088500 through 088525)
56	R-990303	Motor assembly
57	R-860035	Dirt cup latch
58	R-860033	Foam filter
59	R-690240	Socket assembly with diode (088600 through 088760)
		Socket assembly with diode (088500, 088520, 088525)
60	R-860041	Inlet gasket
61	R-860070	Dirt path cover (088500 through 088650)
62	R-860320	Bleed valve housing
63	R-990684	Silcon valve (088600 through 088760)
64	R-860327	Bleed valve window (088600 through 088760)
65	R-863040	Height adjustment assembly (088750, 088760)
66	R-863308	Belt cover, felt (088750, 088760)
67	R-863307	Nozzle cover felt (088750, 088760)
68	R-720433	Pivot screw (088750, 088760)
69	R-860170	Black lead (088500, 088520, 088525, 088750, 088760)
70	R-860165	White lead (088500, 088520, 088525, 088750, 088760)
71	R-690135	Motor housing gasket (088500, 088520, 088525, 088750, 088760)
72	R-860345	Wire form clamp (088500, 088520, 088525, 088750, 088760)