



Models: 089200, 089220, 089470

1.....	R-250100	Screw, body	37.....	NLA	Motor Assy
2.....	R-503819	Screw, body	38.....	R-940065L	Handle Assy, 089470
3.....	NLA	Return Spring	38.....	R-920065	Handle Assy, 089200, 089220
4.....	R-720128	Switch	39.....	R-920200	Switch Mount Assy, 089200, 089220
5.....	NLA	Seal, motor	39.....	R-940200	Switch Mount Assy, 089470
6.....	R-920005	Clamp, strain relief	40.....	R-920215	2 in 1 Tool
7.....	R-920010	Filter, bag chamber	41.....	R-20225L	Triangle Tool Assy, 089470
8.....	NLA	Cap, hose	41.....	R-920225	Triangle Tool Assy, 089200, 089220
9.....	R-920030	Clamp, dirt tube	42.....	R-920240	Hose Assy, 089200, 089220
10.....	R-920035	Tool, crevice	42.....	R-202406	Hose Assy, 089470
11.....	R-920055	Linkage, door	43.....	R-20275L	Front Motor Cover Assy, 089470
12.....	R-920080	Caddy, rear	43.....	R-920275	Front Motor Cover Assy, 089200, 089220
13.....	NLA	Filter, motor cover	44.....	R-20280L	Front Panel Assy, 089470
14.....	R-920090	Gasket, motor	44.....	R-920280	Front Panel Assy, 089200, 089220
15.....	R-920095	Wheel, rear	45.....	R-920300	Mechanical FBI Assy
16.....	R-920100	Axle, rear	46.....	NLA	Back Panel Assy
17.....	R-920105	Gasket, top dirt tube	47.....	R-920330	Nozzle Cover Assy, 0892500, 089220
18.....	NLA	Gasket, bottom dirt tube	47.....	R-940330	Nozzle Cover Assy, 089470
19.....	R-920115	Belt	48.....	R-920360	Nozzle Base Assy
20.....	NLA	Actuator, linkage	49.....	R-920365	Handle Release Pedal Assy
21.....	NLA	Door, dirt passage	50.....	R-920375	Brush Assy
22.....	R-920130	Dirt, tube	51.....	NLA	Height Adjustment Assy
23.....	R-920140	Clamp, pivot	52.....	R-920500	Screw Package
24.....	R-920145	Hose, dirt passage	53.....	R-920700	Motor Assy, brush
25.....	NLA	Holder, hose & wand	54.....	R-920047	Paper Bags, type U, 3 pack
26.....	R-920196	Motor Shroud	55.....	R-997130	Cord, power
27.....	R-920296	Holder, bag	56.....	R-940415	Variable Speed Assy, 089470
28.....	R-920410	Spring, handle release	57.....	R-940416	Button, slide potentiometer, 089470
29.....	NLA	Jacket, switch	58.....	R-940430	Fastener, slide potentiometer, 089470
30.....	NLA	Switch, brush roll			
31.....	NLA	Terminal Block			
32.....	NLA	Bulb, wedge base			
33.....	R-801711A	Wheel Retainer Cap			
34.....	R-820480	Telescopic Wand			
35.....	R-120060	Dirt Passage Cover Assy			
36.....	R-920135	Nozzle Guard Assy			