



- | | | | | | |
|----|-----------|------------------------------------|----------|-----------|-----------------------------------|
| 1 | NLA | Motor Bracket / Dirt Tube | 16 | R-999020 | Power Cord, 20 ft |
| 1 | R-320011 | Motor Bracket / Dirt Tube, 3470/CA | 16 | R-999032 | Power Cord, 32 ft, 3470/CA |
| 2 | NLA | Motor & Seal Assembly | 17 | NLA | Switch, 2 speed |
| 2 | NLA | Motor & Seal Assembly, 3470/CA | 17 | NLA | Switch, 2-speed, 6 amp, 3470/CA |
| 3 | R-503618 | Screw, motor | 18 | NLA | Switch Compartment Cover |
| 4 | R-321050 | Fan | 18 | NLA | Switch Compartment Cover, 3470/CA |
| 5 | R-3200206 | Fan Housing Assy | 19 | R-320801 | Crevice Tool, 7" |
| 6 | R-250100 | Screw, body | 20 | NLA | Pivot Assy |
| 7 | R-670120 | Cord Hook | 21 | R-321066 | Caster Assy |
| 8 | R-320110 | Back Panel Assy | 22 | NLA | Screw |
| 9 | NLA | Motor Cover | 23 | NLA | Triangle Floor Tool Assy |
| 10 | R-503819 | Screw | 24 | R-3200106 | Wand Assy |
| 11 | R-320230 | Paper Bag | 25 | NLA | Handle Assembly |
| 12 | R-3201063 | Latch | NLA | NLA | Nozzle Cover & Base, 3470/CA |
| 13 | NLA | Spring | R-347155 | R-347155 | Handle & Wand Assy, 3470/CA |
| 14 | NLA | Front Panel Assy | NLA | NLA | Brush, 3470/CA |
| 15 | R-520180 | Screw | | | |