


Models: SE2800



1.....	R-280102	Clean Water Tank W/Cap Assembly
2.....	R-280045	Housing Assembly
3.....	R-280507	Inlet Tube Assembly
4.....	R-280302	Dirty Water Tank Assembly
5.....	R-280700	Brush Assembly
6.....	R-280603	Turbine Housing/Brush Assembly
7.....	R-280024	Impeller Assembly
8.....	NLA	Motor Housing Gasket
9.....	R-280515	Inlet Tubing Gasket
10.....	NLA	DWT/Turbine Gasket
11.....	R-280075	Foam Filter
12.....	R-280130	CWT Cap Assembly
13.....	R-280330	Drain Cap Assembly
14.....	R-280125	CWT Latch
15.....	R-280085	Turbine Valve Knob
16.....	R-280150	Switch
17.....	NLA	Switch Seal
18.....	NLA	Impeller/Motor Nut
19.....	R-280260	Impeller/Motor Washer
20.....	R-280127	CWT Spring