


ROYAL

WET / DRY VACUUMS

Models: 08900, 08900B (8 Gallon), 081600, 081600B (16 Gallon)



1.....	R-120005	Upper Blower Housing
2.....	NLA	Seal, end bracket
3.....	R-120035	Fan
4.....	NLA	Spacer
5.....	R-120045	Washer, anti-gyro
6.....	R-120050	Nut
7.....	NLA	Upper Handle & Motor Cover
7.....	R-120056	Upper Handle & Motor Cover, 08900B, 081600B
8.....	R-120060	Exhaust Diffuser
9.....	NLA	Cord
9.....	R-120176	Cord, 6 ft, 08600B, 086100B
10.....	R-120090	Latch
11.....	R-120105	Inlet, bucket, 08900, 08900B
11.....	R-160105	Inlet, bucket, 081600, 081600B
12.....	R-201156	Handle & Hardware, bucket
13.....	R-120125	Screw, motor mount & ground
14.....	R-120155	Ball, shut-off
15.....	NLA	Filter, foam
16.....	R-120171	Filter Cartridge
17.....	R-120173	Wing Bolt, filter
18.....	R-120174	Retainer
19.....	R-120205	Extension Wand
20.....	R-120210	Nozzle, blower
21.....	R-120300	Tool Caddy
22.....	R-250100	Screw, body
23.....	R-259762	Wire Connector
24.....	R-720430	Screw, body

25.....	R-720128	Switch, on/off
26.....	R-200090	Caster
26.....	R-200090	Caster Pack, 08900B
26.....	R-200090	Caster Pack, 086100B
27.....	R-212001	Lower Blower Housing
28.....	R-600300	Motor Assembly, 08900
28.....	R-120030	Motor Assy, 08900B
28.....	R-600300	Motor Assy, 086100B
28.....	R-600300	Motor Assembly, 081600
29.....	R-201356	Cover
30.....	NLA	Blower Latch Ring
31.....	R-201406	Filter Cage Assembly
32.....	R-600836	Upholstery Tool, 2 1/4"
33.....	R-601806	Hose Assembly
34.....	NLA	Floor Nozzle Assembly
35.....	NLA	Insert Squeegee
36.....	R-201180	Screw, w/ nut, pkg
37.....	NLA	Nut
40.....	R-600756	Bucket Assembly, 081600
40.....	R-600756	Bucket Assembly, 086100B
40.....	R-200753	Bucket Assembly, 08900
40.....	R-120075	Bucket Assembly, 08900B
41.....	R-600826	Drain Cap Assembly, 081600
41.....	R-600826	Drain Cap Assembly, 086100B
42.....	R-120174	Retainer
	NLA	Paper Bag, w/ filter, 3 pack