

D-2 SERVICE PARTS

The following D-2 repair parts have been reinstated by Rexair,

RX-R1370.....	Motor Housing
RX-H306.....	Shaft Nut
RX-R683.....	Stage
RX-R667.....	Bearing Plate
RX-H475.....	Screw, bearing plate
RX-R2490.....	Brush Kit
RX-R1552.....	Carbon Brush
RX-H309.....	Screw, machine
RX-R665.....	Grommet
RX-R692.....	Armature
RX-R700.....	Field
RX-R2423.....	Terminal, field
RX-R146.....	Shield, bearing
RX-R147.....	Slinger Ring
NLA.....	Bearing, lower
RX-H308.....	Screw, lockwasher
RX-H13.....	Shaft Nut
RX-R312.....	Separator
RX-R3450.....	Separator Screw
RX-R1415.....	Gasket, bearing plate
RX-R688.....	Spider

R-1024 Power Nozzle

RX-R1781.....	Brush Roll
RX-R1368.....	Brush Roll
RX-R1029.....	Belt
RX-R1240.....	Bearing Assembly
RX-R1939.....	Motor, power nozzle
RX-R1542.....	Inlet Hose
RX-R6621.....	Hose Assembly
RX-R1045.....	Cord Strap
RX-R1249.....	Extension Cord, long
RX-R1242.....	Extension Cord
RX-R1191.....	Axle Bearing

D-2120 Volt

RX-R625.....	Switch Assembly
RX-R747.....	Motor Gasket Flange
RX-R1030.....	Electric Cord
RX-R912.....	Motor Gasket
RX-R750.....	Switch Cover
RX-R601.....	2 Quart Water Pan
RX-R1761.....	Receptacle Assembly
RX-R598.....	Outer Clamp Ring
RX-R599.....	Motor Support Ring