

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



PANASONIC V5003 Owner's Manual

[Shop genuine replacement parts for PANASONIC
V5003](#)




[Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models](#)

----- Manual continues below -----

Models: MC-V5003

Body Assembly




Models: MC-V5003

Body Assembly

Index	Part No.	Description
1	P-111761	Dust compartment unit
2	P-8913	On/Off switch
3	P-111762	Cord stopper
4	P-6140	Screw (cord stopper)
5	P-111763	Power cord
6	P-000623	Wire connector
7	P-111748	Packing (dust container)
8	P-111749	Switch cover
9	P-111752	Packing (switch cover)
10	P-6140	Screw (switch cover)
11	P-7301	Handle screw
12	P-2117	Nut (handle screw)
13	P-111764	Secondary filter (foam)
14	P-111747	Wheel
15	P-111753	Shaft (wheel)
16	P-111754	Stopper (wheel)
17	P-6115	Washer (wheel)
18	P-111387	Dust bag (type U6)
19	P-111755	Suction Inlet
20	P-111765	Motor case
21	P-111496	Filter (motor case)
22	P-111497	Packing (motor case)
23	P-8172	Screw (motor case)
24	P-111498	Fan motor unit
25	P-111756	Noise suppressor

Index	Part No.	Description
26	P-111757	Motor supp
27	P-111766	Motor supp
28	P-3820	Wire cord
29	P-111776	Handle tub
30	P-111499	Handle grip
31	P-111767	Handle grip
32	P-6140	Screw (han
33	P-111758	Upper cord
34	P-111768	Lower cord
35	P-43096	Screw (low
36	P-111769	Extension l
37	P-00104	Wire tie
38	P-111770	Dust cover
39	P-111771	Protector
40	P-111759	Protector s
41	P-111772	Protector c
42	P-111500	Wand hold
43	P-6140	Screw (wan
44	P-6140	Screw (suc
45	P-111773	Insulator p
46	P-111290	Lead asser
47	P-111774	Dusting br
48	P-111760	crevice too
49	P-111775	Extension v

Nozzle Housing



Index	Part No.	Description
1	P-111737	Nozzle hou
2	P-111738	Shaft (pl