

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



PANASONIC V5005 Owner's Manual

[Shop genuine replacement parts for PANASONIC
V5005](#)




[Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models](#)

----- Manual continues below -----

Models: MC-V5005

Motor Housing, Motor, Handle, and Body




Models: MC-V5005

Motor Housing, Motor, Handle, and Body

Index	Part No.	Description
1	P-11237	Dust compartment
2	P-8913	On/off switch
3	P-111762	Cord stopper
4	P-6140	Screw (cord stopper)
5	P-11238	Power cord
6	P-000623	Wire connector
7	P-111748	Packing (dust container)
8	P-111749	Switch cover
9	P-111752	Packing (switch cover)
10	P-6140	Screw (switch cover)
11	P-7301	Handle screw
12	P-2117	Nut
13	P-111764	Secondary filter (foam)
14	P-111694	Wheel
15	P-111753	Shaft (wheel)
16	P-111754	Stopper (wheel)
17	P-6115	Washer (wheel)
18	P-145M	Dust bag (type U6)
19	P-111755	Suction inlet
20	P-11239	Motor case
21	P-111496	Filter (motor case)
22	P-111497	Packing (motor case)
23	P-8172	Screw (motor case)
24	P-11269	Fan motor unit
25	P-111756	Noise suppressor

Index	Part No.	Description
26	P-111757	Motor support
27	P-11240	Motor support
28	P-3820	Wire cord
29	P-111776	Handle tube
30	P-111499	Handle grip
31	P-11241	Handle grip
32	P-6140	Screw (handle)
33	P-111758	Upper cord
34	P-111768	Lower cord
35	P-43096	Screw (lower)
36	P-11242	Extension handle
37	P-00104	Wire tie
38	P-11243	Dust cover
39	P-11244	Protector
40	P-111759	Protector spring
41	P-111771	Protector cover
42	P-111500	Wand holder
43	P-6140	Screw (wand)
44	P-6140	Screw (suction)
45	P-111773	Insulator pad
46	P-10848	Lead assembly
47	P-111774	Dusting brush
48	P-111760	Crevice tool
49	P-111775	Extension wand



Index	Part No.	Description
1	P-11233	Nozzle housing
2	P-111738	Shaft, plastic
3	P-11234	Furniture guard
4	P-111741	Spring pin