


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://ApplianceFactoryParts.com).




PANASONIC V5037 Owner's Manual

[Shop genuine replacement parts for PANASONIC V5037](#)

Nozzle Housing



Agitator Assembly




[Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models](#)

----- Manual continues below -----

Models: MC-V5037

Nozzle Housing



- | | | |
|--------|---------|---------------------|
| 1..... | P-10346 | Nozzle housing |
| 2..... | P-10819 | Shaft, plastic |
| 3..... | P-1012 | Furniture guard |
| 4..... | P-81 | Packing, nozzle |
| 5..... | P-58 | Spring, pedal |
| 6..... | P-6140 | Screw, pedal spring |
| 7..... | P-10347 | Top mark |


- | | | |
|---------|----------|----------------|
| 8..... | P-00181 | Belt |
| 9..... | P-111446 | Lower plate |
| 10..... | P-111447 | Lower plate |
| 11..... | P-7500 | Packing, low |
| 12..... | P-43 | Belt cover, re |
| 13..... | P-6800 | Screw, lower |
| 14..... | P-78 | Plastic holde |

Agitator Assembly



Models: MC-V5037

Body Housing



1.....P-111449Dust compartment unit

2.....P-8913ON/OFF Switch

3.....P-0698Cord stopper

4.....P-0440Cord stopper

17.....P-74009Stopper, wheel

18.....P-6115Washer, wheel

19.....P-111387Dust bag, type U6

20.....P-000025Dust compartment unit

34.....P-000000Cord stopper

35.....P-760000Cord stopper

36.....P-580000Cord stopper

37.....P-000000Cord stopper