


This Owner's Manual is provided and hosted by Appliance Factory Parts.



PANASONIC V5267 Owner's Manual

[Shop genuine replacement parts for PANASONIC V5267](#)




[Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models](#)

----- Manual continues below -----

Models: MC-V5267


Nozzle Housing

- | | | | | |
|----|-------|-----------|-------|-----------------------------|
| 1 | | P-8938 | | Nozzle housing |
| 2 | | P-2125 | | Window |
| 3 | | P-10819 | | Shaft, plastic |
| 4 | | P-000274 | | Furniture guard |
| 5 | | P-81 | | Packing, nozzle |
| 6 | | P-0100095 | | Frame |
| 7 | | P-111427 | | Spring, pedal |
| 8 | | P-7549 | | Nozzle housing |
| 9 | | P-4720 | | Pedal |
| 10 | | P-6140 | | Screw, frame |
| 11 | | P-00181 | | Belt |
| 12 | | P-8939 | | Lower plate assembly |
| 13 | | P-8942 | | Lower plate |
| 14 | | P-1124 | | Belt cover, rear |
| 15 | | P-9846 | | Stop latch spring |
| 16 | | P-2751 | | Latch |
| 17 | | P-9367 | | Bulb socket |
| 18 | | P-00051 | | Pedal shaft |
| 19 | | P-7411G | | Spacer |
| 20 | | P-111468 | | Packing, lower plate, front |
| 21 | | P-10812 | | Screw, spacer |
| 22 | | P-10109 | | Reflector |
| 23 | | P-683 | | Screw, nozzle |
| 24 | | P-7550 | | Bulb |
| 25 | | P-5045 | | Spring, washer |
| 26 | | P-8220 | | Agitator holder |
| 27 | | P-4104 | | Screw, bulb socket |
| 28 | | P-587 | | Washer |
| 29 | | P-392 | | Packing, lower plate, right |
| 30 | | P-742 | | Packing, lower plate, back |
| 31 | | P-2420 | | Hose supporter |
| 32 | | P-9826 | | Warning label |



Agitator Assembly

- 1 P-5491 Agitator assembly
- 2 P-5492 Brush, 4 pcs.
- 3 P-5918 Agitator pulley
- 4 P-111428 Agitator holder
- 5 P-10376 Filter
- 6 P-9709 Brush support, right
- 7 P-9708 Brush support, left
- 8 P-10858 Agitator shaft
- 9 P-4003 E-clip



Motor Housing, Motor, Handle, and Body

- 1 P-111437 Dust compartment unit
- 2 P-111438 Wand holder
- 3 P-6140 Screw, wand holder
- 4 P-8913 On-off switch
- 5 P-0698 Cord stopper
- 6 P-6140 Screw, cord stopper
- 7 P-10935 power cord
- 8 P-000623 Wire connector
- 9 P-660106 Packing, dust container
- 10 ... P-30606 Switch cover
- 11 ... P-73006 Packing, switch cover
- 12 ... P-6140 Screw, switch cover
- 13 ... P-7301 Handle screw
- 14 ... P-2117 Nut, handle screw
- 15 ... P-3200 Filter supporter
- 16 ... P-9829 Secondary filter, electrostatic
- 17 ... P-0114 Wheel
- 18 ... P-10968 Shat, wheel
- 19 ... P-74009 Stopper, wheel
- 20 ... P-6115 Washer
- 21 ... P-111387 Dust bag, type U6
- 22 ... P-10340 Hose ring
- 23 ... P-8972 Cover, suction inlet
- 24 ... P-6140 Screw, suction inlet
- 25 ... P-10876 Motor case
- 26 ... P-10916 packing, rear cover
- 27 ... P-10825 Packing, motor case
- 28 ... P-8172 Screw, motor case
- 29 ... P-6096 Protector, motor
- 30 ... P-10415 Protector spring, blue

- 31 ... P-111417 Protector case, motor
- 32 ... P-111416 Protector supporter,
- 33 ... P-10877 Fan motor unit
- 34 ... P-8182 Carbon brush
- 35 ... P-9823 Screw, brush (not ill
- 36 ... P-10670 Noise suppressor
- 37 ... P-0293 Motor support, front
- 38 ... P-10338 Motor support rubber
- 39 ... P-3820 Wire cord
- 40 ... P-00623 Wire connector
- 41 ... P-9835 Handle
- 42 ... P-000243 Upper cord storage
- 43 ... P-111469 Hose holder
- 44 ... P-7670 Spring, cord hook
- 45 ... P-587 Washer, cord storage
- 46 ... P-000218 Lower cord storage
- 47 ... P-43096 Screw, cord storage
- 48 ... P-111470 Dust cover
- 49 ... P-8946 hose
- 50 ... P-6088 Dusting brush
- 51 ... P-6069 Crevice tool
- 52 ... P-60104 Wand, extension
- 53 ... P-8180 Wand, with tabs
- 54 ... P-00104 Wire tie
- 55 ... P-6106 Packing, insulator
- 56 ... P-3990 Packing, right
- 57 ... P-5860 Packing, left
- 58 ... P-111429 Lead assembly
- 59 ... P-10712 Lead wire, motor

Models: MC-V5267

Motor Housing, Motor, Handle, and Body

