


Models: MC-V5267

Nozzle Housing


- 1 P-8938 Nozzle housing
- 2 P-2125 Window
- 3 P-10819 Shaft, plastic
- 4 P-000274 Furniture guard
- 5 P-81 Packing, nozzle
- 6 P-0100095 Frame
- 7 P-111427 Spring, pedal
- 8 P-7549 Nozzle housing
- 9 P-4720 Pedal
- 10 P-6140 Screw, frame
- 11 P-00181 Belt
- 12 P-8939 Lower plate assembly
- 13 P-8942 Lower plate
- 14 P-1124 Belt cover, rear
- 15 P-9846 Stop latch spring
- 16 P-2751 Latch
- 17 P-9367 Bulb socket
- 18 P-00051 Pedal shaft
- 19 P-7411G Spacer
- 20 P-111468 Packing, lower plate, front
- 21 P-10812 Screw, spacer
- 22 P-10109 Reflector
- 23 P-683 Screw, nozzle
- 24 P-7550 Bulb
- 25 P-5045 Spring, washer
- 26 P-8220 Agitator holder
- 27 P-4104 Screw, bulb socket
- 28 P-587 Washer
- 29 P-392 Packing, lower plate, right
- 30 P-742 Packing, lower plate, back
- 31 P-2420 Hose supporter
- 32 P-9826 Warning label



Models: MC-V5267

Agitator Assembly

- 1 P-5491 Agitator assembly
- 2 P-5492 Brush, 4 pcs.
- 3 P-5918 Agitator pulley
- 4 P-111428 Agitator holder
- 5 P-10376 Filter
- 6 P-9709 Brush support, right
- 7 P-9708 Brush support, left
- 8 P-10858 Agitator shaft
- 9 P-4003 E-clip



Motor Housing, Motor, Handle, and Body

- 1 P-111437 Dust compartment unit
- 2 P-111438 Wand holder
- 3 P-6140 Screw, wand holder
- 4 P-8913 On-off switch
- 5 P-0698 Cord stopper
- 6 P-6140 Screw, cord stopper
- 7 P-10935 power cord
- 8 P-000623 Wire connector
- 9 P-660106 Packing, dust container
- 10 P-30606 Switch cover
- 11 P-73006 Packing, switch cover
- 12 P-6140 Screw, switch cover
- 13 P-7301 Handle screw
- 14 P-2117 Nut, handle screw
- 15 P-3200 Filter supporter
- 16 P-9829 Secondary filter, electrostatic
- 17 P-0114 Wheel
- 18 P-10968 Shat, wheel
- 19 P-74009 Stopper, wheel
- 20 P-6115 Washer
- 21 P-111387 Dust bag, type U6
- 22 P-10340 Hose ring
- 23 P-8972 Cover, suction inlet
- 24 P-6140 Screw, suction inlet
- 25 P-10876 Motor case
- 26 P-10916 packing, rear cover
- 27 P-10825 Packing, motor case
- 28 P-8172 Screw, motor case
- 29 P-6096 Protector, motor
- 30 P-10415 Protector spring, blue
- 31 P-111417 Protector case, motor
- 32 P-111416 Protector supporter, motor
- 33 P-10877 Fan motor unit
- 34 P-8182 Carbon brush
- 35 P-9823 Screw, brush (not illustrated)
- 36 P-10670 Noise suppressor
- 37 P-0293 Motor support, front
- 38 P-10338 Motor support rubber, rear
- 39 P-3820 Wire cord
- 40 P-00623 Wire connector
- 41 P-9835 Handle
- 42 P-000243 Upper cord storage hook
- 43 P-111469 Hose holder
- 44 P-7670 Spring, cord hook
- 45 P-587 Washer, cord storage hook
- 46 P-000218 Lower cord storage hook
- 47 P-43096 Screw, cord storage hook
- 48 P-111470 Dust cover
- 49 P-8946 hose
- 50 P-6088 Dusting brush
- 51 P-6069 Crevice tool
- 52 P-60104 Wand, extension
- 53 P-8180 Wand, with tabs
- 54 P-00104 Wire tie
- 55 P-6106 Packing, insulator
- 56 P-3990 Packing, right
- 57 P-5860 Packing, left
- 58 P-111429 Lead assembly
- 59 P-10712 Lead wire, motor

Models: MC-V5267

Motor Housing, Motor, Handle, and Body

