


Models: MC-V5268


Nozzle Housing



- | | | | | |
|----|-------|----------|-------|----------------------------|
| 1 | | P-111523 | | Nozzle housing |
| 2 | | P-2125 | | Window |
| 3 | | P-10819 | | Shaft, plastic |
| 4 | | P-000274 | | Furniture guard |
| 5 | | P-81 | | Packing, nozzle |
| 6 | | P-000095 | | Frame |
| 7 | | P-111427 | | Spring, pedal |
| 8 | | P-10304 | | Nozzle hose |
| 9 | | P-4720 | | Pedal |
| 10 | | P-6140 | | Screw, frame |
| 11 | | P-00181 | | Belt |
| 12 | | P-8939 | | Lower plate assembly |
| 13 | | P-8942 | | Lower plate |
| 14 | | P-1124 | | Belt cover, rear |
| 15 | | P-9846 | | Stop latch spring |
| 16 | | P-2751 | | Latch |
| 17 | | P-9367 | | Bulb socket |
| 18 | | P-00051 | | Pedal shaft |
| 19 | | P-7411 | | Spacer |
| 21 | | P-8172 | | Screw, spacer |
| 22 | | P-10109 | | Reflector |
| 23 | | P-683 | | Screw, nozzle |
| 24 | | P-7550 | | Bulb |
| 25 | | P-5045 | | Spring, washer |
| 26 | | P-8220 | | Agitator holder |
| 27 | | P-4104 | | Screw, bulb socket |
| 28 | | P-587 | | Washer |
| 29 | | P-392 | | Packing, lower plate right |
| 30 | | P-742 | | Packing, lower plate back |
| 31 | | P-2420 | | Hose supporter |
| 32 | | P-9826 | | Warning label |
| 33 | | P-10373 | | Packing, lower plate front |

Models: MC-V5268

Motor Housing, Motor, Handle, and Body




Models: MC-V5268

Motor Housing, Motor, Handle, and Body

1 ... P-111524	Dust compartment	22 ... P-10340	Hose hook	42 ... P-111432	Lower cord storage hook
2 ... P-111461	Wand holder	23 ... P-111450	Cover, suction inlet	43 ... P-43096	Screw, cord storage hook
3 ... P-6140	Screw, wand holder	24 ... P-6140	Screw, suction inlet	44 ... P-111613	Dust cover
4 ... P-8913	On/Off switch	25 ... P-111521	Motor case	45 ... P-8946	Hose
5 ... P-0698	Cord stopper	26 ... P-201	Packing, rear cover	46 ... P-6088	Dusting brush
6 ... P-6140	Screw, cord stopper	27 ... P-1906	Packing, motor case	47 ... P-6069	Crevice tool
7 ... P-10802	Power cord	28 ... P-8172	Screw, motor case	48 ... P-8180	Wand, with tabs
8 ... P-000623	Wire connector	29 ... P-10343	Fan motor unit	49 ... P-60104	Wand, extension
9 ... P-660106	Packing, dust container	30 ... P-8182	Carbon brush	50 ... P-6106	Packing, insulator
10 ... P-30606	Switch cover	31 ... P-9823	Screw, brush (not illustrated)	51 ... P-10697	Packing, right
11 ... P-6037	Packing, switch cover	32 ... P-10670	Noise suppressor	52 ... P-10698	Packing, left
12 ... P-6140	Screw, switch cover	33 ... P-0293	Motor support, front	53 ... P-000149	Lead, indicator
13 ... P-7301	Handle screw	34 ... P-10338	Motor support rubber, rear	54 ... P-10400	Spring, indicator
14 ... P-2117	Nut, handle screw	35 ... P-3820	Wire cord	55 ... P-98109	Body, indicator
15 ... P-3200	Filter supporter	36 ... P-000623	Wire connector	56 ... P-111525	Cap, indicator
16 ... P-9994	Secondary filter, HEPA	37 ... P-9835	Handle	57 ... P-9300	Packing, indicator
17 ... P-0114	Wheel	38 ... P-000243	Upper cord storage hook	58 ... P-4104	Screw, indicator
18 ... P-10968	Shaft, wheel	39 ... P-111469	Hose holder	59 ... P-8184	Ring spacer
19 ... P-74009	Stopper, wheel	40 ... P-7670	Spring, cord hook	60 ... P-10712	Lead wire, motor
20 ... P-6115	Washer	41 ... P-587	Washer, cord storage hook	61 ... P-10688	Thermal protector unit
21 ... P-111387	Dust bag, type U6				

Agitator Assembly



1 ... P-111511	Agitator assembly
2 ... P-111512	Brush, 3 pcs.
3 ... P-111614	Agitator pulley
4 ... P-111513	Agitator holder
5 ... P-111514	Filter
6 ... P-111517	Brush support, left
7 ... P-111516	Brush support, right
8 ... P-111518	Agitator shaft
9 ... P-111465	Ring clip
10 ... P-111519	Agitator