


Models: MC-V5278

Nozzle Housing




Index	Part No.	Description
1	P-111440	Nozzle housing
2	P-9854	Window
3	P-2500	Shaft, plastic
4	P-10351	Furniture guard
5	P-10920	Light cover
6	P-8172	Screw (light cover)
7	P-10733	Carpet/bare floor - handle release assembly
8	P-9857	Spring (pedal)
9	P-513	Shaft (pedal)
10	P-02181	Screw (pedal/frame assembly)
11	P-4720	Pedal (black)
12	P-9880	Foot pedal cover
13	P-00181	Belt
14	P-10672	Lower plate assembly
15	P-10681	Lower plate
16	P-10394	Packing (lower plate/Body, lower plate)
17	P-9861	Belt cover

Index	Part No.	Description
18	P-6800	Screw (slider support)
19	P-10304	Nozzle hose
20	P-10353	Slider support
21	P-6140	Screw (slider support)
22	P-9367	Socket (bulb)
23	P-7550	Bulb
24	P-98104	Screw (metal lower plate)
25	P-2444	Latch (lower plate)
26	P-9846	Spring (stop latch)
27	P-683	Screw (nozzle housing, for latch)
28	P-9766	Body (lower plate)
29	P-9888	Wheel
30	P-10357	Shaft (wheel)
31	P-02184	Spring (shifter return)
32	P-6140	Screw (body, lower plate)
33	P-98103	Packing (nozzle)

Models: MC-V5278

Motor Housing, Motor, Handle, and Body




Models: MC-V5278

Motor Housing, Motor, Handle, and Body

Index	Part No.	Description
1	P-111689	Dirt compartment unit
2	P-983	On/off switch
3	P-0698	Cord stopper
4	P-6140	Screw (cord stopper)
5	P-10802	Power cord
6	P-000623	Wire connector
7	P-660106	Packing (dust container)
8	P-30606	Switch cover
9	P-73006	Packing (switch cover)
10	P-6140	Screw (switch cover)
11	P-7301	Handle screw
12	P-2117	Nut (handle screw)
13	P-3200	Filter supporter
14	P-9994	Secondary filter (HEPA)
15	P-111690	Wheel
16	P-10968	Shaft (wheel)
17	P-74009	Stopper (wheel)
18	P-6115	Washer
19	P-145M	Dust bag (type U6)
20	P-111458	Hose hook
21	P-111450	Cover (suction inlet)
22	P-6140	Screw (suction inlet)
23	P-111691	Motor case
24	P-200	Packing (rear cover)
25	P-1906	Packing (motor case)
26	P-8172	Screw (motor case)
27	P-10933	Fan motor unit
28	P-8182	Carbon brush
	P-9823	Screw (brush) - not illustrated
30	P-10670	Noise suppressor
31	P-0293	Motor support (front)
32	P-9911	Motor support rubber (rear)
33	P-3820	Wire cord

Index	Part No.	Description
34	P-000623	Wire connector
35	P-111227	Handle assembly
36	000243	Upper cord storage hook
37	P-10403	Hose holder
38	P-7670	Spring (cord hook)
39	P-587	Washer (cord storage hook)
40	P-111432	Lower cord storage hook
41	P-43096	Screw (cord storage hook)
42	P-111692	Dust cover
43	P-8946	Hose
44	P-111726	Dusting brush
45	P-6069	Crevice tool
46	P-8180	Wand (with tabs)
47	P-6106	packing (insulator)
48	P-10697	Packing (right)
49	P-10698	Packing (left)
50	P-10674	Lead (indicator)
51	P-10400	Spring (indicator)
52	P-98109	Body (indicator)
53	P-000147	Cap (indicator)
54	P-9300	Packing (indicator)
55	P-4104	Screw (indicator)
56	P-8184	Ring spacer
57	P-10712	Lead wire (motor)
58	P-10688	Thermal protector unit
59	P-60104	Extension wand (no tabs)
60	P-00104	Wire tie
61	P-10649	Cooling guide
62	P-111433	Screw (flange)
63	P-111436	Flange
64	P-111461	Wand holder
65	P-6140	Screw (wand holder)
66	P-111489	Handle

Agitator Assembly



Index	Part No.	Description
1	P-111441	Agitator assembly
2	P-10915	Brush (6 pcs)
3	P-111464	Agitator pulley
4	P-111514	Agitator holder
5	P-111515	Filter
6	P-111517	End cap (right)

Index	Part No.	Description
7	P-111516	End cap (left)
8	P-111688	Agitator shaft
9	P-111465	E-clip
10	P-111624	Brush holder
11	P-111466	Spacer
12	P-111725	Spacer (brushes)