


Models:

MC-V6915, MC-V6945, MC-V6950, MC-V6965, MC-V6970, MC-V6975, MC-V6980, MC-V6985

Nozzle Housing

- 1 P-00119 Nozzle Housing, V6915
- 1 P-5466 Nozzle Housing, V6945
- 1 P-5458 Nozzle Housing, V6950
- 1 P-00120 Nozzle Housing, V6965
- 1 P-10104 Nozzle Housing, V6970
- 1 P-5467 Nozzle Housing, V6975
- 1 P-11011 Nozzle Housing, V6980
- 1 P-11013 Nozzle Housing, V6985
- 2 P-10105 Window
- 2 P-10105 Window, V6970, V6980, V6985
- 3 P-2500 Shaft, plastic
- 4 P-10107 Furniture Guard
- 4 P-10107 Furniture Guard, V6970
- 4 P-11014 Furniture Guard, V6980, V6985
- 5 P-81 Packing, tight
- 6 P-000095 Frame
- 7 P-58 Spring, pedal
- 8 P-6140 Screw, spring
- 9 P-5459 Pedal
- 9 P-4720 Pedal, V6915, V6965
- 9 P-11015 Pedal, V6980

- 9 P-11016 Pedal, V6985
- 10 P-6140 Screw, frame
- 11 P-2287 Belt, type UB, 2 pack
- 11 P-V270B Belt, type U8, 2 pack, V6980, V6985
- 12 P-9197 Bottom Plate Assy
- 12 P-000107 Bottom Plate Assy, V6915, V6965
- 13 P-2707 Bottom Plate
- 13 P-000113 Bottom Plate, V6915, V6965
- 14 P-7500 Packing, bottom plate
- 15 P-43 Belt Cover
- 16 P-6800 Screw, bottom plate
- 16 P-000015 Screw, bottom plate, V6915, V6965
- 17 P-9682 Nozzle Hose, short
- 17 P-10108 Nozzle Pipe
- 18 P-10106 Reflector
- 19 P-0039 Socket, bulb
- 19 N/A Socket, bulb, V6915, V6965
- 19 P-9367 Socket, bulb, V6980, V6985
- 20 P-2810 Bulb




Models:

MC-V6915, MC-V6945, MC-V6950, MC-V6965, MC-V6970, MC-V6975, MC-V6980, MC-V6985

1 ... P-00021 Dust Compartment, V6915, V6965	8 ... P-11019 Switch Cover, V6980	24 ... P-0012 On/Off Switch, V6975
1 ... P-5460 Dust Compartment, V6945, V6950	8 ... P-11020 Switch Cover, V6985	25 ... P-00024 Switch Lever
1 ... P-0695 Dust Compartment, V6970	9 ... P-00116 Packing, switch cover	25 ... P-0701 Switch Lever, V6970
1 ... P-0707 Dust Compartment, V6975	9 ... P-9869 Packing, switch cover, V6980, V6985	26 ... P-3990 Packing, right
1 ... P-11017 Dust Compartment, V6980, V6985	10 ... P-6140 Screw, switch cover	27 ... P-4160 Packing, left
2 ... P-0696 On/Off Switch, V6915, V6965	11 ... P-4410 Lead Wire, black, V6945, V6950, V6980, V6985	28 ... P-000118 Dust Cover, V6915
2 ... P-10602 On/Off Switch, V6945, V6950	11 ... P-9892 Lead Wire, V6970	28 ... P-5471 Dust Cover, V6945
2 ... P-0696 On/Off Switch, V6970	12 ... P-00022 Lead Wire, V6915, V6965, V6975	28 ... P-5462 Dust Cover, V6950
2 ... P-10602 On/Off Switch, V6980, V6985	13 ... P-9893 Filter Supporter	28 ... P-00617 Dust Cover, V6965
3 ... N/A Cord Stopper	14 ... P-7023 Secondary Filter, foam	28 ... P-0703 Dust Cover, V6970
3 ... P-0698 Cord Stopper, V6970, V6980, V6985	14 ... P-3099 Secondary Filter, electrostatic, V6915, V6965, V6980, V6985	28 ... P-000119 Dust Cover, V6975
4 ... P-6140 Screw, cord stopper	15 ... P-0114 Wheel	28 ... P-7092 Dust Cover, V6980
5 ... P-7906 Power Cord, 30 ft, V6915	16 ... P-16005 Shaft, wheel	28 ... P-11021 Dust Cover, V6985
5 ... P-110118 Power Cord, 25 ft, V6945, V6950	17 ... P-74009 Stopper, wheel, V6915, V6965, V6980, V6985	29 ... P-37020 Wire Cord
5 ... P-9816 Power Cord, 35 ft, V6965	17 ... P-74004 Stopper, wheel, V6945, V6975	30 ... P-3099 Exhaust Filter, electrostatic
5 ... P-7906 Power Cord, 30 ft, V6970, V6975	18 ... P-6115 Washer	31 ... P-000115 PC Assembly, V6965
5 ... P-11018 Power Cord, 25 ft, V6980, V6985	19 ... P-141M Paper Bag, type U6, micron, 3 pk	31 ... P-5472 PC Assembly, V6970, V6975
6 ... P-000623 Wire Connector	19 ... P-115P Paper Bag, type U3, 3 pack	32 ... P-00022 Lead Wire AU, V6965
7 ... P-66306 Packing, dust container	19 ... P-7553 Electrostatic Dust Bag, V6980, V6985	32 ... P-5473 Lead Wire AU, V6970, V6975
7 ... P-0699 Packing, dust cover, V6970, V6980, V6985	20 ... P-10358 Bag Supporter, V6915, V6945, V6950, V6980, V6985	33 ... P-00113 Ornamental Plate, V6965
8 ... P-00114 Switch Cover, V6915	21 ... P-7082 Cover, bag supporter	33 ... P-0704 Ornamental Plate, V6970
8 ... P-5468 Switch Cover, V6945	22 ... P-6140 Screw, bag supporter	33 ... P-000031 Ornamental Plate, V6975
8 ... P-5461 Switch Cover, V6950	23 ... P-11012 Bag Supporter Assy, V6965	34 ... P-000044 LED Lens, V6965, V6970, V6975
8 ... P-00115 Switch Cover, V6965	23 ... P-5470 Bag Supporter Assy, V6970, V6975	35 ... P-000043 Sensor Sensitivity Knob, V6965, V6970, V6975
8 ... P-0700 Switch Cover, V6970		36 ... P-6140 Screw, optic cells, V6970
8 ... P-5469 Switch Cover, V6975		36 ... P-3879 Screw, optic cells, lead wire au, V6975
		P-98115 Partition Board, V6970
		P-000027 PCB Holder, V6965


Motor & Motor Case Assembly




1 ... P-0293 Motor Support Rubber, front	7 ... P-99300 Noise Suppressor, V6915, V6965	11 ... P-9051 Motor Case, V6970
2 ... P-2908 Motor Assy	8 ... P-000623 Wire Nut	11 ... P-000123 Motor Case, V6975
2 ... P-7552 Motor Assy, V6980, V6985	9 ... P-5960 Packing, rear cover	11 ... P-11023 Motor Case, V6980
3 ... P-27009 Carbon Brush Assy	10 ... P-00117 Packing, motor case	11 ... P-11024 Motor Case, V6985
3 ... P-8182 Carbon Brush Assy, V6980, V6985	10 ... P-9899 Packing, motor case, V6970, V6980, V6985	12 ... P-6140 Screw
4 ... P-0036 Retainer Bracket	11 ... P-000122 Motor Case, V6915	12 ... P-8172 Screw, V6980, V6985
5 ... P-0037 Screw	11 ... P-000287 Motor Case, V6945	13 ... P-7805 Plastic Holder
5 ... P-9823 Screw, V6980, V6985	11 ... N/A Motor Case, V6950	14 ... P-0410 Cooling Guide
6 ... P-9911 Motor Support Rubber, rear	11 ... P-00118 Motor Case, V6965	P-8936 Lead Wire, V6980, V6985
7 ... P-9931 Noise Suppressor		P-8184 Ring Spacer, V6980, V6985

Models: MC-V6915, MC-V6945, MC-V6950, MC-V6965, MC-V6970, MC-V6975, MC-V6980, MC-V6985

Handle Assembly & Rear Dust Compartment



Agitator Assembly



- | | | |
|---|--|--|
| P-00108 Agitator Assy, complete, V6915, V6965 | 3 P-0693 End Cap "A", V6915, V6965 | |
| 2 P-8408 Agitator Unit | 4 P-0694 End Cap "B" | |
| 2 P-9212 Agitator Unit, V6915, V6965 | 5 P-0030 Washer | |
| 3 P-0693 End Cap "A" | | |