


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://ApplianceFactoryParts.com).



# PANASONIC V6980 Owner's Manual

[Shop genuine replacement parts for PANASONIC V6980](#)



[Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models](#)

----- Manual continues below -----


Models:

MC-V6915, MC-V6945, MC-V6950, MC-V6965, MC-V6970, MC-V6975, MC-V-

## Nozzle Housing

- 1 ..... P-00119 ..... Nozzle Housing, V6915
- 1 ..... P-5466 ..... Nozzle Housing, V6945
- 1 ..... P-5458 ..... Nozzle Housing, V6950
- 1 ..... P-00120 ..... Nozzle Housing, V6965
- 1 ..... P-10104 ..... Nozzle Housing, V6970
- 1 ..... P-5467 ..... Nozzle Housing, V6975
- 1 ..... P-11011 ..... Nozzle Housing, V6980
- 1 ..... P-11013 ..... Nozzle Housing, V6985
- 2 ..... P-10105 ..... Window
- 2 ..... P-10105 ..... Window, V6970, V6980, V6985
- 3 ..... P-2500 ..... Shaft, plastic
- 4 ..... P-10107 ..... Furniture Guard
- 4 ..... P-10107 ..... Furniture Guard, V6970
- 4 ..... P-11014 ..... Furniture Guard, V6980, V6985
- 5 ..... P-81 ..... Packing, tight
- 6 ..... P-000095 ..... Frame
- 7 ..... P-58 ..... Spring, pedal
- 8 ..... P-6140 ..... Screw, spring
- 9 ..... P-5459 ..... Pedal
- 9 ..... P-4720 ..... Pedal, V6915, V6965
- 9 ..... P-11015 ..... Pedal, V6980


- 9 ..... P-11016 ..... Pedal, V6985
- 10 ..... P-6140 ..... Screw, frame
- 11 ..... P-2287 ..... Belt, type UB, 2 pack
- 11 ..... P-V270B ..... Belt, type UB, 2 pack, V6980, V6985
- 12 ..... P-9197 ..... Bottom Plate Assy
- 12 ..... P-000107 ..... Bottom Plate Assy, V6915, V6965
- 13 ..... P-2707 ..... Bottom Plate
- 13 ..... P-000113 ..... Bottom Plate, V6915, V6965
- 14 ..... P-7500 ..... Packing, bottom plate
- 15 ..... P-43 ..... Belt Cover
- 16 ..... P-6800 ..... Screw, bottom plate
- 16 ..... P-000015 ..... Screw, bottom plate, V6915, V6965
- 17 ..... P-9682 ..... Nozzle Hose, short
- 17 ..... P-10108 ..... Nozzle Pipe
- 18 ..... P-10106 ..... Reflector
- 19 ..... P-0039 ..... Socket, bulb
- 19 ..... N/A ..... Socket, bulb, V6915, V6965
- 19 ..... P-9367 ..... Socket, bulb, V6980, V6985
- 20 ..... P-2810 ..... Bulb



Models:

MC-V6915, MC-V6945, MC-V6950, MC-V6965, MC-V6970, MC-V6975, MC-V

## Body Housing




## Models:

MC-V6915, MC-V6945, MC-V6950, MC-V6965, MC-V6970, MC-V6975, MC-V6980, MC-V6985

1	P-00021	Dust Compartment, V6915, V6965	8	P-11019	Switch Cover, V6980	24	P-0012	
1	P-5460	Dust Compartment, V6945, V6950	8	P-11020	Switch Cover, V6985	25	P-0000	
1	P-0695	Dust Compartment, V6970	9	P-00116	Packing, switch cover	25	P-0701	
1	P-0707	Dust Compartment, V6975	9	P-9869	Packing, switch cover, V6980, V6985	26	P-3990	
1	P-11017	Dust Compartment, V6980, V6985	10	P-6140	Screw, switch cover	27	P-4160	
2	P-0696	On/Off Switch, V6915, V6965	11	P-4410	Lead Wire, black, V6945, V6950, V6980, V6985	28	P-0001	
2	P-10602	On/Off Switch, V6945, V6950	11	P-9892	Lead Wire, V6970	28	P-5471	
2	P-0696	On/Off Switch, V6970	12	P-00022	Lead Wire, V6915, V6965, V6975	28	P-5462	
2	P-10602	On/Off Switch, V6980, V6985	13	P-9893	Filter Supporter	28	P-0061	
3	N/A	Cord Stopper	14	P-7023	Secondary Filter, foam	28	P-0703	
3	P-0698	Cord Stopper, V6970, V6980, V6985	14	P-3099	Secondary Filter, electrostatic, V6915, V6965, V6980, V6985	28	P-0001	
4	P-6140	Screw, cord stopper	15	P-0114	Wheel	28	P-7092	
5	P-7906	Power Cord, 30 ft, V6915	16	P-16005	Shaft, wheel	28	P-1102	
5	P-110118	Power Cord, 25 ft, V6945, V6950	17	P-74009	Stopper, wheel, V6915, V6965, V6980, V6985	29	P-3702	
5	P-9816	Power Cord, 35 ft, V6965	17	P-74004	Stopper, wheel, V6945, V6975	30	P-3099	
5	P-7906	Power Cord, 30 ft, V6970, V6975	18	P-6115	Washer	31	P-0001	
5	P-11018	Power Cord, 25 ft, V6980, V6985	19	P-141M	Paper Bag, type U6, micron, 3 pk	31	P-5472	
6	P-000623	Wire Connector	19	P-115P	Paper Bag, type U3, 3 pack	32	P-0000	
7	P-66306	Packing, dust container	19	P-7553	Electrostatic Dust Bag, V6980, V6985	32	P-5473	
7	P-0699	Packing, dust cover, V6970, V6980, V6985	20	P-10358	Bag Supporter, V6915, V6945, V6950, V6980, V6985	33	P-0011	
8	P-00114	Switch Cover, V6915	21	P-7082	Cover, bag supporter	33	P-0704	
8	P-5468	Switch Cover, V6945	22	P-6140	Screw, bag supporter	33	P-0000	
8	P-5461	Switch Cover, V6950	23	P-11012	Bag Supporter Assy, V6965	34	P-0000	
8	P-00115	Switch Cover, V6965	23	P-5470	Bag Supporter Assy, V6970, V6975	35	P-0000	
8	P-0700	Switch Cover, V6970						
8	P-5469	Switch Cover, V6975						


## Motor & Motor Case Assembly



Models:

MC-V6915, MC-V6945, MC-V6950, MC-V6965, MC-V6970, MC-V6975, MC-V

## Handle Assembly & Rear Dust Compartment



- 1 ..... P-5460 ..... Dust Compartment
- 1 ..... P-000021 ..... Dust Compartment, V6915, V6965
- 1 ..... P-5460 ..... Dust Compartment, V6945, V6975
- 1 ..... P-0707 ..... Dust Compartment, V6970
- 1 ..... P-11022 ..... Dust Compartment, V6980, V6985
- 2 ..... P-000018 ..... Handle Assy
- 2 ..... P-5474 ..... Handle Assy, V6945, V6980, V6985
- 2 ..... P-9507 ..... Handle Assy, V6950
- 2 ..... P-000286 ..... Handle Assy, V6970
- 3 ..... P-7035 ..... Cord Hook, upper
- 4 ..... P-000048 ..... Screw, handle
- 4 ..... P-9907 ..... Screw, handle, V6970, V6980, V6985
- 5 ..... P-8972 ..... Cover, suction inlet
- 5 ..... P-000049 ..... Cover, suction inlet, V6915, V6965
- 5 ..... P-8972 ..... Cover, suction inlet, V6970, V6980, V6985
- 6 ..... P-1061 ..... Hose
- 6 ..... P-0648 ..... Hose, V6915, V6965, V6980, V6985, V6970

- 7 ..... P-5475 ..... Hose Adaptor
- 7 ..... P-58106 ..... Hose Adaptor, V6950
- 8 ..... P-5463 ..... Suction Inlet
- 9 ..... P-9894 ..... Packing, suction inlet
- 9 ..... P-0709 ..... Packing, suction inlet, V6970
- 9 ..... P-9894 ..... Packing, suction inlet, V6980, V6985
- 10 ..... P-00088 ..... Dusting Brush, V6915, V6965
- 10 ..... P-6088 ..... Dusting Brush
- 11 ..... P-6620 ..... Upholstery Tool
- 12 ..... P-6069 ..... Crevice Tool
- 13 ..... P-60104 ..... Wand, extension
- 13 ..... P-000055 ..... Wand, extension, V6915, V6965
- 13 ..... P-9895 ..... Wand, telescoping, V6970
- 13 ..... P-8180 ..... Wand, V6980, V6985
- 14 ..... P-6806 ..... Protector Case
- 14 ..... P-000056 ..... Protector Case, V6915, V6965
- 15 ..... P-7079 ..... Protector Spring
- 15 ..... P-000057 ..... Protector Spring, V6915, V6965
- 15 ..... P-7089 ..... Protector Spring, V6970, V6980, V6985
- 16 ..... P-6096 ..... Protector
- 16 ..... P-692 ..... Protector, V6915, V6965

- 17 ... P-1806
- 17 ... P-0000
- 18 ... P-5464
- 19 ... P-5465
- 19 ... P-0000
- 19 ... P-9896
- 20 ... P-6140
- 21 ... P-9897
- 22 ... P-7507
- 23 ... P-6907
- ..... P-9873
- ..... P-9811

## Agitator Assembly

