


Models: MC-V7315, MC-V7325, MC-V7335, MC-V7355, MC-V7337, MC-V7375, MC-V7395

## Nozzle Housing



- |         |               |                                 |
|---------|---------------|---------------------------------|
| 1.....  | P-5966.....   | Nozzle Housing, V7315           |
| 1.....  | P-8170.....   | Nozzle Housing, V7325           |
| 1.....  | P-9916.....   | Nozzle Housing, V7335           |
| 1.....  | P-9898.....   | Nozzle Housing, V7337           |
| 1.....  | P-9917.....   | Nozzle Housing, V7355           |
| 1.....  | P-11025.....  | Nozzle Housing, V7375           |
| 1.....  | P-11026.....  | Nozzle Housing, V7395           |
| 2.....  | P-9854.....   | Window                          |
| 3.....  | P-2500.....   | Shaft, plastic                  |
| 4.....  | P-9855.....   | Furniture Guard                 |
| 5.....  | P-9856.....   | Light Cover, V7315              |
| 5.....  | P-8171.....   | Light Cover, V7325              |
| 5.....  | P-9918.....   | Light Cover, V7335, V7375       |
| 5.....  | P-98100.....  | Light Cover, V7337              |
| 5.....  | P-9879.....   | Light Cover, V7355              |
| 5.....  | P-11035.....  | Light Cover, V7395              |
| 6.....  | P-8172.....   | Screw, light cover, V7325       |
| 6.....  | P-42092.....  | Screw, light cover, V7337       |
| 7.....  | P-9878.....   | Frame                           |
| 7.....  | P-000095..... | Frame, V7315, V7325             |
| 8.....  | P-9857.....   | Spring, pedal                   |
| 9.....  | P-513.....    | Shaft, pedal                    |
| 10..... | P-4106.....   | Screw, pedal/frame              |
| 11..... | P-4720.....   | Pedal, black                    |
| 12..... | P-9880.....   | Cover, foot pedal               |
| 12..... | P-10207.....  | Cover, foot pedal, V7375, V7395 |
| 13..... | P-V270B.....  | Belt, type UB8, 2 pack          |
| 14..... | P-9858.....   | Bottom Plate Assy, V7315        |
| 14..... | P-8947.....   | Bottom Plate Assy, V7325        |
| 14..... | P-9881.....   | Bottom Plate Assy, V7335, V7355 |
| 14..... | P-98101.....  | Bottom Plate Assy, V7337        |
| 14..... | P-9764.....   | Bottom Plate Assy, V7375, V7395 |
| 15..... | P-2859.....   | Bottom Plate, V7315             |
| 15..... | P-5893.....   | Bottom Plate, V7325             |
| 15..... | P-5964.....   | Bottom Plate, V7335, V7355      |
| 15..... | P-98102.....  | Bottom Plate, V7337             |
| 15..... | P-9765.....   | Bottom Plate, V7375, V7395      |
| 16..... | P-6140.....   | Screw, pedal shaft              |
| 17..... | P-9861.....   | Belt Cover                      |
| 18..... | P-6800.....   | Screw, slider support           |
| 19..... | P-9862.....   | Nozzle Hose, short              |
| 19..... | P-00121.....  | Nozzle Pipe, V7337              |
| 20..... | P-9863.....   | Slider Support                  |
| 21..... | P-6140.....   | Screw, slider support           |
| 22..... | P-9367.....   | Socket, bulb                    |
| 23..... | P-2810.....   | Bulb                            |
| 24..... | P-9883.....   | Foot Gear Pedal                 |
| 25..... | P-9884.....   | Shoulder Screw                  |
| 26..... | P-9885.....   | Nut/Lock Washer                 |
| 27..... | P-9886.....   | Spring, foot gear pedal         |


- |         |              |                               |
|---------|--------------|-------------------------------|
| 28..... | P-9887.....  | Spring, pedal assembly        |
| 29..... | P-9888.....  | Wheel                         |
| 30..... | P-9889.....  | Roller Shaft                  |
| 31..... | P-10367..... | Belt Gear                     |
| 32..... | P-9891.....  | Retaining Ring                |
| 33..... | P-98103..... | Packing, nozzle               |
| 33..... | P-9919.....  | Packing, nozzle, V7335, V7355 |
| 34..... | P-98104..... | Screw, bottom plate, V7337    |
| 35..... | P-2444.....  | Latch, bottom plate, V7337    |
| 36..... | P-9846.....  | Spring, stop latch            |
| 37..... | P-683.....   | Screw                         |

P-4104..... Screw, handle release, V7315, V7325

P-9766..... Body Lower Plate, V7325

Models: MC-V7315, MC-V7325, MC-V7335, MC-V7355, MC-V7337, MC-V7375, MC-V7395


## Body Assembly



Models: MC-V7315, MC-V7325, MC-V7335, MC-V7355, MC-V7337, MC-V7375, MC-V7395

1.....P-9865.....Dust Compartment, V7315	13....P-9893.....Filter Supporter	28....P-9933.....Dust Cover, V7355
1.....P-8173.....Dust Compartment, V7325	14....P-7023.....Secondary Filter, foam	28....P-11030.....Dust Cover, V7375
1.....P-9924.....Dust Compartment, V7335, V7355	15....P-0114.....Wheel	28....P-11031.....Dust Cover, V7395
1.....P-98107.....Dust Compartment, V7337	16....P-16005.....Shaft, wheel	29....P-3820.....Wire Cord
1.....P-11027.....Dust Compartment, V7375, V7395	17....P-74009.....Stopper, wheel	30....P-3099.....Exhaust Filter, electrostatic, V7315, V7335, V7337, V7355
2.....P-9869.....Packing, dust cover	18....P-6115.....Washer	30....P-8176.....Exhaust Filter, HEPA, V7325, V7375, V7395
3.....N/A.....Cord Stopper	19....P-115P.....Paper Bag, type U3, 3 pack	31....P-5472.....PC Assembly
3.....P-0698.....Cord Stopper, V7325, V7375, V7395	20....P-9928.....Sensor Sensitivity Knob	32....P-9934.....Ornamental Plate
4.....P-6140.....Screw, cord stopper	21....P-7082.....Cover, bag supporter	33....P-9935.....LED Lens
5.....P-7906.....Power Cord	22....P-6140.....Screw, bag supporter	34....P-6800.....Screw, on/off switch
6.....P-000623.....Wire Connector	23....P-5470.....Bag Supporter Assembly	35....P-00104.....Wire Tie
7.....P-9866.....Packing, dust container	23....P-10358.....Bag Supporter, V7315, V7337	P-98109.....Indicator Body, V7337
7.....P-9869.....Packing, dust container, V7315	23....P-8175.....Bag Supporter, V7325	P-9300.....Indicator Packing, V7337
8.....P-9867.....Switch Cover, V7315, V7337	24....P-10602.....On/Off Switch, V7315, V7325	P-000148.....Indicator Spring, V7337
8.....P-8174.....Switch Cover, V7325	24....P-0696.....On/Off Switch, V7335, V7337	P-000149.....Indicator Lead, V7337
8.....P-9925.....Switch Cover, V7335, V7375	24....P-9929.....On/Off Switch, V7355, V7395	P-000147.....Indicator Cap, V7337
8.....P-9920.....Switch Cover, V7355	24....P-0696.....On/Off Switch, V7375	P-4104.....Indicator Screw, V7337
8.....P-11029.....Switch Cover, V7395	25....P-000024.....Switch Lever	
9.....P-9927.....Partition Board	25....P-0701.....Switch Lever, V7325, V7375, V7395	
10....P-6140.....Screw, switch cover	26....P-3990.....Packing, right	
11....P-3879.....Screw, optic cells	27....P-4160.....Packing, left	
12....P-9892.....Lead Wire	27....P-5860.....Packing, left, V7325, V7375, V7395	
12....P-4410.....Lead Wire, V7315, V7355	28....P-9868.....Dust Cover, V7315	
12....N/A.....Lead Wire, V7395	28....P-8948.....Dust Cover, V7325	
	28....P-9932.....Dust Cover, V7335	
	28....P-98108.....Dust Cover, V7337	


## Motor & Motor Case Assembly



1.....P-0293.....Motor Support Rubber, front	6.....P-8183.....Motor Support Rubber, rear, V7325	13....P-9876.....Motor Support Foam
2.....P-2908.....Motor Assy, V7315	7.....P-9931.....Noise Suppressor	14....P-0410.....Cooling Guide
2.....P-8181.....Motor Assy, V7325	8.....P-000623.....Wire Nut	15....P-4160.....Body Packing, motor case
2.....P-9905.....Motor Assy, V7335, V7355	9.....P-9874.....Packing, rear cover	16....P-9877.....Motor Support Rubber Insert, front
2.....P-9905.....Motor Assy, V7337	10....P-9875.....Motor Case, V7315	N/A.....Flange, V7335, V7337, V7355, V7375, V7395
2.....P-11033.....Motor Assy, V7375, V7395	10....P-8949.....Motor Case, V7325	P-9912.....Screw, flange,
3.....P-270091.....Carbon Brush Assy	10....P-9939.....Motor Case, V7335, V7375	P-8184.....Ring Spacer, V7325, V7375, V7395
3.....P-8182.....Carbon Brush Assy, V7325, V7375, V7395	10....P-98113.....Motor Case, V7337	N/A.....Lead Wire, V7325, V7375, V7395
P-6800.....Screw, carbon brush, V7325	10....P-9944.....Motor Case, V7355	
P-9823.....Screw, carbon brush, V7375, V7395	10....P-11034.....Motor Case, V7395	
4.....P-0036.....Retainer Bracket, carbon brush	11....P-42092.....Screw, motor case	
5.....P-0037.....Screw, brush bracket	11....P-8172.....Screw, motor case, V7325, V7375, V7395	
6.....P-9911.....Motor Support Rubber, rear	12....P-7805.....Plastic Holder	


Models: MC-V7315, MC-V7325, MC-V7335, MC-V7355, MC-V7337, MC-V7375, MC-V7395

## Handle Assembly & Rear Dust Compartment



- |   |   |   |
|---|---|---|
| 1..... P-9865 ..... Dust Compartment, V7315         | 4..... P-000048 .... Screw, handle, V7315                       | 13... P-6806 ..... Protector Case                   |
| 1..... N/A..... Dust Compartment, V7325             | 5..... P-8972 ..... Cover, suction inlet                        | 14... P-7089 ..... Protector Spring                 |
| 1..... P-9924 ..... Dust Compartment, V7335, V7355  | 6..... P-0648 ..... Hose  | 15... P-6096 ..... Protector                        |
| 1..... N/A..... Dust Compartment, V7337             | 6..... P-8179 ..... Hose, V7325                                 | 16... P-1806 ..... Protector Supporter              |
| 1..... P-11027 ..... Dust Compartment, V7375, V7395 | 6..... P-0648 ..... Hose, V7375, V7395                          | 17... P-9896 ..... Wand Holder, V7337               |
| 2..... P-9872 ..... Handle Assy, V7315              | 7..... P-9908 ..... Switch Knob                                 | 17... P-7070 ..... Wand Holder, V7355, V7375, V7395 |
| 2..... P-8178 ..... Handle Assy, V7325              | 7..... P-9938 ..... Switch Knob, V7355, V7395                   | 18... P-6140 ..... Screw, holder                    |
| 2..... P-9936 ..... Handle Assy, V7335              | 8..... P-9894 ..... Packing, suction inlet                      | 19... P-9897 ..... Holder, dust brush               |
| 2..... P-98111 ..... Handle Assy, V7337             | 9..... P-6088 ..... Dusting Brush                               | 20... P-9873 ..... Hose Ring                        |
| 2..... P-9937 ..... Handle Assy, V7355              | 10... P-6620 ..... Upholstery Tool                              | 20... P-000061 .... Hose Ring, V7335, V7355         |
| 2..... P-9768 ..... Handle Assy, V7375              | 11... P-6069 ..... Crevice Tool                                 | P-98112 ..... Mount, hose ring                      |
| 2..... P-11032 ..... Handle Assy, V7395             | 12... P-9895 ..... Telescoping Wand, V7337                      | 21... P-60104 ..... Extension Wand, no tabs         |
| 3..... P-7035 ..... Cord Hook, upper                | 12... P-8180 ..... Extension Wand, w/ tabs, V7325, V7375, V7395 |   |
| 4..... P-9907 ..... Screw, handle                   |   |   |

## Agitator Assembly



- |  |
|--|
| 1..... P-9767 ..... Agitator Unit, V7325, V7375, V7395 |
| 1..... P-9864 ..... Agitator Unit, V7315, V7335, V7355 |
| 2..... P-7095 ..... End Cap                            |
| 3..... P-0030 ..... Washer                             |

- MC-V7337 AGITATOR
- |                                |
|--------------------------------|
| P-98105..... Brush Holder      |
| P-9906..... End Cap (2)        |
| P-98106..... Agitator Pulley   |
| P-110113 ..... Agitator Holder |
| P-110114 ..... Brush Unit      |