


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



PANASONIC V7365 Owner's Manual

[Shop genuine replacement parts for PANASONIC
V7365](#)

Nozzle Housing




[Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models](#)

----- Manual continues below -----

Models: MC-V7320, MC-V7347, MC-V7357, MC-V7365, MC-V7367, MC-V7377, M

Nozzle Housing




- | | | | | |
|----|-------|---------|-------|---------------------------------------------------|
| 1 | | P-8920 | | Nozzle Housing |
| 1 | | P-10112 | | Nozzle Housing, V7320 |
| 1 | | P-11025 | | Nozzle Housing, V7365 |
| 1 | | P-10446 | | Nozzle Housing, V7385 |
| 2 | | P-9854 | | Window |
| 3 | | P-2500 | | Shaft, plastic |
| 4 | | P-9855 | | Furniture Guard |
| 4 | | P-10351 | | Furniture Guard,
V7365, V7385,
V7367, V7377 |
| 5 | | P-8921 | | Light Cover |
| 5 | | P-9879 | | Light Cover, V7320 |
| 5 | | P-9918 | | Light Cover, V7365 |
| 5 | | P-9879 | | Light Cover, V7385 |
| 6 | | P-8172 | | Screw, light cover |
| 6 | | P-42092 | | Screw, light cover, V7320 |
| 7 | | P-9878 | | Frame |
| 8 | | P-9857 | | Spring, pedal |
| 9 | | P-513 | | Shaft, pedal |
| 10 | | N/A | | Screw, pedal/frame |
| 10 | | P-4104 | | Screw, pedal/frame, V7320 |
| 11 | | P-4720 | | Pedal, black |
| 12 | | P-10207 | | Cover, foot pedal |
| 12 | | P-9880 | | Cover, foot pedal, V7320 |
| 13 | | P-V270B | | Belt, type UB8, 2 pack |
| 14 | | P-8922 | | Bottom Plate Assy |
| 14 | | P-9881 | | Bottom Plate Assy, V7320 |
| 14 | | P-9764 | | Bottom Plate Assy, V7365, V7385 |
| 15 | | P-8923 | | Bottom Plate |
| 15 | | P-5964 | | Bottom Plate, V7320 |

PANASONIC

V-



Models: MC-V7320, MC-V7347, MC-V7357, MC-V7365, MC-V7367, MC-V737



Models: MC-V7320, MC-V7347, MC-V7357, MC-V7365, MC-V7367, MC-V7377

1 ... P-10396	Dust Compartment	11 ... P-9893	Filter Supporter	26 ... P-9810
1 ... P-5899	Dust Compartment, V7320	12 ... P-7023	Secondary Filter, foam	26 ... P-1039
1 ... N/A	Dust Compartment, V7347, V7357	13 ... P-0114	Wheel	27 ... P-9300
1 ... P-10359	Dust Compartment, V7365	14 ... P-16005	Shaft, wheel	28 ... P-0001
1 ... P-11027	Dust Compartment, V7385	15 ... P-74009	Stopper, wheel	29 ... P-0001
2 ... P-0696	On/Off Switch	16 ... P-6115	Washer, wheel	30 ... P-000
2 ... P-10602	On/Off Switch, V7365	17 ... P-115P	Paper Bag, type U3, 3 pack	31 ... P-4104
2 ... P-9929	On/Off Switch, V7385	17 ... P-115PT	Paper Bag, type U3, 12 pack	32 ... P-6800
3 ... P-0698	Cord Stopper	18 ... P-5470	Bag Supporter	33 ... P-0701
3 ... N/A	Cord Stopper, V7320	18 ... P-10358	Bag Supporter, V7347, V7357 V7365, V7385	33 ... P-0000
4 ... N/A	Screw, cord stopper	18 ... P-10350	Bag Supporter, V7367	34 ... P-0010
5 ... P-9816	Power Cord	19 ... P-6140	Screw, bag supporter	35 ... P-0008
5 ... P-7906	Power Cord, V7320	20 ... P-3990	Packing, right	36 ... P-5472
5 ... P-7906	Power Cord, V7365, V7385	21 ... P-5860	Packing, left	37 ... P-9934
6 ... P-000623	Wire Connector	22 ... P-7092	Dust Cover, V7320	37 ... P-0000
7 ... P-9866	Packing, dust container	22 ... P-8927	Dust Cover, V7347	38 ... P-9935
7 ... P-66306	Packing, dust container, V7320	22 ... P-8928	Dust Cover, V7357	38 ... P-0000
8 ... P-7091	Switch Cover, V7320	22 ... P-10360	Dust Cover, V7365	39 ... P-9928
8 ... P-8925	Switch Cover, V7347, V7367	22 ... P-10397	Dust Cover, V7367	39 ... P-0000
8 ... P-8926	Switch Cover, V7357, V7377	22 ... P-10398	Dust Cover, V7377	40 ... P-7082
8 ... P-8926	Switch Cover, V7365	22 ... P-10448	Dust Cover, V7385	41 ... P-5470
8 ... P-9926	Switch Cover, V7385	23 ... P-3820	Wire Cord	P-9811
9 ... P-6140	Screw, switch cover	24 ... P-3099	Exhaust Filter, electrostatic, V7320	P-9927
9 ... P-6037	Packing, switch cover, V7320	24 ... P-8176	Exhaust Filter, HEPA, V7347, V7357, V7365, V7367, V7377, V7385	
10 ... P-9892	Lead Wire	25 ... P-9869	Packing, dust cover	
10 ... P-4410	Lead Wire, black, V7347, V7357, V7365, V7385			

Handle Assembly & Rear Dust Compartment




1 ... N/A	Dust Compartment, V7320	10 ... P-7089	Protector Spring	25 ... P-9938
1 ... P-8929	Dust Compartment, V7347, V7357	11 ... P-6096	Protector	26 ... P-7554
1 ... P-10361	Dust Compartment, V7365	12 ... P-1806	Protector Spring	27 ... P-8932
1 ... P-10361	Dust Compartment, V7385			27 ... P-10361

PANASONIC

V-

Models: MC-V7320, MC-V7347, MC-V7357, MC-V7365, MC-V7367, MC-V7377, MC-V7385

Motor Case & Motor



- 1 P-0293 Motor Support Rubber, front
- 2 P-2908 Motor Assy, V7320
- 2 P-8935 Motor Assy, V7347, V7357
- 2 P-10405 Motor Assy, V7367, V7377
- 2 P-8181 Motor Assy, V7365
- 2 P-11033 Motor Assy, V7385
- 3 P-8182 Carbon Brush Assy
- 3 P-27009 Carbon Brush Assy, V7320
- P-9823 Screw, carbon brush
- 4 P-0036 Retainer Bracket, V7320
- 5 P-0037 Screw, brush retainer, V7320
- 6 P-9911 Motor Support Rubber, rear
- 7 P-9931 Noise Suppressor
- 8 P-000623 .. Wire Connector

- 9 P-5960 Packing, rear cover
- 9 P-9874 Packing, rear cover, V7347, V7357, V7367, V7377, V7365, V7385
- 10 .. P-9899 Packing, motor case
- 11 .. P-7094 Motor Case, V7320
- 11 .. P-8937 Motor Case, V7347, V7357
- 11 .. P-9939 Motor Case, V7365
- 11 .. P-10406 Motor Case, V7367, V7377
- 11 .. P-9944 Motor Case, V7385
- 12 .. P-8172 Screw, motor case
- 12 .. P-42092 Screw, motor case, V7320
- 13 .. P-7805 Plastic Holder
- 14 .. P-0410 Cooling Guide

- 15 .. P-996
- 16 .. P-991
- 16 .. P-991
- P-893
- N/A ...
- P-818

Agitator Assembly

