


Models: MC-V7320, MC-V7347, MC-V7357, MC-V7365, MC-V7367, MC-V7377, MC-V7385

## Nozzle Housing



- 1 ... P-8920 ..... Nozzle Housing
- 1 ... P-10112 ..... Nozzle Housing, V7320
- 1 ... P-11025 ..... Nozzle Housing, V7365
- 1 ... P-10446 ..... Nozzle Housing, V7385
- 2 ... P-9854 ..... Window
- 3 ... P-2500 ..... Shaft, plastic
- 4 ... P-9855 ..... Furniture Guard
- 4 ... P-10351 ..... Furniture Guard, V7365, V7385, V7367, V7377
- 5 ... P-8921 ..... Light Cover
- 5 ... P-9879 ..... Light Cover, V7320
- 5 ... P-9918 ..... Light Cover, V7365
- 5 ... P-9879 ..... Light Cover, V7385
- 6 ... P-8172 ..... Screw, light cover
- 6 ... P-42092 ..... Screw, light cover, V7320
- 7 ... P-9878 ..... Frame
- 8 ... P-9857 ..... Spring, pedal
- 9 ... P-513 ..... Shaft, pedal
- 10 ... N/A ..... Screw, pedal/frame
- 10 ... P-4104 ..... Screw, pedal/frame, V7320
- 11 ... P-4720 ..... Pedal, black
- 12 ... P-10207 ..... Cover, foot pedal
- 12 ... P-9880 ..... Cover, foot pedal, V7320
- 13 ... P-V270B ..... Belt, type UB8, 2 pack
- 14 ... P-8922 ..... Bottom Plate Assy
- 14 ... P-9881 ..... Bottom Plate Assy, V7320
- 14 ... P-9764 ..... Bottom Plate Assy, V7365, V7385
- 15 ... P-8923 ..... Bottom Plate
- 15 ... P-5964 ..... Bottom Plate, V7320
- 15 ... P-9765 ..... Bottom Plate, V7365, V7385
- 16 ... P-9860 ..... Packing
- 17 ... P-9861 ..... Belt Cover
- 18 ... P-6800 ..... Screw, slider support
- 19 ... P-10108 ..... Nozzle Pipe
- 19 ... P-00121 ..... Nozzle Pipe, V7320
- 19 ... P-9862 ..... Nozzle Hose, short, V7365, V7385, V7367, V7377
- 20 ... P-9863 ..... Slider Support
- 20 ... P-10353 ..... Slider Support, V7365, V7385, V7367, V7377
- 21 ... P-6140 ..... Screw, slider support
- 22 ... P-9367 ..... Socket, bulb
- 23 ... P-2810 ..... Bulb


- 24 ... P-10367 ..... Pedal Gear Assy
- 24 ... P-9883 ..... Foot Pedal Gear, V7320
- 25 ... P-9884 ..... Shoulder Screw
- 26 ... P-9885 ..... Nut/Lock Washer
- 27 ... N/A ..... Spring, foot gear pedal
- 27 ... P-9886 ..... Spring, foot gear pedal, V7320
- 28 ... P-9887 ..... Spring, pedal gear assy
- 29 ... P-9888 ..... Wheel
- 30 ... P-9889 ..... Shaft, wheel
- 31 ... P-02184 ..... Spring, shifter return
- 32 ... P-6140 ..... Screw, bottom plate
- 32 ... P-98104 ..... Screw, bottom plate, V7348

- 33 ... P-98103 ..... Packing, nozzle
- 34 ... P-98104 ..... Screw, metal bottom plate
- 35 ... P-2444 ..... Latch, bottom plate
- 36 ... P-9846 ..... Spring, stop latch
- 37 ... P-683 ..... Screw, nozzle housing, latch
- 38 ... P-9766 ..... Body, lower plate
- P-10367 ..... Belt Gear Kit, V7320



Models: MC-V7320, MC-V7347, MC-V7357, MC-V7365, MC-V7367, MC-V7377, MC-V7385

## Body Housing






Models: MC-V7320, MC-V7347, MC-V7357, MC-V7365, MC-V7367, MC-V7377, MC-V7385

1 ... P-10396	Dust Compartment	11 ... P-9893	Filter Supporter	26 ... P-98109	Body, indicator
1 ... P-5899	Dust Compartment, V7320	12 ... P-7023	Secondary Filter, foam	26 ... P-10399	Body, indicator, V7367/77
1 ... N/A	Dust Compartment, V7347, V7357	13 ... P-0114	Wheel	27 ... P-9300	Packing, indicator
1 ... P-10359	Dust Compartment, V7365	14 ... P-16005	Shaft, wheel	28 ... P-000148	Spring, indicator
1 ... P-11027	Dust Compartment, V7385	15 ... P-74009	Stopper, wheel	29 ... P-000149	Lead, indicator
2 ... P-0696	On/Off Switch	16 ... P-6115	Washer, wheel	30 ... P-000147	Cap, indicator
2 ... P-10602	On/Off Switch, V7365	17 ... P-115P	Paper Bag, type U3, 3 pack	31 ... P-4104	Screw, indicator
2 ... P-9929	On/Off Switch, V7385	17 ... P-115PT	Paper Bag, type U3, 12 pack	32 ... P-6800	Screw, on/off switch
3 ... P-0698	Cord Stopper	18 ... P-5470	Bag Supporter	33 ... P-0701	Switch Lever
3 ... N/A	Cord Stopper, V7320	18 ... P-10358	Bag Supporter, V7347, V7357, V7365, V7385	33 ... P-000024	Switch Lever, V7320
4 ... N/A	Screw, cord stopper	18 ... P-10350	Bag Supporter, V7367	34 ... P-00104	Wire Tie
5 ... P-9816	Power Cord	19 ... P-6140	Screw, bag supporter	35 ... P-00086	Screw, dirt sensor optic cells
5 ... P-7906	Power Cord, V7320	20 ... P-3990	Packing, right	36 ... P-5472	PC Assembly
5 ... P-7906	Power Cord, V7365, V7385	21 ... P-5860	Packing, left	37 ... P-9934	Ornamental Plate
6 ... P-000623	Wire Connector	22 ... P-7092	Dust Cover, V7320	37 ... P-000031	Ornamental Plate, V7320
7 ... P-9866	Packing, dust container	22 ... P-8927	Dust Cover, V7347	38 ... P-9935	LED Lens
7 ... P-66306	Packing, dust container, V7320	22 ... P-8928	Dust Cover, V7357	38 ... P-000044	LED Lens, V7320
8 ... P-7091	Switch Cover, V7320	22 ... P-10360	Dust Cover, V7365	39 ... P-9928	Sensor Knob
8 ... P-8925	Switch Cover, V7347, V7367	22 ... P-10397	Dust Cover, V7367	39 ... P-000043	Sensor Knob, V7320
8 ... P-8926	Switch Cover, V7357, V7377	22 ... P-10398	Dust Cover, V7377	40 ... P-7082	Cover, bag supporter
8 ... P-8926	Switch Cover, V7365	22 ... P-10448	Dust Cover, V7385	41 ... P-5470	Bag Supporter, dirt sensor
8 ... P-9926	Switch Cover, V7385	23 ... P-3820	Wire Cord	P-98115	Partition Board, V7320
9 ... P-6140	Screw, switch cover	24 ... P-3099	Exhaust Filter, electrostatic, V7320	P-9927	Partition Board, V7385
P-6037	Packing, switch cover, V7320	24 ... P-8176	Exhaust Filter, HEPA, V7347, V7357, V7365, V7367, V7377, V7385		
10 ... P-9892	Lead Wire	25 ... P-9869	Packing, dust cover		
10 ... P-4410	Lead Wire, black, V7347, V7357, V7365, V7385				

## Handle Assembly & Rear Dust Compartment



1 ... N/A	Dust Compartment, V7320	10 ... P-7089	Protector Spring	25 ... P-9938	Knob, switch, V7385
1 ... P-8929	Dust Compartment, V7347, V7357	11 ... P-6096	Protector	26 ... P-7554	Lever, handle, V7347/57/67/77
1 ... P-10361	Dust Compartment, V7365	12 ... P-1806	Protector Spring	27 ... P-8932	Handle, V7347, V7357
1 ... P-40507	Dust Compartment, V7367, V7377	13 ... N/A	Hose Ring Mount, V7320	27 ... P-10404	Handle, V7367, V7377
1 ... P-11027	Dust Compartment, V7385	13 ... P-98112	Hose Ring Mount, V7347, V7357	28 ... P-8172	Screw, cord hook, V7347/57/67/77
2 ... P-8972	Cover, suction inlet	14 ... P-9896	Wand Holder	29 ... P-8933	Handle Cover, front, V7347/57/67/77
3 ... P-8179	Hose	P-10403	Hose Holder, V7367, V7377	30 ... P-8934	Handle Cover, rear, V7347/57/67/77
3 ... P-0648	Hose, V7320	15 ... P-6140	Screw	31 ... P-8172	Screw, handle cover, V7347/57/67/77
3 ... P-10436	Hose, V7367, V7367, V7385	16 ... P-9897	Holder, dusting brush	32 ... P-7301	Screw, handle, V7347/57/67/77
4 ... P-9894	Packing, suction inlet	17 ... P-9873	Hose Ring	33 ... P-2117	Nut, handle screw, V7347/57/67/77
5 ... P-6088	Dusting Brush	18 ... P-9817	Handle Grip, right, V7347/57/67/77	34 ... P-9907	Screw, handle assy, V7347/57/67/77
6 ... P-6620	Upholstery Tool	19 ... P-9818	Handle Grip, left, V7347/57/67/77		
7 ... P-6069	Crevice Tool	20 ... P-8172	Screw, grip, V7347/57/67/77		
8 ... P-9895	Telescoping Wand, V7320	21 ... P-9819	Cord Hook, upper, V7347/57/67/77		
8 ... P-8931	Telescoping Wand, V7347, V7357	22 ... P-7670	Spring, cord hook, V7347/57/67/77		
8 ... P-8180	Telescoping Wand, tabs, V7365, V7367, V7377, V7385	23 ... P-587	Washer, cord hook, V7347/57/67/77		
9 ... P-6806	Protector Case	24 ... P-9820	Window, switch, V7347/57/67/77		
		25 ... P-9821	Knob, switch, V7347/57/67/77		


### HANDLE ASSEMBLY FOR V7320, V7365, V7385

P-000286	Handle Assembly, V7320
P-10362	Handle Assembly, V7365
P-9937	Handle Assembly, V7385
P-7035	Cord Hook, upper
P-6907	Knob, switch, V7320
P-9907	Knob, switch, V7365, V7385




Models: MC-V7320, MC-V7347, MC-V7357, MC-V7365, MC-V7367, MC-V7377, MC-V7385

## Motor Case & Motor



- |  |   |  |
|--|---|--|
| 1 .... P-0293 ..... Motor Support Rubber, front  | 9 .... P-5960 ..... Packing, rear cover         |  |
| 2 .... P-2908 ..... Motor Assy, V7320            | 9 .... P-9874 ..... Packing, rear cover, V7347, |  |
| 2 .... P-8935 ..... Motor Assy, V7347, V7357     | V7357, V7367, V7377, V7365,                     |  |
| 2 .... P-10405 .... Motor Assy, V7367, V7377     | V7385   |  |
| 2 .... P-8181 ..... Motor Assy, V7365            | 10 .. P-9899 ..... Packing, motor case          |  |
| 2 .... P-11033 .... Motor Assy, V7385            | 11 .. P-7094 ..... Motor Case, V7320            | 15 .. P-9960 ..... Flange                |
| 3 .... P-8182 ..... Carbon Brush Assy            | 11 .. P-8937 ..... Motor Case, V7347, V7357     | 16 .. P-9915 ..... Screw, flange, V7320  |
| 3 .... P-27009 .... Carbon Brush Assy, V7320     | 11 .. P-9939 ..... Motor Case, V7365            | 16 .. P-9912 ..... Screw, flange, V7347, |
| P-9823 ..... Screw, carbon brush                 | 11 .. P-10406 .... Motor Case, V7367, V7377     | V7357, V7365                             |
| 4 .... P-0036 ..... Retainer Bracket, V7320      | 11 .. P-9944 ..... Motor Case, V7385            | P-8936 ..... Lead Wire, V7347,           |
| 5 .... P-0037 ..... Screw, brush retainer, V7320 | 12 .. P-8172 ..... Screw, motor case            | V7357, V7365                             |
| 6 .... P-9911 ..... Motor Support Rubber, rear   | 12 .. P-42092 .... Screw, motor case, V7320     | N/A ..... Ring Spacer, V7347, V7357      |
| 7 .... P-9931 ..... Noise Suppressor             | 13 .. P-7805 ..... Plastic Holder               | P-8184 ..... Ring Spacer, V7365,         |
| 8 .... P-000623 .. Wire Connector                | 14 .. P-0410 ..... Cooling Guide                | V7367, V7377                             |

## Agitator Assembly



- |        |   |
|--------|---|
|        | P-10395 ..... Agitator Assy, w/o end caps, V7367, V7377     |
| 1 .... | P-98105 ..... Brush Holder, V7347, V7357, V7367, V7377      |
| 2 .... | P-9906 ..... Brush Support, V7347, V7357, V7367, V7377      |
| 3 .... | P-8924 ..... Agitator Pulley, V7347, V7357, V7367, V7377    |
| 4 .... | P-110113 ..... Agitator Holder, V7347, V7357, V7367, V7377  |
| 5 .... | P-110114 ..... Brush Strips (4), V7347, V7357, V7367, V7377 |

### AGITATOR PARTS FOR V7320, V7365, V7385

- |        |                                   |
|--------|-----------------------------------|
| P-9864 | ..... Agitator Unit, V7320        |
| P-9767 | ..... Agitator Unit, V7365, V7385 |
| P-7095 | ..... End Cap (brush support)     |
| P-0030 | ..... Washer                      |