


Models: MC-V7400D, MC-V7407D


Nozzle Housing

- 1 P-10737 Nozzle Housing, V7400D
- 1 P-10789 Nozzle Housing, V7407D
- 2 P-10738 Window
- 3 P-10739 Brush "A"
- 4 P-10740 Furniture Guard
- 5 P-10741 Felt, upper
- 6 P-10742 Switch Assy, agitator, on/off
- 7 P-10743 Button, agitator, on/off
- 8 P-10586 Overload Protector
- 9 P-10744 Extension, overload protector, 7400
- 9 P-00127 Extension, overload protector, 7407
- 10 P-10745 Reflector
- 11 P-10746 Lead Wire
- 12 Thermal Protector
- 13 ... P-000623 Wire Connector
- 14 P-10747 Filter
- 15 P-10748 Lower Plate
- 16 P-10749 Felt, lower plate
- 17 P-10750 Shaft, wheel
- 18 P-10751 Wheel
- 19 P-10752 Nozzle Hose
- 20 P-6140 Screw, lower plate
- 21 P-10753 Nozzle Cover
- 22 P-10754 Socket, bulb
- 23 P-7550 Bulb
- 24 P-10755 Pedal
- 25 P-10756 Plate, pedal
- 26 P-6140 Screw, pedal plate
- 27 P-10757 Lead Wire, brown
- 28 Lead Wire, blue
- 29 ... P-10758 Motor Support



Models: MC-V7400D, MC-V7407D

Body




Models: MC-V7400D, MC-V7407D

- 1 P-10774 Dust Compartment Assy, V7400D
- 1 P-10791 Dust Compartment Assy, V7407D
- 2 P-0696 On/Off Switch
- 3 P-000623 Wire Connector
- 4 P-9866 Packing, dust container
- 5 P-8925 Switch Cover, V7400D
- 5 P-8926 Switch Cover, V7407D
- 6 P-6140 Screw, switch cover
- 7 P-9892 Lead Wire, black
- 8 P-9893 Filter Supporter
- 9 P-10634 Secondary Filter, foam
- 10 P-0114 Wheel
- 11 P-16005 Shaft, wheel
- 12 P-74009 Stopper, wheel
- 13 P-6115 Washer, wheel
- 14 P-115P Paper Bag, type U3, 3pk
- 14 P-115PT Paper Bag, type U3, 12pk
- 15 P-5470 Bag Supporter Assy

- 16 P-6140 Screw, bag supporter
- 17 P-10775 Dust Cover, V7400D
- 17 P-10792 Dust Cover, V7407D
- 18 P-10635 Wire Cord
- 19 P-8176 Exhaust Filter, HEPA
- 20 P-4104 Screw, indicator
- 21 P-10661 Protector Cover
- P-10316 Spring, protector, V7400D
- P-10776 Protector, V7400D
- 22 P-7082 Cover, bag supporter
- 23 P-00086 Screw, optic cells
- 24 P-5472 PCB Assembly
- 25 P-9934 Ornamental Plate
- 26 P-9935 LED Lens
- 27 P-9928 Sensor Knob
- 28 Rear Cover Packing
- 29 P-000147 Cap, indicator
- 30 P-0701 Switch Lever

- 31 P-6800 Screw, on/off switch
- 32 Locking Cam
- 33 P-98104 Screw, locking cam
- 34 P-10777 Jumping Lead Wire
- 35 P-10778 Lower PCB Assembly
- 36 Cap, capacitor
- 37 P-000623 Wire Connector
- 38 P-00104 Wire Tie
- 39 Packing, PCB wires
- 40 P-6800 Screw, on/off switch, uprt position
- 41 P-0696 On/Off Switch, upright position
- 42 P-98109 Body, indicator
- 43 P-9300 Packing, indicator
- 44 P-10400 Spring, indicator
- 45 P-10674 Lead, indicator

Agitator Assembly




- P-10759 Agitator, complete
- 2 P-10760 Internal Gear
- 3 P-10761 Screw, internal gear
- 4 P-10762 Agitator, tufted
- 5 P-10763 Motor, agitator
- 6 P-10764 Fan

- 7 P-10765 Washer
- 8 P-10766 Lock Nut
- 9 P-10767 Holder, bearing
- 10 P-10768 Holder, agitator
- 11 P-10769 Bearing
- 12 P-10770 Rubber Support

- 13 P-10771 End Cap, tufted
- 14 P-10772 Screw, end cap
- 15 P-10773 Gear Unit Assy
- 16 P-10757 Lead Wire, brown
- 17 Lead Wire, blue

Motor Case & Motor




- 1 P-0293 Motor Support Rubber, front
- 2 P-10785 Motor Assy, V7400D
- 2 P-10793 Motor Assy, V7407D
- 3 P-8182 Carbon Brush Assy
- 4 P-10690 Screw, carbon brush
- 5 P-9911 Motor Support Rubber, rear

- 6 P-10670 Noise Suppressor
- 7 P-000623 Wire Connector
- 8 P-9874 Packing, rear cover
- 9 P-10786 Motor Case, V7400D
- 9 P-10794 Motor Case, V7407D
- 10 P-6140 Screw, motor case

- 11 P-10787 Flange
- 12 P-10690 Screw, flange
- 13 P-10712 Lead Wire, motor
- 14 N/A Lead Wire Assy
- 15 P-10649 Cooling Guide
- 16 P-10788 Motor Seal

Models: MC-V7400D, MC-V7407D

Handle Assembly, Rear Dust Compartment and Cord Reel Assembly



- 1 ... P-10774 Dust Compartment Assy, V7400D
- 1 ... P-10791 Dust Compartment Assy, V7404D
- 2 ... P-10691 Screw, handle cap
- 3 ... P-9907 Screw, handle
- 4 ... P-8972 Cover, suction inlet
- 5 ... P-10436 Hose
- 6 ... P-6140 Screw, bracket
- 7 ... P-10512 Packing, suction inlet
- 8 ... P-6069 Crevice Tool
- 9 ... P-10781 Extension Wand, w/ tabs, V7400D
- 9 ... P-8180 Extension Wand, w/ tabs, V7404D
- 10 ... P-9873 Hose Ring
- 11 ... P-60104 Extension Wand, w/o tabs
- 12 ... P-10638 Cord Reel Cover
- 13 ... P-6140 Screw, cord reel cover
- 14 ... P-10782 Brake Lever Assy, V7400D
- 14 ... P-10639 Brake Lever Assy, V7404D
- 15 ... P-10640 Cord Reel Assy
- 16 ... P-6140 Screw, cord reel assy
- 17 ... P-10783 Contact Base Assy, V7400D
- 17 ... P-10709 Contact Base Assy, V7404D
- 18 ... P-10663 Contact Disc Assy
- 19 ... P-10680 Cord Reel Hub Assy
- 20 ... P-10641 Bracket, cord reel
- 21 ... P-10642 Cord Guide
- 22 ... P-10643 Spring, brake lever
- 23 ... P-6140 Screw, brake lever
- 24 ... P-587 Washer, brake lever
- 25 ... P-10699 Handle Cap
- 26 ... P-10645 Fabric Brush
- 27 ... P-10646 Brush Holder
- 28 ... P-9817 Handle Grip, right
- 29 ... P-9816 Handle Grip, left
- 30 ... P-8172 Screw, handle grip
- 31 ... P-9820 Window, switch
- 32 ... P-9821 Knob, switch
- 33 ... P-7554 Lever, handle
- 34 ... P-10404 Handle
- 35 ... P-10449 Screw
- 36 ... P-10403 Hose Holder
- 37 ... P-2117 Nut, handle screw
- 38 ... P-8934 Handle Cover, rear
- 39 ... P-8933 Handle Cover, front
- 40 ... P-7301 Screw, handle assy
- 41 ... P-8172 Screw, handle cover

HANDLE ASSY FOR MC-V7400D

- P-10780 Handle Assy
- P-9907 Screw, handle
- P-10647 Handle Cover
- P-10784 Switch Knob Lock