


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://ApplianceFactoryParts.com).



PANASONIC V7407D Owner's Manual

[Shop genuine replacement parts for PANASONIC V7407D](#)




[Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models](#)

----- Manual continues below -----

Models: MC-V7400D, MC-V7407D

Nozzle Housing

- 1 P-10737 Nozzle Housing, V7400D
- 1 P-10789 Nozzle Housing, V7407D
- 2 P-10738 Window
- 3 P-10739 Brush "A"
- 4 P-10740 Furniture Guard
- 5 P-10741 Felt, upper
- 6 P-10742 Switch Assy, agitator, on/off
- 7 P-10743 Button, agitator, on/off
- 8 P-10586 Overload Protector
- 9 P-10744 Extension, overload protector, 7400
- 9 P-00127 Extension, overload protector, 7407
- 10 ... P-10745 Reflector
- 11 ... P-10746 Lead Wire
- 12 Thermal Protector
- 13 ... P-000623 Wire Connector
- 14 ... P-10747 Filter
- 15 ... P-10748 Lower Plate
- 16 ... P-10749 Felt, lower plate
- 17 ... P-10750 Shaft, wheel
- 18 ... P-10751 Wheel
- 19 ... P-10752 Nozzle Hose
- 20 ... P-6140 Screw, lower plate
- 21 ... P-10753 Nozzle Cover
- 22 ... P-10754 Socket, bulb
- 23 ... P-7550 Bulb
- 24 ... P-10755 Pedal
- 25 ... P-10756 Plate, pedal
- 26 ... P-6140 Screw, pedal plate
- 27 ... P-10757 Lead Wire, brown
- 28 Lead Wire, blue
- 29 ... P-10758 Motor Support




PANASONIC

V

Models: MC-V7400D, MC-V7407D


1	P-10774	Dust Compartment Assy, V7400D	16 ...	P-6140	Screw, bag supporter	31 ...	P-6800
1	P-10791	Dust Compartment Assy, V7407D	17 ...	P-10775	Dust Cover, V7400D	32	
2	P-0696	On/Off Switch	17 ...	P-10792	Dust Cover, V7407D	33 ...	P-9810
3	P-000623	Wire Connector	18 ...	P-10635	Wire Cord	34 ...	P-1077
4	P-9866	Packing, dust container	19 ...	P-8176	Exhaust Filter, HEPA	35 ...	P-1077
5	P-8925	Switch Cover, V7400D	20 ...	P-4104	Screw, indicator	36	
5	P-8926	Switch Cover, V7407D	21 ...	P-10661	Protector Cover	37 ...	P-0000
6	P-6140	Screw, switch cover		P-10316	Spring, protector, V7400D	38 ...	P-0010
7	P-9892	Lead Wire, black		P-10776	Protector, V7400D	39	
8	P-9893	Filter Supporter	22 ...	P-7082	Cover, bag supporter	40 ...	P-6800
9	P-10634	Secondary Filter, foam	23 ...	P-00086	Screw, optic cells	41 ...	P-0696
10 ...	P-0114	Wheel	24 ...	P-5472	PCB Assembly	42 ...	P-9810
11 ...	P-16005	Shaft, wheel	25 ...	P-9934	Ornamental Plate	43 ...	P-9300
12 ...	P-74009	Stopper, wheel	26 ...	P-9935	LED Lens	44 ...	P-1040
13 ...	P-6115	Washer, wheel	27 ...	P-9928	Sensor Knob	45 ...	P-1067
14 ...	P-115P	Paper Bag, type U3, 3pk	28		Rear Cover Packing		
14 ...	P-115PT	Paper Bag, type U3, 12pk	29 ...	P-000147	Cap, indicator		
15 ...	P-5470	Bag Supporter Assy	30 ...	P-0701	Switch Lever		

Agitator Assembly



	P-10759	Agitator, complete	7	P-10765	Washer	13 ...	P-1077
2	P-10760	Internal Gear	8	P-10766	Lock Nut	14 ...	P-1077
3	P-10761	Screw, internal gear	9	P-10767	Holder, bearing	15 ...	P-1077
4	P-10762	Agitator, tufted	10 ...	P-10768	Holder, agitator	16 ...	P-1077
5	P-10763	Motor, agitator	11 ...	P-10769	Bearing	17	
6	P-10764	Fan	12 ...	P-10770	Rubber Support		


Motor Case & Motor



PANASONIC

V-

Models: MC-V7400D, MC-V7407D



- 1 P-10774 Dust Compartment Assy, V7400D
- 1 P-10791 Dust Compartment Assy, V7404D
- 2 P-10691 Screw, handle cap
- 3 P-9907 Screw, handle
- 4 P-8972 Cover, suction inlet
- 5 P-10436 Hose
- 6 P-6140 Screw, bracket
- 7 P-10512 Packing, suction inlet
- 8 P-6069 Crevice Tool
- 9 P-10781 Extension Wand, w/ tabs, V7400D
- 9 P-8180 Extension Wand, w/ tabs, V7404D
- 10 P-9873 Hose Ring
- 11 P-60104 Extension Wand, w/o tabs
- 12 P-10638 Cord Reel Cover
- 13 P-6140 Screw, cord reel cover
- 14 P-10782 Brake Lever Assy, V7400D
- 14 P-10639 Brake Lever Assy, V7404D
- 15 P-10640 Cord Reel Assy
- 16 P-6140 Screw, cord reel assy
- 17 P-10783 Contact Base Assy, V7400D
- 17 P-10709 Contact Base Assy, V7404D
- 18 P-10663 Contact Disc Assy
- 19 P-10680 Cord Reel Hub Assy
- 20 P-10641 Bracket, cord reel

