


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



PANASONIC V7501 Owner's Manual

[Shop genuine replacement parts for PANASONIC
V7501](#)




[Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models](#)

----- Manual continues below -----

Models: MC-V7501/7505/7515


Nozzle Housing

- | | | |
|----|----------|---------------------------------------|
| 1 | P-10893 | Nozzle Housing |
| | P-11166 | Nozzle Housing, 7501 |
| | P-111307 | Nozzle Housing, 7515 |
| 2 | P-10894 | Furniture Guard |
| 3 | P-6140 | Screw, window |
| 4 | P-10895 | Lower plate |
| | P-27005 | Lower plate, 7515 |
| 5 | P-10357 | Shaft roller |
| 6 | P-9888 | Roller, nozzle |
| 7 | P-10896 | Spring, lower plate |
| 8 | P-6140 | Screw, handle release assembly |
| 9 | P-10897 | Tensioner assembly |
| | P-11167 | Tensioner assembly, 7501 |
| 10 | P-10898 | Idler unit assembly |
| | P-11168 | Idler unit assembly, 7501/7515 |
| 11 | P-6140 | Screw, idler unit assembly |
| 12 | P-11198 | Flat belt |
| | P-11169 | Flat belt, 7501/7515 |
| 13 | P-000506 | Stretch belt |
| | P-11170 | Stretch belt, 7501/7515 |
| 14 | P-10899 | Cover, belt, 7505/7515 |
| | P-11171 | Cover, belt, 7501 |
| 15 | P-11199 | Holder, pin |
| | P-11172 | Holder, pin, 7501/7515 |
| 16 | P-6140 | Screw, pin holder |
| 17 | P-43 | Belt guide |
| 18 | P-10886 | Pulley, idler |
| 19 | P-10887 | Pedal, bare floor |
| 20 | P-10888 | Screw, bare floor |
| 21 | P-10889 | Window, agitator |
| 22 | P-000095 | Frame, handle release assembly |
| 23 | P-4720 | Pedal, handle release assembly |
| 24 | P-00051 | Pedal shaft, handle release assembly |
| 25 | P-9857 | Pedal spring, handle release assembly |
| 26 | P-6140 | Screw, lower plate |
| 27 | P-11173 | Packing, nozzle, 7501 |
| 28 | P-6140 | Screw, tensioner assembly, 7501 |




Agitator Assembly

- | | | |
|---|----------|-------------------------|
| 1 | P-10890 | Agitator Assembly |
| | P-111306 | Agitator Assembly, 7515 |
| 2 | P-10891 | Bearing unit |
| 3 | P-0030 | Washer |
| 4 | P-10892 | Gear box |
| 5 | P-6140 | Screw, gear box |



Models: MC-V7501/7505/7515

Motor Housing



1 P-10900 Dust compartment unit

2 P-10602 ON/OFF switch

3 P-11200 Lead wire, black
P-11178 Lead wire, black, 7501/7515

4 P-11201 Lead wire, black with receptacle
P-11177 Lead wire, black with
receptacle, 7501/7515

5 P-0698 Cord stopper, 7505/7515

P-10870 Cord stopper, 7501

6 P-6140 Screw, cord stopper

17 P-10905 Bag supporter, top

18 P-6140 Screw, bag supporter

19 P-10906 Packing, air outlet
P-10512 Packing, air outlet, 7501

20 P-6140 Screw, bag supporter

P-10905 Screw, bag supporter, 7515

21 P-10838 Dust cover

P-10908 Dust cover, 7515

P-11180 Dust cover, 7501

22 P-10909 Motor case

P-11180

32 P-10909

33 P-10909

34 P-10909

P-11180

35 P-10909

36 P-10709


P-10709

37 P-11201

P-11180

Models: MC-V7501/7505/7515

Body



1	P-10935	Power cord
	P-10802	Power cord, 7515
2	P-10936	Handle cover
3	P-7035	Upper storage cord hook
4	P-10937	Handle seal
5	P-6140	Screw, handle cover
6	P-10938	Handle button unit
7	P-10939	Spring, handle
	P-11174	Spring handle, 7501/7515

19	P-10948	Connector
20	P-6140	Screw, co
21	P-6140	Screw, air
22	P-11206	Exhaust fi
	P-11178	Exhaust fi
23	P-10945	Filter cover
	P-10949	Filter cover
24	P-10950	Hose hook
25	P-10962	Hose ri