


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).




PANASONIC V7531 Owner's Manual

**Shop genuine replacement parts for PANASONIC
V7531**



Nozzle Housing

Agitator Assembly




Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models

----- Manual continues below -----

Models: MC-V7531

Nozzle Housing

- 1 P-10893 Nozzle housing
- 2 P-10894 Furniture guard
- 3 P-6140 Screw, window
- 4 P-10895 Lower plate
- 5 P-10357 Shaft, roller
- 6 P-111284 Roller, nozzle
- 7 P-10896 Spring, lower plate
- 8 P-6140 Screw, handle release assembly
- 9 P-11167 Tensioner assembly
- 10 P-10886 Idler unit assembly
- 11 P-6140 Screw, idler unit assembly
- 12 P-11169 Flat belt
- 13 P-11170 Stretch belt
- 14 P-10899 Cover, belt
- 15 P-11172 Holder, pin
- 16 P-6140 Screw, pin holder
- 17 P-43 Belt guide
- 18 P-10886 Pulley, idler
- 19 P-10887 Pedal, bare floor
- 20 P-10888 Screw, bare floor
- 21 P-10889 Window, agitator
- 22 P-000095 Frame, handle release assembly
- 23 P-4720 Pedal, handle release assembly
- 24 P-00051 Pedal shaft, handle release assembly
- 25 P-9857 pedal spring, handle release assembly
- 26 P-6140 Screw, lower plate
- 27 P-11173 Packing nozzle
- 28 P-6140 Screw, tensioner assembly




Agitator Assembly

- 1 P-10890 Agitator assembly
- 2 P-10891 Bearing unit
- 3 P-0030 Washer
- 4 P-10892 Gear box
- 5 P-6140 Screw, gear box



Models: MC-V7531

Motor Housing



1 P-111285 Dust compartment unit

2 P-111286 ON/OFF switch

3 P-11178 Lead wire, black

18 P-6140 Screw

19 P-10906 Packing, air outlet

20 P-6140 Screw, bag supporter


35 P-1112

36 P-107

37 P-111

Models: MC-V7531

Body



| | | |
|---|----------|-------------------------|
| 1 | P-10802 | Power cord |
| 2 | P-10936 | Handle cover |
| 3 | P-111293 | Upper storage cord hook |
| 4 | P-111294 | handle seal |
| 5 | P-6140 | Screw, handle cover |
| 6 | P-10938 | Handle button unit |
| 7 | P-11174 | Spring, handle |
| 8 | P-3820 | Wire cord |

| | | |
|----|----------|------------|
| 24 | P-10962 | Hose ring |
| 25 | P-10964 | Nozzle ho |
| 26 | P-10963 | Nozzle ho |
| 27 | P-111299 | Attachme |
| 28 | P-111300 | Wand with |
| 29 | P-6069 | Crevice to |
| 30 | P-10403 | Hose hold |
| 31 | P-0091 | Fabric bru |