


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).




PANASONIC V7571 Owner's Manual

[Shop genuine replacement parts for PANASONIC
V7571](#)



Agitator Assembly




[Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models](#)

----- Manual continues below -----

Models: MC-V7571


Nozzle Housing

- | | | |
|----|----------|---------------------------------------|
| 1 | P-10893 | Nozzle housing |
| 2 | P-10894 | Furniture guard |
| 3 | P-6140 | screw, window |
| 4 | P-10895 | Lower plate |
| 5 | P-10357 | Shaft, roller |
| 6 | P-111284 | Roller, nozzle |
| 7 | P-10896 | Spring, lower plate |
| 8 | P-6140 | Screw, handle release assembly |
| 9 | P-11167 | Tensioner assembly |
| 10 | P-11168 | Idler unit assembly |
| 11 | P-6140 | screw, Idler unit assembly |
| 12 | P-11169 | Flat belt |
| 13 | P-11170 | Stretch belt |
| 14 | P-10899 | Cover, belt |
| 15 | P-11172 | Holder, pin |
| 16 | P-6140 | Screw, pin holder |
| 17 | P-43 | Belt guide |
| 18 | P-10886 | Pulley, idler |
| 19 | P-10887 | Pedal, bare floor |
| 20 | P-10888 | Screw, bare floor |
| 21 | P-10889 | Window, agitator |
| 22 | P-000095 | Frame, handle release assembly |
| 23 | P-4720 | Pedal, handle release assembly |
| 24 | P-00051 | Pedal shaft, handle release assembly |
| 25 | P-000010 | Pedal spring, handle release assembly |
| 26 | P-6140 | Screw, lower plate |
| 27 | P-11173 | Packing, nozzle |
| 28 | P-6140 | Screw, tensioner assembly |




Agitator Assembly

- | | | |
|---|---------|-------------------|
| 1 | P-10890 | Agitator assembly |
| 2 | P-10891 | Bearing unit |
| 3 | P-0030 | Washer |
| 4 | P-10892 | Gear box |
| 5 | P-6140 | Screw, gear box |



Models: MC-V7571

Motor Housing




- | | | |
|---|----------|----------------------------------|
| 1 | P-111331 | Dust compartment unit |
| 2 | P-10602 | ON/OFF switch |
| 3 | P-111332 | Lead wire, black |
| 4 | P-11177 | Lead wire, black with receptacle |
| 5 | P-0698 | Cord stopper |
| 6 | P-6140 | Screw, cord stopper |
| 7 | P-000623 | Wire connectors |
| 8 | P-111333 | Switch cover |

- | | | |
|----|----------|------------------------|
| 23 | P-111336 | Secondary Filter |
| 24 | P-111337 | Fan motor unit |
| 25 | P-10953 | Seal, fan motor |
| 26 | P-11185 | Motor support, rear |
| 27 | P-111338 | Motor support assembly |
| 28 | P-10776 | Protector |
| 29 | P-10316 | Spring, protector |
| 30 | P-11141 | Support protector |


Models: MC-V7571

Body



Models: MC-V7571

Dust Bin



1	P-111352	Filter case
2	P-111353	Cover, handle
3	P-111354	Button, release
4	P-41355	Spring, release button
5	P-10888	Screw, handle cover
6	P-111356	Knob
7	P-9907	Screw, knob
8	P-111357	Cam, cleaning