


Models: MC-V100

## Nozzle Housing



- 1 ..... P-10564 ..... Nozzle Cover, front
- 2 ..... P-10565 ..... Insert, nozzle cover
- 3 ..... P-10566 ..... Button, on/off switch
- 4 ..... P-10567 ..... Button, overload protector
- 5 ..... P-000342 ..... Screw
- 6 ..... P-10568 ..... Nozzle Cover, main
- 7 ..... P-10569 ..... Furniture Guard
- 8 ..... P-10570 ..... Shroud, motor
- 9 ..... P-10571 ..... Motor
- 10 ..... P-10572 ..... Washer
- 11 ..... P-10573 ..... Grommet, rubber
- 12 ..... P-10574 ..... Motor Mount
- 13 ..... P-10575 ..... Seal, motor shaft


- 14 ..... P-10576 ..... Seal A, swivel
- 15 ..... P-10577 ..... Swivel
- 16 ..... P-10578 ..... Impeller
- 17 ..... P-10579 ..... Packing, air outlet
- 18 ..... P-10580 ..... Washer, impeller
- 19 ..... P-10581 ..... Nut, impeller
- 20 ..... P-10582 ..... Plate, swivel
- 21 ..... P-10583 ..... Seal B, swivel
- 22 ..... P-10584 ..... Elbow, air intake
- 23 ..... P-10585 ..... Gasket, air intake elbow
- 24 ..... P-10586 ..... Overload Protector
- 25 ..... P-10587 ..... Power Cord
- 26 ..... P-62001 ..... Retainer, power cord

- 27 ..... P-000623 ..... Wire Connector
- 28 ..... P-10588 ..... On/Off Switch
- 29 ..... P-10584 ..... Wheel, rear
- 30 ..... P-10590 ..... Nozzle Base
- 31 ..... P-MCV10B ..... Belt, sold each
- 32 ..... P-10357 ..... Axle Shaft
- 33 ..... P-10591 ..... Wheel, front
- 34 ..... P-000361 ..... End Cap, agitator
- 35 ..... P-0030 ..... Washer, agitator
- 36 ..... P-10592 ..... Agitator



Models: MC-V100

## Handle, Bag Cover & Dust Bag



- |    |          |                         |
|----|----------|-------------------------|
| 1  | P-6800   | Screw, upper cord hook  |
| 2  | P-000633 | Cord Hook, upper        |
| 3  | P-10593  | Handle, upper           |
| 4  | P-10594  | Bag Support             |
| 5  | P-10595  | Cover, top bag retainer |
| 6  | P-53701  | Bag Retainer, top       |
| 7  | P-10596  | Bag Cover               |
| 8  | P-MCV10P | Paper Bag, U9, each     |
| 9  | P-6140   | Screw, lower cord hook  |
| 10 | P-10597  | Cord Hook, lower        |
| 11 | P-10598  | Handle, lower           |
| 12 | P-65007  | Bag Retainer, bottom    |