


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



# PANASONIC V225 Owner's Manual

[Shop genuine replacement parts for PANASONIC V225](#)




[Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models](#)

----- Manual continues below -----


# PANASONIC

Models: MC-V210, MC-V225

- 1..... P-10806 ..... Nozzle Housing
- 2..... P-10807 ..... Lower Plate Assy
- 3..... P-10808 ..... Lower Plate
- 4..... P-9766 ..... Body, lower plate
- 5..... P-6140 ..... Screw, body, lower plate, 10pk
- 6..... P-10394 ..... Packing, lower plate
- 7..... P-43 ..... Belt Cover
- 8..... P-683 ..... Screw, nozzle, 10pk
- 9..... P-2444 ..... Latch
- 10..... P-10819 ..... Plastic Shaft
- 11..... P-10456 ..... Window Cover
- 12..... P-58 ..... Pedal Spring
- 13..... P-9846 ..... Stop Latch Spring
- 14..... P-00181 ..... Belt
- 15..... P-10832 ..... Slider Support
- 16..... P-10527 ..... Sliding Knob
- 17..... P-10528 ..... Height Adjustment Cam
- 18..... P-9888 ..... Wheel, V210  
P-111284 ..... Wheel, V225
- 19..... P-10357 ..... Shaft, wheel
- 20..... P-6140 ..... Screw, slider support, 10pk
- 21..... P-78 ..... Plastic Holder
- 22..... P-10304 ..... Nozzle hose, V225




**B** BLOCK



# PANASONIC

Models: MC-V210, MC-V225




# PANASONIC

Models: MC-V210, MC-V225

1..... P-10529 ..... Dust compartment unit, V210	19..... P-02712 ..... Cover, suction inlet	36..... P-10
P-10803 ..... Dust compartment unit, V225	20..... P-6140 ..... Screw, suction inlet	P-89
2..... P-10451 ..... On/Off Switch	21..... P-8943 ..... Motor Case, V210	37..... P-93
3..... P-10804 ..... Power Cord	P-11197 ..... Motor Case, V225	38..... P-00
4..... P-000623 ..... Wire Connector, 10pk	22..... P-201 ..... Packing, rear cover	39..... P-00
5..... P-660106 ..... Packing, dust cover	23..... P-10825 ..... Packing, motor case	40..... P-69
6..... P-10452 ..... Switch Cover	24..... P-98104 ..... Screw, motor case, 10pk, V210	41..... P-18
7..... P-73006 ..... Packing, switch cover	P-8172 ..... Screw, motor case, 10pk, V225	42..... P-68
8..... P-6140 ..... Screw, 10pk	25..... P-111304 ..... Fan motor unit	43..... P-10
9..... P-7301 ..... Handle Screw	26..... P-10459 ..... Cover Cap, V210	44..... P-10
10..... P-2117 ..... Nut, handle screw	P-10384 ..... Cover Cap, V225	45..... P-10
11..... P-3200 ..... Filter Supporter	27..... P-9912 ..... Screw, ground, 10pk	46..... P-61
12..... P-375 ..... Secondary Filter	28..... P-10670 ..... Noise Suppressor	47..... P-10
P-9994 ..... Secondary filter, HEPA	29..... P-10338 ..... Motor Support, rear	48..... P-10
13..... P-10441 ..... Wheel	30..... P-0293 ..... Rubber, motor support, front	49..... P-60
14..... P-10968 ..... Shaft, wheel	31..... P-10385 ..... Wire Cord	50..... P-60
15..... P-74009 ..... Stopper, wheel	32..... P-000623 ..... Wire Connector, 10pk	51..... P-81
16..... P-6115 ..... Washer, wheel	33..... P-10537 ..... Handle, w/ cord hook	52..... P-98
17..... P-145M ..... Paper Bag, U6, micron, 3pk, V210	34..... P-10816 ..... Lead Wire Assy	
P-111387 ..... Dust Bag, U6, V225	35..... P-10833 ..... Dust Cover, V210	
18..... P-6140 ..... Screw, suction inlet, 10pk	P-111577 ..... Dust Cover, V225	

1..... P-10809 ..... Agitator Unit, V210
P-111576 ..... Agitator Unit, V225
2..... P-9906 ..... End Cap, V210
3..... P-10810 ..... Brush Unit, V210



B-1  
Agitator As

1..... P-000067 ..... Fan Case
2..... P-000068 ..... Nut
3..... P-00621 ..... Washer (a)
4..... P-000152 ..... Fan
5..... P-6206 ..... Washer (b)
6..... P-10329 ..... Spacer
7..... P-10393 ..... Brush Assy, set, V215
P-270091 ..... Brush Assy, set, V225
8..... P-0036 ..... Bracket

