


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



PANASONIC V325 Owner's Manual

[Shop genuine replacement parts for PANASONIC V325](#)




[Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models](#)

----- Manual continues below -----


PANASONIC

Models: MC-V325




PANASONIC

Models: MC-V325




A
1.....



Ha

- 1..... P-11
- 2..... P-66
- 3..... P-60
- 4..... P-10
- 5..... P-11
- 6..... P-10
- 7..... P-98
- 8..... P-60
- 9..... P-11




Mot

- 1.....
- 2.....
- 3.....
- 4.....

PANASONIC

Models: MC-V325

Body



PANASONIC

Models: MC-V325

Body, Motor Housing, and Motor

1	P-10563	Dust compartment
2	P-7330	Screw, handle
3	P-10545	Carry handle
4	P-10546	Support plate
5	P-10547	Tool holder
6	P-111417	Protector case
7	P-692	Spring, protector, blue
8	P-000057	Protector
9	P-111416	Protector supporter
10	P-10602	Switch, on/off
11	P-10389	Rubber protector
12	P-10823	Power cord, 50 ft.
13	P-00104	Wire tie
14	P-10968	Shaft, wheel
15	P-6115	Washer, wheel
16	P-0062	Wheel
17	P-74009	Stopper, wheel
18	P-2486	Fitting, handle
19	P-10549	Supporter, handle
20	P-8172	Screw, handle supporter
21	P-6140	Screw, carry handle
22	P-6140	Screw, tool holder
23	P-3780	Filter, secondary
24	P-10551	Wire cord
25	P-9912	Screw, grounding
26	P-000623	Wire connector, switch area
27	P-4410	Lead wire, black
28	P-10552	Switch cover
29	P-6140	Screw, switch cover
30	P-111476	Bumper
31	P-111387	Dust bag
32	P-10628	Release button, dust cover
33	P-10824	Dust cover
34	P-111478	Filter cover
35	P-111479	Filter, electrostatic exhaust
	P-MCV197H	Filter, HEPA
36	P-10558	Filter, motor case
37	P-111480	Motor case
38	P-8172	Screw, motor case
39	P-10533	Motor assembly
40	P-2700091	Carbon brush, motor
41	P-0293	Motor support, front
42	P-9911	Motor support, rear
43	P-9912	Screw, motor flange