


Power Nozzle & Agitator Assembly



- 1 P-10601 Lower Body Unit
- 2 P-10603 Belt Guard
- 3 P-4505 Axle, front
- 4 P-90016 Wheel
- 5 P-681689 Spring, round, 5/16"
- 6 P-681384 Washer
- 7 P-5702 pedal Spring
- 8 P-10604 Shaft, pedal
- 9 P-10605 Pedal, handle release
- 10 P-6140 Screw
- 11 P-10599 Belt, 2pk
- 12 P-10606 Motor Assy
- 13 P-000353 Seal, motor shaft
- 14 P-7011 Motor Support
- 15 P-2905 Motor Holder
- 16 P-8172 Screw
- 17 P-10607 Cover, lower plate
- 18 P-6809 Latch Cover
- 19 P-9846 Spring, stop latch


- 20 P-57006 Knob, height adjustment
- 21 P-61009 Height Adjustment Cam
- 22 P-000623 Wire Connector
- 23 P-10608 Lead Wire, black
- 24 P-10609 Lead Wire, red
- 25 P-53106 Slider Support
- 26 P-76009 Overload Protector
- 27 N/A On/Off Switch, bare floor
- 28 P-10570 brush Shroud, motor
- 29 P-10610 Packing, motor seal
- 30 P-10611 Nozzle Housing Assembly
- 31 P-87005 Spring, reset button
- 32 P-64006 Push Button, reset
- 33 P-10612 Window Cover

- 34 P-10613 Plastic Holder
- 35 P-87005 Bulb Socket
- 36 P-7550 Bulb, light
- 37 P-10614 Wire Cover
- 38 P-000041 1/8" Spring
- 39 P-10615 Axle Clip
- 40 P-10616 Insulation Tube
- 41 P-8172 Screw
- 42 P-0030 Washer

Models: MC-V400

1 P-10617 Dust Cmpartment	19 P-10549 Supporter, handle	37 P-10545 Carrying Handle
2 P-04005 Shaft, rear wheel	20 P-10552 Switch Cover	38 P-10547 Attachment Tray
3 P-10618 Plastic Bearing	21 P-92109 Suction Motor Assy	39 P-10546 Support Plate
4 P-681384 washer	22 P-10625 Lead Wire, white	40 P-10429 Power Cord
5 P-6009 Wheel, rear	23 P-9931 Noise Suppressor	41 P-10389 Rubber Protector
6 P-681689 Spring, round, 5/16"	24 P-24 Motor Support, front	42 P-10555 Dust Cover
7 P-10619 Label, wheel	25 P-10626 Motor Support, rear	43 P-10628 Cover Button
8 P-10620 Cover, rear wheel	26 P-93033 Plastic Cover, motor	44 P-7330 Handle Screw
9 P-6140 Screw	27 P-10627 Motor Cover, front	45 P-145M Paper Bag, type U6, micro, 3pk
10 P-10602 Switch, on/off	28 P-10553 Bumper	46 P-10629 Insulation Tube
11 P-0696 Switch, bare floor	29 P-10551 Wire Cord	47 P-1510 Lever, switch
12 P-10621 Lead Wire, blue	30 P-10557 Filter	48 P-5860 Body Packing, left
13 P-10622 Lead Wire, blue	31 P-10556 Cover, front filter	49 P-3990 Body Packing, right
14 P-10623 Lead Wire, black	32 P-10550 Filter, secondary	50 P-8172 Screw
15 P-000623 Wire Connector	33 P-3209 Filter Supporter	51 P-9912 Screw, grounding
16 P-10624 Ground Wire, green	34 P-10558 Filter, exhaust	52 P-00104 Tie Cable
17 P-4410 Lead Wire, black	35 P-9406 Hose Assembly, short	
18 P-2486 Fitting, handle	36 P-0035 Carbon Brush, 2pk	

Agitator Assembly



P-9299 Agitator Assembly
2 P-10630 Agitator Unit
3 P-7809 Brush, long
4 P-7909 Brush, short
5 P-9906 Bearing Unit
6 P-0030 Washer

Handle, Hose & Attachments

1 P-9509 Handle Assembly
2 P-000633 Cord Hook
3 P-6800 Screw, cord hook
4 P-10560 Handle
5 P-8972 Suction Inlet Cover
6 P-8179 Hose Unit, stretch
7 P-9894 Packing, suction inlet
8 P-6069 Crevice Tool
9 P-10631 Wand, telescoping
10 P-10562 Suction Control
11 P-6088 Dusting Brush
12 P-6620 Upholstery Nozzle

