



Index	Part #	Description
B-1	P-11496	Dust Cover Assembly
B-2	P-11497	Dust Cover
B-3	P-11498	Buckle
B-4	P-11499	Buckle Spring
B-5	P-11500	Packing
B-6	P-11501	Suction Inlet Packing
B-7	P-11502	Cord Rewind Pedal
B-8	P-11503	Switch Pedal
B-9	P-11504	Pedal Spring
B-10	P-11505	Handle
B-11	P-11506	Indicator Unit
B-12	P-11507	Upper Body Unit
B-13	P-11508	Gasket
B-14	P-11509	Cord Reel Partition Unit
B-15	P-11510	Rail Base Unit
B-16	P-11511	Control Knob Unit
B-17	N/A	Control
B-18	N/A	Printed Circuit Board A Unit
B-19	P-11512	Switch Cover
B-20	P-11513	Printed Circuit Board Holder
B-21	P-11514	Motor Support Rubber Rear
B-22	P-11515	Motor Support Front
B-23	P-11516	Noise Suppressor Unit

Index	Part #	Description
B-24	P-11517	Fan Motor Unit
B-25	P-11518	Motor Support Rubber Front
B-26	P-11519	Secondary Filter
B-27	P-11520	Pre-filter
B-28	P-11521	Paper Bag (Type C-20E, 5pk)
B-29	P-11522	Bag Supporter
B-30	P-11523	Spring A
B-31	P-11524	Dust Box Packing
B-32	P-11525	Wheel
B-33	P-11526	Handle Cover
B-34	P-11527	Lower Body
B-35	P-11528	Caster Unit
B-36	P-11529	Gasket H
B-37	P-11530	Gasket J
B-38	P-11531	Filter Unit
B-39	P-11532	Filter Cover
B-40	P-11533	Dusting Brush Unit
B-41	P-11534	Crevice Tool
B-42	P-11535	Tapping Screw
B-43	P-11536	Tapping Screw
B-44	P-11537	Tapping Screw
B-45	P-11538	Tapping Screw

ATTACHMENTS

Index	Part #	Description
A1	P-11477	Hose Assembly
A2	P-11478	Extension Wand Unit
A3	P-11479	Turbin Nozzle
A4	P-11480	Crevice Tool
A5	P-11481	Dusting Brush
A6	P-11482	Floor Nozzle Upper Unit
A7	P-11483	Nozzle Lever
A8	P-11484	Supporter
A9	P-11485	Agitator Assembly
A10	P-11486	Belt
A11	P-11487	Nozzle Wand Unit
A12	N/A	Turbine Assembly
A13	P-11488	Nozzle
A14	P-11489	Floor Nozzle Lower Unit
A15	P-11490	Floor Nozzle Brush D Unit
A16	P-11491	Floor Nozzle Brush C Unit
A17	P-11492	Floor Nozzle Brush F Unit
A18	P-11493	Floor Nozzle Brush E Unit
A19	P-11494	Brush Cover Unit
A20	P-11495	Screw

