


This Owner's Manual is provided and hosted by Appliance Factory Parts.



PANASONIC 8430 Owner's Manual

[Shop genuine replacement parts for PANASONIC 8430](#)



[Find Your PANASONIC Vacuum Cleaner Parts - Select From 605 Models](#)

----- Manual continues below -----

PANASONIC

Models: MC-7420, MC-8420, MC-8430

Dust Cover and Attachments



A1	P-6060	Dust Cover
A2	P-125P	Paper Bag, 3 pack
A2	P-125PT	Paper Bag, 12 pack
A2	254	Paper Bag, 3 pack (R)
A2	254-12	Paper Bag, 12 pack (R)
A3	P-9974	Floor and Wall Brush
A4	P-3810	Attachment Tray A
A5	P-3731	Attachment Tray B
A6	P-882	Dusting Brush
A7	P-864	Upholstery Brush
A8	P-6073	Crevice Tool
A9	P-12344	Floor Nozzle Assembly, 7420
A10	P-12345	Pipe, floor nozzle, 7420
A11	P-12346	Upper Housing, floor nozzle, 7420
A12	P-364	Roller, floor nozzle, 7420
A13	P-12347	Roller Shaft, floor nozzle, 7420
A14	P-12348	Bumper, floor nozzle, 7420
A15	P-12349	Lower Housing, floor nozzle, 7420
A16	P-416	Screw, 7420, 10 pk
A17	P-12350	Hose Assembly, 7420
A17	P-97062	Hose Assembly, 8420,8430
A18	P-9840	Wand, curved
A19	P-164	Grip Cover
A20	P-9274	Spring Button
A21	P-542	Suction Regulator
A22	P-12354	Extension Wand
	N/A	Label, 7420
	P-614	Packing



PANASONIC

Models: MC-7420, MC-8420, MC-8430


Body Unit



PANASONIC

Models: MC-7420, MC-8420, MC-8430

Cord Reel Unit



- | | | | | |
|----|-------|---------|-------|-----------------------------|
| C1 | | P-12395 | | Body Partition |
| C2 | | N/A | | Spring, brake |
| C3 | | P-12397 | | Lever Unit, brake |
| C4 | | P-12398 | | Contact Base Unit |
| C5 | | P-12399 | | Rail base Unit / Power Cord |
| C6 | | N/A | | Cord Reel Assembly |
| C7 | | P-416 | | Screw, 10 pk |
| C8 | | P-12400 | | Screw |

Motor Assembly

PANASONIC

Models: MC-8420, MC-8430

Power Nozzle

E1	P-124078	Top Mark
E2	P-12098	Body
E3	P-12410	Packing, body
E4	P-12411	Furniture Guard
E5	N/A	Pipe Connector
E6	P-12413	Joint Pipe
E7	P-12414	Filter
E8	N/A	Motor Assembly, power nozzle
E9	P-12416	Motor Support, rubber, upper
E10	P-12417	Cover, motor support
E11	P-280	Belt, 2 pack
E11	P-100	Belt, 2 pack (R)
E12	P-12418	Stop Spring, pipe
E13	P-81	Tight Packing
E14	N/A	Bottom Cover
E15	P-909	Roller, floor nozzle
E16	P-12420	Shaft, floor nozzle roller
E17	N/A	Roller
E18	P-12422	Shaft, roller
E19	P-12423	Rubber, floor nozzle
E20	P-02	Motor Support, rubber, front
E21	P-394	Power Cord
E22	SS-34	Cord Bushing, sold each (R)
E23	P-430	Screw
E24	P-413	Screw
E25	P-03	Motor Support, rubber, rear
E26	P-12428	Screw

Agitator Assembly

	P-921	Agitator Assembly
F2	P-05	E-Clip, 30 pk
F3	P-74	Spacer
F4	P-85	Brush Strip, 4 pcs used
F4	P-425	Brush Strip, pair (R)
F5	N/A	Agitator Pulley, w/ bearing