


Power Nozzle




Models: MC-V9644

Power Nozzle

| Index | Part No. | Description |
|-------|----------|----------------------------------|
| 1 | P-11251 | Wand Assembly, Upper |
| 2 | P-11094 | Wand Assembly, Lower |
| 3 | P-000372 | Lock, Spring Wand |
| 4 | P-11252 | Power Head Cover |
| 5 | P-00126 | Lens, Light Cover |
| 6 | P-00124 | Lens, Height Adjustment |
| 7 | P-11098 | Extension, Button |
| 8 | P-00036 | Screw, Nozzle Cover |
| 9 | P-11253 | Nozzle Cover |
| 10 | P-11099 | Furniture Guard |
| 11 | P-11100 | Screw, Wand Release Button Cover |
| 12 | P-11101 | Rear Cover, Wand Release Button |
| 13 | P-11102 | Wand Release Button |
| 14 | P-11103 | Bulb Socket |
| 15 | P-7550 | Bulb, Headlight |
| 16 | P-11222 | Swivel Cap |
| 17 | P-11105 | Swivel |
| 18 | P-00128 | Swivel Seal |
| 19 | P-11106 | Front Cover |
| 20 | P-11107 | Pad, Foot Pedal |
| 21 | P-00129 | Lever, Indicator |
| 22 | P-111397 | Cam, Indicator |
| 23 | P-00130 | Washer, Thrust |
| 24 | P-00131 | Washer |
| 25 | P-00132 | Catch, Indexing |
| 26 | P-00078 | Ratchet, Catch |
| 27 | P-00133 | Indicator Block |
| 28 | P-00134 | Spring, Assist |
| 29 | P-00342 | Screw, Motor Bridge |
| 30 | P-00135 | Bridge, Motor |
| 31 | P-11108 | Lead Wire "A" Unit |
| 32 | P-11254 | Belt (Type CB-6) |
| 33 | P-11223 | Motor, Nozzle |
| 34 | P-00137 | Spring, Motor Adjust |
| 35 | P-000623 | Wire Connector |
| 36 | P-00067 | Overload Protector |
| 37 | P-11110 | Release, Handle |
| 38 | P-11112 | Lifter |
| 39 | P-00138 | Roller, Rear |
| 40 | P-00138 | Axle, Rear |
| 41 | P-11255 | Base |
| 42 | P-00139 | Axle Assembly, Front |
| 43 | P-11225 | Agitator Assembly |
| 44 | P-11256 | Power Nozzle Assembly |

Models: MC-V9644

Body




Models: MC-V9644

Body

| Index | Part No. | Description |
|-------|----------|----------------------------|
| 1 | P-11257 | Canopy Cover |
| 2 | P-11128 | Brake Pedal |
| 3 | P-111398 | Spring, Cord Button |
| 4 | P-11127 | Final Filter |
| 5 | P-11158 | Motor Shield |
| 6 | P-11129 | Cord Cover |
| 7 | P-000303 | Electrostatic Filter |
| 8 | P-11131 | Relay |
| 9 | P-4104 | Screw |
| 10 | P-11132 | Motor Assembly |
| 11 | P-11133 | Motor Seal Assembly |
| 12 | P-11134 | Lead Wire |
| 13 | P-11135 | Lead Wire |
| 14 | P-8182 | Motor Brush |
| 15 | P-11136 | Motor |
| 16 | P-11137 | Screw |
| 17 | P-000272 | Screw |
| 18 | P-11159 | Cord Reel |
| 19 | P-111399 | Handle Grip |
| 20 | P-11160 | Wheel, Rear |
| 21 | P-11139 | Lower Body |
| 22 | P-00026 | Filter Frame |
| 23 | P-11258 | Bumper, Molded |
| 24 | P-11141 | Wiring Harness |
| 25 | P-00021 | Pin, Caster Retainer |
| 26 | P-11142 | Wheel, Caster |
| 27 | P-11143 | Caster, Roller Unit |
| 28 | P-11144 | Bulkhead |
| 29 | P-11259 | Dust Box Unit |
| 30 | | Tool Storage Unit |
| 31 | P-11147 | Hood Latch |
| 32 | P-11148 | Crevice Tool |
| 33 | P-11149 | Dusting Brush |
| 34 | P-11150 | Floor Brush |
| 35 | P-11151 | Fabric Brush |
| 36 | P-11260 | Dust Bag |
| 37 | P-11262 | Bag Mount |
| 38 | P-00101 | Gasket, Port |
| 39 | P-00102 | Spring, Bag Mount |
| 40 | P-11152 | Strike Insert |
| 41 | P-11261 | Indicator Packing |
| 42 | P-11154 | Performance Indicator Unit |
| 43 | P-6363 | Bracket |
| 44 | P-4104 | Screw |

Models: MC-V9644

Hose



| Index | Part No. | Description |
|-------|----------|------------------|
| 1 | P-11263 | Hose Assembly |
| 2 | P-11264 | Hose Unit |
| 3 | P-11122 | Ornamental Plate |
| 4 | P-11123 | Handle Unit |
| 5 | P-11265 | Switch |
| 6 | P-11125 | Switch Button |
| 7 | P-11126 | Suction Control |
| 8 | P-10691 | Screw |