

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Bissell 3920 Owner's Manual

[Shop genuine replacement parts for Bissell 3920](#)



[Find Your Bissell Vacuum Cleaner Parts - Select From 377 Models](#)


----- Manual continues below part list -----

Available Replacement Parts for Bissell 3920

BR-1008	BELT VACUUM SANYO (2 PACK)
B-203-1063	CREVICE ATTACHMENT
B-203-1068	EXTENSION WAND
BR-1860	HEPA FILTER
B-203-8045	BRUSH ROLLER ASSEMBLY

Pet Hair Eraser

Model 3920



PET HAIR ERASER

Model 3920

KEY	PART NO	DESCRIPTION	KEY	PART NO	DESCRIPTION
1	2037131	HANDLE ASSY-BLACK PEARL	XX	2036719	POWER SWITCH
2	2031399	TURBOBRUSH - PET	XX	2031297	LIGHT BULB
3	2032304	TWIST AND SNAP HOSE ASSY	XX	2032319	POWER CORD 35FT.
4	2032414	DIRT CUP	XX	1104002	USERS GUIDE
5	2032334	WINDOW LAMP			
6	2032335	PRE MOTOR FILTER TRAY			
7	2032358	CONNECTOR HOSE			
8	2032323	CUSHION-MOTOR F			
9	2032320	MOTOR-FAN AC			
10	2032324	SUPPORT MOTOR			
11	2032317	POST MOTOR FILTER GRILLE			
12	2032308	HOSE CLIP			
13	2032307	HOSE CLIP-UPPER			
14	2032306	HOSE AND CORD ASSY.			
15	2031228	UPHOLSTERY TOOL			
16	2032303	CURVED HOSE			
17	2031022	EXTENSION WAND			
18	2031063	CREVICE TOOL			
20	2032347	LEVER RELEASE			
21	2032346	WHEEL			
22	2032349	SHAFT WHEEL			
23	2032351	H/A ASSY BODY			
24	2032350	NECK BRUSH			
25	2037132	COVER BRUSH - BLACK PEARL			
26	2037133	CASE DRUM ASSY			
27	2032305	DRUM BRUSH ASSY.			
28	2032348	H/A KNOB			
29	2032376	E-RINGS			
30	2032374	ACCESS PLATE			
31	2032388	UPPER LOUVERS			
32	2032372	INNER CYCLONE			
33	2037134	COVER, PET HAIR LIFTER			
34	2037130	PET HAIR ERASER			
35	2031368	PET CONTOUR TOOL			
XX	3290	PRE MOTOR FILTER- STYLE 14			
XX	3091	HEPA POST MOTOR FILTER- STYLE 8/14			
XX	2031093	STYLE 7/9/10 BELT			