


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).




# Kenmore 116.2439081 Owner's Manual

[Shop genuine replacement parts for Kenmore  
116.2439081](#)





[Find Your Kenmore Vacuum Cleaner Parts - Select From 745 Models](#)

----- Manual continues below -----



1	KE-706865	COVER, CANOPY
2	KE-706592	FRAME, CORD LOCK
3	KE-706407	BUTTON, SWITCH
4	KE-748060	SPRING, SWITCH
5	KE-706513	SWITCH, ON-OFF
7	KE-706389	FILTER, REAR EXHAUST
8	KE-706827	AEGIS, MOTOR
9	KE-703515	SHIELD, MOTOR
10	KE-681546	SCREW
11	KE-706011	PLATE, MOTOR MOUNT
12	KE-706821	MOUNT, MOTOR
13	KE-700591	MOTOR
14	KE-588867	BRUSH, MOTOR
15	KE-588708	FAN
16	KE-681550	SCREW
17	KE-706026	CANOPY
18	KE-700889	CORD REEL
19	KE-596564	CONNECTOR, WIRE
20	KE-706007	WHEEL, REAR
21	KE-706002	BASE
22	KE-706061	FILTER, SAFETY
23	KE-706008	BUMPER
24	KE-706398	RECEPTACLE
25	KE-706884	PIN, CASTER RETAINER
26	KE-706006	BEARING, CASTER
27	KE-706005	FRAME, CASTER
28	KE-706004	WHEEL, CASTER
29	KE-706018	HEAD
30	KE-706019	RELEASE, LID
31	<b>KER-14551</b>	BAG, DUST SEARS NO. 20-5055
32	KE-676246	MOUNT, BAG
33	KE-706017	GASKET, PORT
34	KE-706024	SPRING, BAG MOUNT
35	KE-706415	INSERT, STRIKE
36	KE-596702	TIE, CABLE
37	KE-706021	LID, TOOL COVER
38	KE-706026	GRIP, HANDLE
39	KE-706943	FOAM, SWITCH BUTTON



1	KE-743280	HOSE
2	KE-743284	SWIVEL ASSEMBLY
3	KE-743282	LINK, PLUG
4	KE-743295	FRAME, PLUG
5	KE-743276	HOUSING, SWIVEL
6	KE-743337	PIN, CONTACT
7	KE-743340	HANDLE ASSEMBLY
8	KE-742786	ADAPTER, TUBE
9	KE-743374	CONTROL, SUCTION
10	KE-743286	CORD & PLUG ASSEMBLY
11	KE-743352	COVER, CORD
12	KE-742859	LOCK, CORD COVER
13	KE-725419	SPRING, WAND LOCK
14	KE-743079	HOSE ASSEMBLY
15	KE-742806	BRUSH, FLOOR
16	KE-742801	TOOL, CREVICE
17	KE-742811	BRUSH, FABRIC
18	KE-742798	BRUSH, DUSTING