


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://ApplianceFactoryParts.com).




# Kenmore 116.35725400 Owner's Manual

[Shop genuine replacement parts for Kenmore  
116.35725400](#)




[Find Your Kenmore Vacuum Cleaner Parts - Select From 745 Models](#)

----- Manual continues below -----




1	KE-KC97ECDWZV06	Cord, power
2	KE-4370396	Lever, on-off switch
3	KE-4368653	On-off switch, above, floor
4	KE-4370400	Holder
5	KE-4370399	Holder, hose
6	KE-4370392	Holder, wand
7	KE-KC10KCEPZV06	Bag supporter
10	KE-KC95BCKTZR0Q	Handle assembly (complete)
13	KE-4370427	Wire, black lead
14	KE-4370575	Suction inlet packing
15	KE-8191575	Packing, dust container
17	KE-KC60KBFZV0Q	Cover, dust (includes item 24)
18	KER-1800	Filter sears no. 20-86889
20	KE-8191577	Filter, exhaust
21	KE-8191735	Case, motor
24	KE-8192460	Filter assembly
26	KE-4369564	Stopper, wheel (2)
27	KE-KC01CAMAZV07	Wheel
28	KE-4369562	Washer, wheel
29	KE-4369561	Shaft, rear wheel
30	KE-4370404	Support, rubber mount (front)
31	KE-8191580	Hose, flexible
32	KE-4370266	Flange, motor
33	KE-8191785	Screw, belt guard
34	KE-4370265	Support, rubber motor (front)
36	KE-KC40KBLDZV07	Compartment, dust
37	KE-4368522	Connector, wire (2)
38	KE-4368563	Screw, motor, case mounting
42	KE-8191582	Cover, filter
43	KE-4370420	Screw, handle
44	KE-4370280	Screw, motor case mounting
45	KE-4368563	Screw, motor, case mounting
46	KE-4370430	Packing, motor case (adhesive back)
47	KE-4370465	Wire, cord
52	KE-8191589	Lead wire, assembly
55	KE-KC64BBFEZV07	Handle
57	KE-KC14BCHFZV07	Handle lid
67	KE-KC26KCKVZBUU	Case filter assembly
68	KE-8191569	Valve, grommett
77	KE-8191895	Protector assembly
78	KER-1810	Filter unit
80	KE-KC66PBPZV06	Caddy, handi-mate jr.
81	KE-KC82DCJRVO	Clip, caddy
82	KE-4370790	Screw, handle cap mounting



6/04

1 KE-8191685	Cover, light
2 KE-4370410	Window
3 KE-KC01AAMAZR0Q	Housing, nozzle
4 KE-8191728	Latch, nozzle, left side
5 KE-4368563	Screw, motor, case mounting
6 FA-3500	Bulb, light sears no.20-5240
7 KE-4369526	Socket, bult
8 KE-8174976	Cover, agitator, brush
11 KE-4369527	Shaft, wheel
12 KE-4370263	Bearing, nozzle
13 KE-4369606	Screw, retaining
14 KE-4370425	Wheel
15 KE-KC90HAMAZV06	Cam, height adjustment
19 KE-4370394	Pedal
20 KE-4370258	Spring, pedal
21 KE-4370259	Shaft, pedal
22 KE-4370260	Cover, foot pedal
23 KE-8191730	Cover, belt
24 KE-4368563	Screw, motor, case mounting
25 KE-8195180	Shifter, belt
26 KE-4370544	Nozzle, packing
27 KE-4369535	Guard, belt
28 KE-4369542	Sliding knob height adjustment
29 PR-1015	Belt, sears no. 20-5275
30 KE-KC27AAMDZV07	Lower plate assembly
31 KE-8174967	Guard, furniture
32 KE-8192015	Agitator assembly
33 KE-81091810	Screw, belt guard
34 KE-4370433	Reflector , nozzle



1	KE-8191584	Hose, flexible
2	KE-4368684	Tool, crevice sears no. 20-52631
3	KE-4369868	Wand, telescopic
4	KE-4368996	Regulatory, suction
5	KE-4368681	Brush, combination
6	KE-4368609	Brush ,combination