

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Grand Hall PREMIUM 327 Owner's Manual

[Shop genuine replacement parts for Grand Hall
PREMIUM 327](#)







[Find Your Grand Hall Grill Parts - Select From 203 Models](#)

----- Manual continues below -----

Portable Gas Barbecues

Parts List




Barbecue models:

Premium 321S
Premium 323
Premium 325
Premium 326
Premium 326X
Premium 327
Professional 529
Professional 584

Premium 321S, 323, 325 models

This diagram is provided to assist you identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and or service.

Items included in your barbecue specification may differ from the parts list, depending on region or specific dealer specification.




List applicable to Premium 321S, 323, 325 models

Ref	Description	Premium 321S		Premium 323		Premium 325	
		Part No.	Qty	Part No.	Qty	Part No.	Qty
1	Hood assembly	P00119416A	1	P00119414D	1	P00119416A	1
1a	Hood trim plate	P0011424DV	1	-	-	P0011424DV	1
2	Protective pad	P05518001I	4	P05518001I	4	P05518001I	4
3	Temperature gauge	P00601011B	1	P00601011B	1	P00601011B	1
4	Hood badge	P00407006S	1	P00407006S	1	P00407006S	1
5	Hood handle	P00205055B	1	P00205055B	1	P00205055B	1
6	Cooking rack – fixed	P01505008E	1	P01505008E	1	P01505008E	1
7a	Grill plate	P01602004E	2	P01602004E	2	P01602004E	2
7b	Hot plate	P05702002E	1	P05702002E	1	P05702002E	1
8	Flame tamer	P01705009E	2	P01705009E	2	P01705009E	2
9	Body panel – left	P00720261A	1	P00720261A	1	P00720261A	1
10	Body panel – right	P00721281A	1	P00721281A	1	P00721281A	1
11	Body panel – front	P00738169A	1	P00738169A	1	P00738169A	1
12	Body panel – rear	P00725219A	1	P00725219A	1	P00725219A	1
13	Body panel – rear wind shield	P00725224A	1	P00725224A	1	P00725224A	1
14	Burner – main	P02008056A	1	P02008056A	1	P02008056A	1
15	Burner support bracket	P02209012B	1	P02209012B	1	P02209012B	1
16	Gas collector box with electrode	P026080124	3	P026080124	3	P026080124	3
17	Electronic wire set	P02615023A	1	P02615023A	1	P02615023A	1
18	Electronic igniter – 4 port	P02502164C	1	P02502164C	1	P02502164C	1
19	Gas valve / manifold / heat shield assy – LP	Y0060391	1	Y0060392	1	Y0060392	1
19a	Gas valve – with jet	P03222100A	4	P03222100A	4	P03222100A	4
19b	Manifold	P05005112A	1	P05005082A	1	P05005082A	1
19c	Heat shield	P03007073B	1	P03007073B	1	P03007073B	1
20	Decorative front panel	P07508004P	1	P07508004P	1	P07508004P	1
21	Control panel – with screen print	P02913161A	1	P02913171A	1	P02907843A	1
22	Control knob for main burner	P03419123H	4	P03419123M	4	P03419123M	4
23	Control knob seat	P03415263L	4	P03415263L	5	P03415263L	5
24	Grease tray track – left	P05330006K	1	P05330006K	1	P05330006K	1
25	Grease tray track – right	P05330007K	1	P05330007K	1	P05330007K	1
26	Grease draining tray	P02706126A	1	P02706126A	1	P02706126A	1
27	Grease draining tray heat shield	P06903025B	1	P06903025B	1	P06903025B	1
28	Grease receptacle	P02701075B	1	P02701075B	1	P02701075B	1
29	Side shelf – left	P01102020C	1	P01102010C	1	P01102010C	1
29a	Side shelf decoration panel – left	P07503005A	1	-	-	-	-
30	Side shelf – right	P01103020C	1	-	-	-	-
30a	Side shelf decoration – right	P07502015A	1	-	-	-	-
31	Tool holder	P05514008A	1	P05514008A	1	P05514008A	1
32	Tool hook	P05514053F	4	P05514053F	4	P05514053F	4
33	Trolley bottom shelf	P01002051D	1	P01002051D	1	P01002051D	1
34	Castor seat – left front / right rear	P05327007G	2	P05327007G	2	P05327007G	2
35	Castor seat – right front / left rear	P05327008G	2	P05327008G	2	P05327008G	2
36	Trolley legs with side panel – left	P07617011B	1	P07617001B	1	P07617001B	1
37	Trolley legs with side panel – right	P07618021B	1	P07618001B	1	P07618001B	1
38	Trolley rear panel – NG	P07702036B	1	P07702036B	1	P07702036B	1
39	Trolley bracket – front	P03305015D	1	P03305015D	1	P03305015D	1
40	Door stop plate	P05510002B	2	P05510002B	2	P05510002B	2
41	Lighting stick	P05313023B	1	P05313023B	1	P05313023B	1
42	Door	P04301019L	1	P04304001B	1	P04301019A	1
43	Door magnet	P05523002K	2	P05523002K	2	P05523002K	2
44	Door trim plate	P07510002N	1	P07510002B	1	P07510002N	1
45	Door spacer	P06801010G	2	P06801010G	2	P06801010G	2
46	Door handle	P00205029B	1	P00205029B	1	P00205029B	1
47	Door hinge bracket – top right	P03313002D	1	P03313002D	1	P03313002D	1
48	Door hinge bracket – bottom right	P03313003D	1	P03313003D	1	P03313003D	1
49	Castor – 3" with brake	P05119001A	4	P05119001A	4	P05119001A	4
50	Regulator with hose – LP	P03603005A	1	P03603005A	1	P03603005A	1
51	Hose clip	P05528001E	1	P05528001E	1	P05528001E	1
A1	Side burner frame	-	-	P01104015C	1	P01104015C	1
A2	Side burner body assembly	-	-	P02302005D	1	P0115346A	1
A3	Side burner lid	-	-	P00115345K	1	P00119416A	1
A4	Pot support	-	-	P00805013B	1	P00805013B	1
A5	Side burner electrode	-	-	P02607005C	1	P02607005C	1
A6	Side burner gas valve assembly – LP	-	-	Y0060263	1	Y0060263	1
A7	Side burner control knob	-	-	P03426093M	1	P03426093M	1
A9	Side burner body with brass burner ring	-	-	P02002007A	1	P02002007A	1
A10	Side burner bracket	-	-	P02215072E	1	P02215072E	1
A11	Side burner connection hose	-	-	P03705019J	1	P03705019J	1
A12	Side burner body bracket	-	-	P03305011D	2	P03305011D	2
	Hardware pack	P06003065A	1	P06003043B	1	P06003043B	1

Premium 326, 326X models

This diagram is provided to assist you identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and or service.

Items included in your barbecue specification may differ from the parts list, depending on region or specific dealer specification.




List applicable to Premium 326, 326X models

Ref	Description	Premium 326		Premium 326X		Premium 326X Part No.	Qty
		Part No.	Qty	Part No.	Qty		
1	Hood assembly	P0011970AA	1	P0011970AA	1		
1a	Hood trim plate	P0011429DV	1	P0011429DV	1		
2	Protective pad	P05518001I	4	P05518001I	4		
3	Temperature gauge	P00601011B	1	P00601011B	1		
4	Hood badge	P00407006S	1	P00407006S	1		
5	Hood handle	P00205034B	1	P00205034B	1		
6	Cooking rack – fixed	P01506005G	1	P01506005G	1		
7a	Grill plate	P01615028H	3	P01615028H	3		
7b	Hot plate	P05702002E	1	P05702002E	1		
8	Flame tamer	P01708009E	3	P01708009E	3		
9	Body panel – left	P00720631A	1	P00720631A	1		
10	Body panel – right	P00721631A	1	P00721631A	1		
11	Body panel – front	P00738149A	1	P00738649A	1		
12	Body panel – rear	P00725239A	1	P00725239A	1		
13	Body panel – rear wind shield	P00725639A	1	P00725824A	1		
14	Burner – main	P02008056A	5	P02008056A	5		
15	Burner support bracket	P02210012B	1	P02210012B	1		
16	Gas collector box with electrode	P026080124	4	P026080124	3		
16a	Gas collector box with electrode	-	-	P026080144	1		
17	Electronic wire set	P02615024A	1	P02615090A	1		
18	Electronic igniter – 4 port / 6 port	P02502164C	1	P02502145C	1		
19	Gas valve / manifold / heat shield assy – LP	Y0060486	1	Y0060478	1		
19a	Gas valve – with jet	P03222110A	5	P03222110A	5		
19b	Manifold	P05008152A	1	P05009042A	1		
19c	Heat shield	P03009143B	1	P03009153B	1		
19d	Gas valve – back	-	-	P05009042A	1		
20	Decorative front panel	P07508005P	1	P07508005P	1		
21	Control panel – with screen print	P02909631B	1	P02909951A	1		
22	Control knob for main burner	P03419123H	5	P03419123H	5		
23	Control knob seat	P03415263L	5	P03415263L	6		
24	Grease tray track – left	P05330006K	1	P05330006K	1		
25	Grease tray track – right	P05330007K	1	P05330007K	1		
26	Grease draining tray	P02707036A	1	P02707036A	1		
27	Grease draining tray heat shield	P06903026B	1	P06903026B	1		
28	Grease receptacle	P02701075B	1	P02701075B	1		
29	Side shelf – left	P01102020C	1	P011060434	1		
30	Side shelf – right	N/A	-	P011070424	1		
31	Tool holder	P05514008A	1	P05514008A	1		
32	Tool hook	P05514053F	4	P05514053F	4		
33	Trolley bottom shelf – cylinder hole	P01004051D	1	P01004051D	1		
35	Castor seat – left front, right rear	P05327007G	2	P05327007G	2		
36	Castor seat – right front, left rear	P05327008G	2	P05327008G	2		
37	Trolley legs with side panel – left	P07617021B	1	P07617013B	1		
38	Trolley legs with side panel – right	P07618001B	1	P07618021B	1		
41	Trolley rear panel – NG (use for LP)	P07702058B	1	P07702058B	1		
42	Trolley bracket – front	P03305042D	1	P03305042D	1		
43	Door stop plate	P05510002B	4	P05510002B	4		
44	Door guide plate	P055100064	1	P055100064	1		
45	Door – left	P04202037J	1	P04202037J	1		
46	Door magnet	P05523002K	4	P05523002K	4		
47	Door trim plate	P07510003N	2	P07510003N	2		
48	Door spacer	P06801010G	4	P06801010G	4		
49	Door – right	P04303037J	1	P04303037J	1		
50	Door handle	P00205029B	2	P00205029B	2		
51	Door hinge bracket – top left	P03313004D	1	P03313004D	1		
52	Door hinge bracket – top right	P03313002D	1	P03313002D	1		
53	Door hinge bracket – bottom left	P03313005D	1	P03313005D	1		
54	Door hinge bracket – bottom right	P03313003D	1	P03313003D	1		
59	Castor – 3" with brake	P05119001A	4	P05119001A	4		
60	Regulator with hose – LP	P03603005A	1	P03603005A	1		
65	Lighting stick	P05313023B	1	P05313023B	1		
66	Hose clip	P05528001E	1	P05528001E	1		
67	Side shelf decoration panel – right	P07502015P	1	-	-		
68	Side shelf decoration panel – left	P075030005P	1	-	-		
A1	Side burner frame	P01104038C	1	-	-		
A2	Side burner body assembly	P02302010D	1	-	-		
A3	Side burner lid	P001153464	1	-	-		
A4	Pot support	P00805013B	1	-	-		
A5	Side burner electrode	P02607053L	1	-	-		
A6	Side burner gas valve assembly – LP	Y0060372	1	-	-		
A7	Control knob for side burner	P03426093L	1	-	-		
A8	Control knob seat	P03415263L	1	-	-		
A9	Side burner body with brass burner ring	P02002007A	1	-	-		
A10	Side burner bracket	P02215072E	1	-	-		
A11	Side burner connection hose	P03710001F	1	-	-		
A12	Side burner body bracket	P03305011P	2	-	-		
B1	Back burner assembly	-	-	P02007003A	1		
B2	Back burner orifice – LP	-	-	P06509023A	1		
B3	Back burner extension tube	-	-	P03717046A	1		
B4	Back burner gas collector box	-	-	P02621001K	1		
B6	Back burner electrode	-	-	P02614049C	1		
B7	Back burner wind shield	-	-	P06905045B	1		
B8	Back burner control knob	-	-	P03419263H	1		
	Hardware pack	P06003062A	1	P06003068A	1		

Premium 327, Professional 529 models

This diagram is provided to assist you identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and or service.

Items included in your barbecue specification may differ from the parts list, depending on region or specific dealer specification.




List applicable to Premium 327, Professional 529 models

Ref Description	Premium 327		Professional 529	
	Part No.	Qty	Part No.	Qty
1 Hood assembly	P00119134D	1	P00119436A	1
1a Hood trim plate	-	-	P0011429DV	1
2 Protective pad	P055180011	4	P055180011	4
3 Temperature gauge	P00601011B	1	P00601011B	1
4 Hood badge	P00407006S	1	P00407006S	1
5 Hood handle	P00205034B	1	P00205034B	1
6 Cooking rack – fixed	P01506003G	1	P01515004B	1
7a Grill plate	P01604004B	3	P01604004B	3
7b Hot plate	P05702002E	1	P05702002E	1
8 Flame tamer	P01705009E	3	P017080094	3
9 Body panel – left	P00720261A	1	P007202634	1
10 Body panel – right	P00721281A	1	P007212834	1
11 Body panel – front	P00738149A	1	P007381484	1
12 Body panel – rear	P00725239A	1	P007252384	1
13 Body panel – rear wind shield	P00725254A	1	P007252564	1
14 Burner – main	P02008056A	5	P02008056A	5
15 Burner support bracket	P02210012B	1	P0221001C4	1
16 Gas collector box with electrode	P026080124	4	P026080124	4
17 Electronic wire set	P02615024A	1	P02615024A	1
18 Electronic igniter – 4 port	P02502164C	1	P02502164C	1
19 Gas valve / manifold / heat shield assy – LP	Y0060393	1	Y0060393	1
20 Decorative front panel	P07508005D	1	P07508005P	1
21 Control panel – with screen print	P0291501AA	1	P02915021A	1
22 Control knob for main burner	P03419123H	5	P03419123H	5
23 Control knob seat	P03415263L	5	P03415263L	5
24 Grease tray track – left	P05330006K	1	P053300064	1
25 Grease tray track – right	P05330007K	1	P053300074	1
26 Grease draining tray	P02707036A	1	P02707036A	1
27 Grease draining tray heat shield	P06903026B	1	P06903026B	1
28 Grease receptacle	P02701075B	1	P02701075B	1
29 Side shelf – left	P01102012M	1	P011060064	1
30 Side shelf insert – left	P0011511E4	1	N/A	-
31 Tool holder	P05514008A	1	P05514008A	1
32 Tool hook	P05514053F	4	P05514053F	4
33 Trolley bottom shelf – cylinder hole	P01004051K	1	-	-
34 Trolley bottom shelf – pullout tray	-	-	P010080214	1
35 Castor seat – left front, right rear	P05327007G	2	P05327007G	2
36 Castor seat – right front, left rear	P05327008G	2	P05327008G	2
37 Trolley legs with side panel – left	P07617002E	1	P076020064	1
38 Trolley legs with side panel – right	P07618002E	1	P076030084	1
41 Trolley rear panel – NG (use for LP)	P07702035E	1	P077010334	1
42 Trolley bracket – front	P03305016J	1	P033060044	1
43 Door stop plate	P05510002B	4	P05510002L	4
44 Door guide plate	P055100064	1	P055100064	1
45 Door – left	P04305001E	1	P04302021J	1
46 Door magnet	P05523002K	4	P05523002K	4
47 Door trim plate	P07510003D	2	P07510003N	2
48 Door spacer	P06801010G	4	P06801010G	4
49 Door – right	P04306001E	1	P04303021J	1
50 Door handle	P00205029B	2	P00205029B	2
51 Door hinge bracket – top left	P03313004J	1	P03314005C	1
52 Door hinge bracket – top right	P03313002J	1	P03314006C	1
53 Door hinge bracket – bottom left	P03313005J	1	P03314007C	1
54 Door hinge bracket – bottom right	P03313003J	1	P03314008C	1
55 Trolley partition panel – left	P07512001D	1	P07512001D	1
56 Trolley partition panel bracket – left	P03303014J	1	P03303014J	1
59 Castor – 3" with brake	P05119001A	4	P05119001A	4
60 Regulator with hose – LP	P03603005A	1	P03603020A	1
65 Lighting stick	P05313023B	1	P05313023B	1
67 Cylinder pull-out tray assembly – LP	N/A	-	Y0340042	1
67a Cylinder tray handle	-	-	P04020001C	1
68 Hose clip	P05528001E	1	P05528001E	1
A1 Side burner frame	P01104015M	1	P011080084	1
A2 Side burner body assembly	P02302005D	1	P023010114	1
A3 Side burner lid	P001153464	1	P001153464	1
A4 Pot support	P00805013B	1	P00805013B	1
A5 Side burner electrode	P02607005C	1	P02607005C	1
A6 Side burner gas valve assembly – LP	Y0060263	1	Y0060263	1
A7 Control knob for side burner	P03426093L	1	P03426093L	1
A8 Control knob seat	P03415263L	1	P03415263L	1
A9 Side burner body with brass burner ring	P02002007A	1	P02002007A	1
A10 Side burner bracket	P02215072E	1	P0221507C4	1
A11 Side burner connection hose	P03705019J	1	P03705019J	1
A12 Side burner body bracket	P03305011P	2	P033060054	2
Hardware pack	P06003041B	1	P06003042A	1

Professional 584 model

This diagram is provided to assist you identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and or service.

Items included in your barbecue specification may differ from the parts list, depending on region or specific dealer specification.



List applicable to Professional 584 model

Ref	Description	Part #	Qty	Ref	Description	Part #	Qty
1	Hood assembly	P00119436A	1	41	Castor seat – right front, left rear	P05327008G	2
2	Hood trim plate	P0011429DV	1	42	Trolley legs with side panel – left	P076140044	1
3	Protective pad	P05518001I	4	43	Trolley legs with side panel – right	P076150154	1
4	Temperature gauge	P00601011B	1	46	Trolley rear panel – LP / NG	P07701037H	1
5	Hood badge	P00407006S	1	47	Trolley rear panel bracket	P033060064	1
6	Hood handle	P00205034B	1	48	Trolley bracket – front	P033060084	1
7	Cooking rack – fixed	P01515004B	1	49	Door stop plate	P05510002L	4
8a	Grill plate	P01604004B	3	50	Door guide plate	P055100064	1
8b	Hot plate	P05702002E	1	51	Door – left	P04302023J	1
9	Flame tamer	P017080094	3	52	Door magnet	P05523002K	4
10	Body panel – left	P007202834	1	53	Door trim plate	P07510005N	2
11	Body panel – right	P007212634	1	54	Door spacer	P06801010G	4
12	Body panel – front	P0073814B4	1	55	Door – right	P04303023J	1
13	Body panel – rear	P0072526B4	1	56	Door handle	P00205057B	2
14	Burner – main	P02008056A	5	57	Door hinge bracket – top left	P03314005C	1
15	Burner support bracket	P0221001C4	1	58	Door hinge bracket – top right	P03314006C	1
16	Gas collector box with electrode	P026080124	4	59	Door hinge bracket – bottom left	P03314007C	1
17	Electronic wire set	P02615028A	1	60	Door hinge bracket – bottom right	P03314008C	1
18	Electronic igniter – 4 port	P02502184C	1	61	Trolley partition panel – left	P07512003D	1
19	Electronic igniter – 2 port	P02502192C	1	62	Trolley partition panel bracket – left	P03303014J	1
20	Electronic wire set – 5 point	P02615040A	1	65	Cylinder pull-out tray assembly – LP	Y0340042	1
21	Electronic wire set – 2 point	P02615027A	1	65a	Cylinder tray handle	P04020001C	1
22	Gas valve / manifold / heat shield assembly – LP	Y0060394	1	66	Castor – 3" with brake	P05119001A	4
22a	Gas valve – main	P03222108A	5	67	Regulator with hose – LP	P03603020A	1
22b	Gas valve – side	P03222129A	1	72	Manual lighting tube	P05313006C	1
22c	Gas valve back	P03222097A	1	A1	Body panel outside – right	P007430364	1
22d	Manifold	P05010012A	1	A2	Side burner grease tray track assembly	P05516009G	1
22e	Heat shield	P03011053B	1	A3	Side burner body assembly	P023010114	1
22f	Main burner orifice – 1.07 mm	P06519044A	5	A4	Side burner body bracket	P033060054	2
22g	Side burner orifice – 1.10 mm	P06533005A	1	A5	Side burner lid	P001153464	1
23	Decorative front panel	P07508008P	1	A6	Pot support	P00805013B	1
24	Control panel – with screen print	P02911601B	1	A7	Side burner electrode	P02607006C	1
25	Control knob for main / side burner	P03419153H	6	A10	Side burner body with brass burner ring	P02002007A	1
26	Control knob seat	P03415263L	7	A11	Side burner bracket	P02215072E	1
27	Grease tray track – left	P053300084	1	A12	Side burner wind shield	P069060134	1
28	Grease tray track – right	P053300094	1	A13	Side burner grease tray – tray	P02718015B	1
29	Grease draining tray	P02707036A	1	B1	Back burner assembly	P02007003A	1
30	Grease draining tray heat shield	P06903026B	1	B2	Back burner orifice – LP, 1.05 mm	P06509023A	1
31	Grease receptacle	P02701075B	1	B3	Back burner extension tube	P03717034A	1
32	Body wind shield	P069060144	1	B4	Back burner gas collector box	P026210014	1
33	Back burner frame	P020110134	1	B6	Back burner electrode	P02614009C	1
34	Side shelf – left	P011060064	1	B7	Back burner wind shield	P069060154	1
35	Side shelf – right	P011070084	1	B8	Back burner control knob	P03419163H	1
36	Tool holder	P05514008A	1		Hardware pack	P06003040A	1
37	Tool hook	P05514053A	4				
38	Trolley bottom shelf	P010100184	1				
40	Castor seat – left front, right rear	P05327007G	2				

PRIVACY POLICY

Focus Lifestyle Products Pty Ltd may collect personal information about a consumer of its products in the course of receiving or responding to a warranty claim. Such information is only collected to enable the resolution of the warranty claim to the consumer's satisfaction, and is not disclosed to other organisations except service agents or sometimes the applicable retailer.

Focus Lifestyle Products has a Privacy Policy (*available on request*), which encompasses compliance with the Privacy Act 1988 (Cth). Importantly, individual consumers generally have a right to access information held about them.

Manufactured by
Grand Hall Enterprises Ltd China
for
Focus Lifestyle Products Pty Ltd

ABN 93 160 136 977

223 - 225 Governor Road, Braeside,
Victoria, Australia 3195

P.O. Box 532 Mordialloc,
Victoria, Australia 3195

enquiry@focuslifestyle.com.au

Tel: (03) 8586 2200 or FreeCall: 1800 680 405

Fax: (03) 9587 7965

All specifications are subject to change
without notice.