


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



KITCHENAID KCDC250K Owner's Manual

[Shop genuine replacement parts for KITCHENAID
KCDC250K](#)



[Find Your KITCHENAID Disposal Parts - Select From 75 Models](#)


----- Manual continues below -----

UPPER HOUSING AND FLANGE PARTS

DISPOSER

KitchenAid®

For Model: KCDC250K




Illus. No.	Part No.	DESCRIPTION
1	4211300	Stopper Assembly
2	8174306	Mounting Assembly
8	4211615	Gasket, Mounting
11	8174332	Trim Shell
12	4211339	Clip
13	4211649	Insulation
14	8174309	Bolt, Thru

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER HOUSING AND MOTOR PARTS


For Model: KCDC250K



Illus. No.	Part No.	DESCRIPTION
1		Enclosure Assy (Not Serviceable)
6	4211322	Actuator Assembly, Centrifugal
7	8174333	Stator Assembly
8	8174312	Switch Assembly, Start
9	8174334	Protector, Overload
10	4211647	End Frame Assembly, Lower
12	8174293	Kit, Installation
16	4211326	Shield, Wire
17	8174315	Cover, Terminal
20	8174310	Wrench, Emergency

Following Parts Not Illustrated

- LIT4211613 Guide, Use And Care
- LIT4211614 Instructions, Installation



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST