


PARTS LIST FOR

KitchenAid

DISPOSER

**MODEL
KCDC250X**

UPPER HOUSING AND FLANGE PARTS



4-92 Printed in U.S.A.

KitchenAid
ST. JOSEPH, MI 49085

© 1991, 1992 KITCHENAID




Part No. 4211558 Rev. B

5-92

| | | |
|----|---------|--|
| 1 | 4211332 | Stopper Assembly |
| 2 | 4211333 | Gasket, Stopper |
| 3 | 4211553 | Flange, Strainer |
| 4 | 4211302 | Gasket, Sink (2) |
| 5 | 4211303 | Flange, Backup |
| 6 | 4211304 | Flange, Mounting |
| 7 | 4211306 | Ring, Retaining |
| 8 | 4211334 | Gasket, Mounting |
| 9 | 4211308 | Flange, Body |
| 10 | 4211554 | Container, Body Assembly |
| 11 | 4211335 | Screw (3) |
| 12 | 4211337 | O-Ring |
| 13 | 4211555 | Trim Shell Assembly (includes illus. No. 15) |
| 14 | 4211305 | Screw, Backup (3) |
| 15 | 4211339 | Clip, Trim Shell (2) |
| 16 | 4211444 | Insulation, Top |

LOWER HOUSING AND MOTOR PARTS

For Model: KCDC250X



| | | |
|----|---------|--|
| 1 | 4211311 | Kit, Sleeve And Seal (Includes Plug, Nut, Washer, Slinger And Sleeve) |
| 2 | 4211341 | Plug |
| 3 | 4211492 | End Bell Assembly (Upper) |
| 4 | 4211557 | Rotor And Shaft Assembly |
| 5 | 4211321 | Washer |
| 6 | 4211322 | Centrifugal Actuator Assembly |
| 7 | 4211556 | Stator Assembly |
| 8 | 4211515 | End Frame Assembly (Lower) |
| 9 | 4211348 | Bolt, Thru (4) |
| 10 | 4211342 | Shredder |
| 11 | 4211344 | Gasket, Tailpipe |
| 12 | 4211317 | Tailpipe |
| 13 | 4211345 | Flange, Tailpipe |
| 14 | 4211346 | Screw, Tailpipe |
| 15 | 4211324 | Switch Assembly Start |
| 16 | 4211549 | Protect, Overload |
| 17 | 4211326 | Shield, Wire |
| 18 | 4211328 | Cover, Terminal |
| 19 | 4211329 | Screw |
| 20 | 4211330 | Screw, Tailpipe |
| 21 | 4211435 | Emergency, Wrench Assembly |
| 22 | 4211396 | Adapter, Sink Assembly |
| 23 | 4211565 | Kit, Instruction (Includes Nos. 11, 12, 13, 14, 21, Instructions and Use and Care Guide) |

Following Parts Not Illustrated

| | |
|------------|----------------------------|
| LIT4211550 | Guide, Use And Care |
| LIT4211551 | Instructions, Installation |
| LIT4211558 | Repair Parts List |