


# MOTOR AND HOUSING PARTS

For Model: KFP710WH0, 4KFP710WH0

(White) (White)

FOOD PROCESSOR  
7 Cup

**KitchenAid**®



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MOTOR AND HOUSING PARTS

For Model: KFP710WH0, 4KFP710WH0

(White) (White)


<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
1		Literature Parts
	8211901	Use & Care Guide
	8211954	Repair Parts List
2	8211816	Sleeve, Motor Shaft
3	8211817	Seal, Oil
4	8211806	Housing, Motor
5	8211610	Clamp, Cable
6	8211871	Screw, Clamp
7	8211813	Motor
8	8211814	Grommet, Motor
9	8211801	Base, Housing
10	8211810	Cover, Screw
11	8211811	Screw, Motor Locking
12	8211878	Cover, Switch
13	8211884	Bezel, Switch Panel
14	8211887	Seal, Switch Panel
15	8211870	Screw, Torx
16	8211812	Screw, Switch Panel
17	8211876	Nameplate
18	8211608	Capacitor
19	8211879	Relay & Switch Assembly
20	8211772	Foot
21	8211886	Cord, Power

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# ATTACHMENT PARTS

For Model: KFP710WH0, 4KFP710WH0

(White) (White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# ATTACHMENT PARTS

For Model: KFP710WH0, 4KFP710WH0

(White) (White)

<b>Illus.</b>	<b>Part</b>	
<b>No.</b>	<b>No.</b>	<b>DESCRIPTION</b>
1	8211760	Spatula
2	8211897	Disc, Slicing 2mm & Grating 4mm
3	8211902	Mini Blade
4	8211900	Adapter, Shaft & Disc
5	8211903	Blade
6	8211892	Pusher, Food
7	8211891	Cover, Work Bowl
8	8211906	Bowl, Work

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST