


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://ApplianceFactoryParts.com).



KITCHENAID KFP740QBF1 Owner's Manual

[Shop genuine replacement parts for KITCHENAID
KFP740QBF1](#)



[Find Your KITCHENAID Small Appliance Parts - Select From 538 Models](#)

----- Manual continues below -----

PARTS LIST

for

KitchenAid®

9-CUP FOOD PROCESSOR

MODELS:

KFP740WH1 (White)
4KFP740WH1 (White)
KFP740QWH1 (White)
KFP740QOB1 (Onyx Black)
KFP740QER1 (Empire Red)
KFP740QGC1 (Gloss Cinnamon)
KFP740QBW1 (Blue Willow)
KFP740QBF1 (Buttercup)




FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS



MOTOR AND HOUSING PARTS

For Models: KFP740__1, 4KFP740__1



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND HOUSING PARTS


For Models: KFP740__1, 4KFP740__1

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8212411	Use & Care, Trilin
	8212140	Repair Parts List
2	8211850	Sleeve, Motor Shaft
3	8211828	Seal, Oil
4		Housing, Motor
	8212184	White
	8212238	Onyx Black
	8212236	Empire Red
	8212285	Gloss Cinnamon
	8212284	Blue Willow
	W10159620	Buttercup
5	8211610	Clamp, Cable
6	8211731	Screw, Clamp
7	8212186	Motor, Sheet Metal
8	8212188	Grommet, Motor
9		Base, Housing
	8212183	White
	8212190	Onyx Black
	8212187	Empire Red
	8212283	Gloss Cinnamon
	8212282	Blue Willow
	W10159621	Buttercup
10		Cover, Screw
	8212185	White
	8212193	Onyx Black
	8212191	Empire Red
	8212287	Gloss Cinnamon
	8212286	Blue Willow
	W10159622	Buttercup
11	8211829	Screw, Motor Locking
12	8211848	Bezel, Switch Panel
13	8211607	Clip, Capacitor
14	8211847	Overlay, Panel Switch Assy
15	8211842	Nameplate
16	8211608	Capacitor
17	8212011	Relay & Switch Assembly
18		Foot
	8211844	White
	8211845	Black
19		Cord, Power
	8211856	White
	8211855	Black
20	8211605	Terminal Block
21	8211852	Cover, Terminal

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ATTACHMENT PARTS

For Models: KFP740__1, 4KFP740__1



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ATTACHMENT PARTS

For Models: KFP740__1, 4KFP740__1

Illus. No.	Part No.	DESCRIPTION
1	8211760	Spatula
2		Disc, Slicing
	8211929	2 mm
3	8212012	Mini Blade
4	8211858	Adapter, Shaft & Disc
5	8212013	Blade, Multipurpose
6	8212035	Pusher, Food
7	8212029	Cover, Work Bowl
8		Bowl, Work
	8211939	White
	8212044	Onyx Black
	W10159632	Empire Red
	W10159633	Gloss Cinnamon
	W10159634	Blue Willow
	W10159635	Buttercup
9		Disc, Shredding
	8211933	4 mm
10	8211926	Bowl, Mini
11	8212015	Blade, Dough

OPTIONAL PARTS NOT ILLUSTRATED

8212034	Accessory Box
8212025	Citrus Extractor
8211925	Whip, Egg (9-Cup)
8211927	Lid, Mini Bowl
8211928	Bowl, Chef's
	Disc, Slicing
8211930	4 mm
8211931	6 mm
	Disc, Shredding
8211932	2 mm
8211934	6 mm
8211935	Disc, Julienne
8211936	Disc, Grating
	Parmesan/Ice
8211937	Disc, Cutting
	French Fry
8211938	Rack, Disc

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST