

PARTS LIST

for

KitchenAid®

9-SPEED HAND MIXER

ARCHITECT SERIES

MODELS

KHM920ACS0 (Cocoa Silver)

KHM920AWH0 (White)

KHM920AER0 (Empire Red)

KHM920ACA0 (Candy Apple)

KHM920AOB0 (Onyx Black)

KHM920AEB0 (Electric Blue)



FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS




KITCHENAID

ST. JOSEPH MICHIGAN 49085

UNIT PARTS

Variations of Models: KHM920A__0



Illus. No.	Part No.	DESCRIPTION
1		Literature
	W10250601	Use & Care Guide
	W10276065	Repair Parts List
2	◆	Mixer, Complete
3	W10240913	Beaters, Turbo (Incl. Rt & Lt)
4	W10275837	Hooks, Dough (Incl. Rt & Lt)
5	8212341	Rod, Blending
6	8212340	Whisk

◆ **NOTE:**
 Parts not sold separately.
 Must be purchased as a
 complete unit.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST