

# PARTS LIST

for

# **KitchenAid®** **9-SPEED HAND MIXER**

## MODELS:

KHM9PWH5 (White)  
KHM900PK5 (Pink)  
KHM900ER5 (Empire Red)  
KHM9QWH5 (White)  
KHM9QBU5 (Cobalt Blue)  
KHM9QER5 (Empire Red)  
KHM9QOB5 (Onyx Black)  
KHM9QAC5 (Almond Creme)  
KHM9QGN5 (Empire Green)  
KHM9QMY5 (Majestic Yellow)  
KHM9QGC5 (Gloss Cinnamon)  
KHM9QBW5 (Blue Willow)  
KHM9PPK5 (Pink)  
KHM9PER5 (Empire Red)  
KHM9PFB5 (French Blue)  
KHM9PGG5 (Grass Green)  
KHM9PSY5 (Sunshine Yellow)




FOR CUSTOMER SATISFACTION ALWAYS USE  
FACTORY SPECIFICATION PARTS



# UNIT PARTS

## Variations of Models: KHM9\_\_5



Illus. No.	Part No.	DESCRIPTION
1	8212345	Literature Use & Care Guide (Trilingual)
	8212056	Repair Parts List
2	◆	Mixer, Complete
3	8212348	Beaters, Turbo (Incl. Rt & Lt)
4	8212351	Hooks, Dough (Incl. Rt & Lt)
5	8212341	Rod, Blending
6	8212340	Whisk

◆ **Note:**  
 Parts not sold separately.  
 Must be purchased as a complete unit.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST