

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



KITCHENAID KM25G0XWH5 Owner's Manual

[Shop genuine replacement parts for KITCHENAID
KM25G0XWH5](#)

KitchenAid®

[Find Your KITCHENAID Mixer Parts - Select From 532 Models](#)

----- Manual continues below -----

PARTS LIST

for


KitchenAid®

COMMERCIAL MIXER

VARIATIONS OF

KM25G0XWH4

SOLID STATE




FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS



CASE, GEARING AND PLANETARY UNIT

For Model: KM25G0XWH4



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CASE, GEARING AND PLANETARY UNIT

For Model: KM25G0XWH4


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9703311	Gearcase Motor Housing	14	9708191	Agitator Shaft Assembly	27	3400200	Screw (3) 1/4 – 20 x 3/4
2	9707507	Motor (10 Tooth)	15	9708172	Planetary Assembly	28		Bearing
3	242765-2	Cap, Attachemnt Hub	16	9704677	Pin, Groove		9703560	Front
4	240374	Thumb Screw	17	9706770	Worm Gear		9703570	Rear
5	9707795	Band, Trim	18	9707223	Retaining Pin	29	9703445	Thrust Bearing
6	9706813	Power Cord	19	9706529	Gear, Worm Follower	30	9706036	Lead, Motor to Control
7	9703671	Transmission Housing	20	9703338	Gear, Attachment Hub Bevel	31	9706247	Seal, Motor Shaft
8	9706648	Control Assembly	21	9703337	Gear, Bevel	32	9707425	Gasket, Transmission
9	9703312	Sensor, Hall Effect	22	3400617	Screw, 6-32 x 1/4	34	8533910	Washer
10	9706090	Washer	23	3400814	Screw, 8-32 x 5/8	35	9706141	Ring, Attachment Hub
11	9703434	Washer, Fiber	24	9707793	Lower Gear Case	36	9706814	Screen, Vent
12	9703340	Gear, Pinion	25	9703680	Retaining Clip	37	9706816	Guard
13	9703438	Retaining Clip	26	67500-55	"O" Ring			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BASE AND PEDESTAL UNIT

For Model: KM25G0XWH4

Illus. No.	Part No.	DESCRIPTION
1	LIT9707796 LIT8204559	Literature Parts Use & Care Guide Repair Parts List
2	9703414	Foot, Rubber (5)
3	9703673	Column Assembly
4	9707633	Bowl Support (Includes Item 18)
5	9703474	Latch, Bowl Spring
6	9706885	Arm, Bowl Lift
7	9706787	Rod, Bowl Lift
8	9703690	Base And Foot Assembly
9	9703439	Washer
10	9237	Spring
11	4159092	Nut
12	9706788	Handle, Bowl Lift
13	3400863	Screw
14	9707681	Bowl (5 Qt)
15	4176045	Beater, Flat
16	9708196	Dough Hook
17	9704310	Wire Whip
18	4162028	Pin, Bowl Locating
20	9703426	Cam, Adjusting
21	3400200	Screw, 1/4-20 x 3/4
22	3400018	Screw, 10-24 x 1/2
23	9703307	Clip



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ACCESSORY PARTS

For Model: KM25G0XWH4

Illus.	Part
No.	No. DESCRIPTION

Following Parts Not Illustrated

OPTIONAL ATTACHMENTS, ACCESSORIES AND SERVICE ITEMS

4164778	Mixer Attachment Pak (Includes Food Grinder (FG-A), Food Strainer (FVSP), And Vegetable Slicer, (RVS-A) (FPP-A)
4164749	Food Grinder (FG-A)
4164751	Grain Mill (GM-A)
4164768	Pasta Maker And Food Grinder (Includes SNP Pasta Maker Plates) (SN/FG-A)
4164775	Fruit/Vegetable Strainer Parts (Use With FG-A Model Only) (FVSP)
4164750	Rotor Slicer/Shredder (With 4 Standard Cones) Fine Shredder, Coarse Shredder, Thick Slicer, And Thin Slicer (RVS-A)
4164824	Pasta Maker Plates (SNP-A)
4164774	Fruit/Vegetable Strainer And Food Grinder (FVS/FG-A)
4162838	Food Tray (FT)
4164748	Juicer (JE)
4164747	Can Opener (CO)
4164803	Sausage Stuffer Kit (SSA)
4160588	Grease, Planetary

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST