


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



KITCHENAID KSM120ER0 Owner's Manual

[Shop genuine replacement parts for KITCHENAID
KSM120ER0](#)

COLOR VARIATION PARTS
FOR MODELS: KSM120__0



[Find Your KITCHENAID Mixer Parts - Select From 532 Models](#)

----- Manual continues below -----

PARTS LIST

for

KitchenAid®

4 1/2 QT. STAND MIXER CUSTOM – TILT

MODELS:

**KSM120WH0 (White)
KSM120ER0 (Empire Red)
KSM120OB0 (Onyx Black)
KSM120MC0 (Metallic Chrome)**




**FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS**



COLOR VARIATION PARTS

FOR MODELS: KSM120_0



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------



Colors Subject To Change.
Any Color Not Listed is
No Longer Available.
If Additional Colors Are Added,
This Page Will Be Updated.

1	240291-1	Motor Housing White
	240291-21	Empire Red
	240291-13	Onyx Black
	9704025	Metallic Chrome
2		Trim Band
	9706661	Black
3		Planetary
	240286-1	White
	240286-23	Empire Red
	240286-16	Onyx Black
	9706670	Metallic Chrome
4		End Cover
	240253-1	White
	240253-22	Empire Red
	240253-14	Onyx Black
	9704029	Metallic Chrome
5		Lower Gearcase
	240350-4	White
	240350-84	Empire Red
	240350-56	Onyx Black
	9706662	Metallic Chrome
6		Pedestal & Foot
	3179260	White
	9702304	Empire Red
	3179275	Onyx Black
	9706684	Metallic Chrome

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BASE AND PEDESTAL UNIT

FOR MODELS: KSM120_0




Illus. No.	Part No.	DESCRIPTION
1	9709785	Literature Parts Use & Care Guide (Trilingual)
	8212410	Repair Parts List
2	4162529	Screw Cap Kit
3	9709280	Lever, Latch Black
4	24450	Link, Latch
5	115792	Foot, Base
6	**	Pedestal
7	16910	Pin, Hinge
8	103993	Screw, Latch Bearing
9	24452	Latch, Link & Lever Assembly
10	9709055	Latch
11	8533912	Washer
12	110679	Screw, Pivot
13	116241	Washer, Spring
14	3400020	Screw
15	9708470	Beater, Flat
16	242550-2	Bowl And Base (4 1/2 Qt.)
17	9708471	Dough Hook
18	9706446	Wire Whip

**Refer to Page 3
Color Variation Parts

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CASE, GEARING AND PLANETARY UNIT

FOR MODELS: KSM120_0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CASE, GEARING AND PLANETARY UNIT

FOR MODELS: KSM120__0


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	**	Gearcase Motor Housing	14	9709627	Bevel Pinion & Center Gear	26	240285	Ring, Planetary Drip
2	242765-2	Cap, Attachment Hub	15	240018-1	Pin (Vertical Center Shaft)	28	9703903	Pinion, Gear
3		Thumb Screw	16	3180163	Washer	29	89411	Screw, Adjusting
4	9709194	Black	17	9705443	Pin, Grooved	30	3400203	Screw, Set
5	8533914	Lock Washer	18	4162324	Gasket, Transmission Case	31	3400025	Screw, Machine
6	3180161	Washer	19	**	Lower Gear Case	32	67500-55	"O" Ring
7	W10112253	Worm Gear	20	3180163	Washer	33	311932	Screw
8	240308	Worm Gear Bracket And Bearing	21	9703904	Gear, Internal	34	**	Cover, End
9	3400022	Screw And L.W. Assy.	22	103994	Screw	35	9706090	Screw
10	240210-2	Shaft & Pinion	23	**	Planetary	36	240309-2	Worm Gear Bracket And Gear
11	9705444	Pin, Grooved	24	4176067	Agitator Shaft	37	4160474	Center Shaft & "O" Ring
12	240026	Shaft, Vertical Center	25	240018-1	Pin (Agitator Shaft Pinion)	38	9703438	Ring
13	9705130	Gear, Attachment Hub Bevel				39	9704677	Pin, Groove

**Refer to Page 3
Color Variation Parts

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND CONTROL PARTS

FOR MODELS: KSM120_0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND CONTROL PARTS

FOR MODELS: KSM120__0

Illus. No.	Part No.	DESCRIPTION
1	110679	Screw, Pivot
2	116241	Washer, Spring
3		Lever, Speed Control Assembly
	9709276	Black
4	3183680	Spring, Control Plate
5	3184176	Speed Link & Cam
6	240205	Spring, Flat
7	240769	Screw
8	9702695	Field Assembly
9	9704324	Washer, Bearing
11	16998	Stud, Governor Drive
12	3180162	Washer
13	W10068270	Washer
14	240775-1	Seal, End
15	3180526	Bracket, Bearing Asm.
16	3180238	Washer
17	8533905	Nut, Machine
18	240680	Insert, Brush Holder
19	9706416	Brush, Carbon
20	9707926	Screw, Set
21	116286	Cap, Spring Seat
22	116287	Spring, Cap
23		Cap, Brush Holder
	3184212	Black
24	17830	Governor Assembly
25	240904-2	Control Plate Assembly
26		Power Cord
	9701025	White
	9701026	Black
27	9706595	Phase Control Board Assembly
28	9708315	Armature & Bearing
29	4162634	Sleeve, Motor Stud
30	3184609	Screw, Ground
31	3179908	Housing, Brush Holder
32	4162546	Brush Holder
33	W10068260	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ACCESSORY PARTS

FOR MODELS: KSM120__0

Illus. No.	Part No.	DESCRIPTION
	4164839	Speed Disc (Service Tool)
	4160588	Grease, Planetary
	4164778	Mixer Attachment Pak (Includes Food Grinder (FG-A), Food Strainer (FVSP), And Vegetable Slicer, (RVS-A) (FPP-A)
	4164749	Food Grinder (FG-A)
	4164768	Pasta Maker And Food Grinder (Includes SNP Pasta Maker Plates) (SN/FG-A)
	4164775	Fruit/Vegetable Strainer Parts (Use With FG-A Model Only) (FVSP)
	4164750	Rotor Slicer/Shredder (With 4 Standard Cones) Fine Shredder, Coarse Shredder, Thick Slicer, And Thin Slicer (RVS-A)
	3177975	Pouring Shield (KPS2CL)
	4164824	Pasta Maker Plates (SNP-A)
	4164774	Fruit/Vegetable Strainer And Food Grinder (FVS/FG-A)
	3180617	Cover, Decorative (Cotton Polyester)
	4162838	Food Tray (FT)
	4164748	Juicer (JE)
	4164747	Can Opener (CO)
	4164803	Sausage Stuffer Kit (SSA)
	3177924	Bowl Cover, Plastic Non-Sealing
	4163337	Bowl, Stainless With Handle
	3180262	Bowl, 3 Qt. (KSM103 & KSM110)
	4162160	Bowl, Satin Stainless
	8212519	Ice Cream Attachment – KICA
	8211924	Grain Mill – KGMA

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST