


This Owner's Manual is provided and hosted by Appliance Factory Parts.



KITCHENAID 5KSM156PSACA0 Owner's Manual

[Shop genuine replacement parts for KITCHENAID
5KSM156PSACA0](#)



[Find Your KITCHENAID Mixer Parts - Select From 532 Models](#)

----- Manual continues below -----

PARTS LIST

for

KitchenAid®

5 QT. STAND MIXER – AUSTRALIAN

ARTISAN – TILT HEAD – 90TH ANNIVERSARY

MODEL:

5KSM156PSACA0 (Candy Apple)



FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS



KITCHENAID

ST. JOSEPH MICHIGAN 49085

COLOR VARIATION PARTS

For Models: 5KSM156PSA_0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COLOR VARIATIONS PARTS

For Models: 5KSM156PSA__0


Illus. No.	Part No.	DESCRIPTION
1		Motor Housing
	W10239115	Candy Apple
2		Trim Band
	W10258966	Black/Frost
3		End Cover
	W10239110	Candy Apple
4		Planetary
	W10239112	Candy Apple
5		Lower Gearcase
	W10245786	Candy Apple
6		Pedestal w/Feet & Headlock
	W10245720	Candy Apple

Colors Subject To Change.
Any Color Not Listed is
No Longer Available.
If Additional Colors Are Added,
This Page Will Be Updated.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CASE, GEARING AND PLANETARY UNIT

For Models: 5KSM156PSA_0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CASE, GEARING AND PLANETARY UNIT

For Models: 5KSM156PSA__0

Illus. No.	Part No.	DESCRIPTION
1	**	Gearcase Motor Housing
2	242765-2	Cap, Attachment Hub
3	9709194	Thumb Screw Black
4	**	Band, Trim
5	3180161	Washer
6	W10112253	Worm Gear
7	240308	Worm Gear Bracket and Bearing
8	9705444	Pin
9	240210-2	Gear, Shaft & Pinion
10	9705130	Gear, Attachment Hub Bevel
11	9709627	Gear, Bevel Pinion & Center
12	240026	Shaft, Vertical Center
13	240018-1	Pin, Agitator Shaft
14	9705443	Pin, Groove
15	4162324	Gasket, Transmission
16	67500-55	O-Ring
17	3180163	Washer
18	**	Lower Gear Case
19	103994	Screw
20	3184052	Shaft, Agitator
21	9703438	Ring, Retaining
22	9704677	Pin, Groove
23	4162914	Screw
24	**	Cover, End
25	311932	Screw
26	3400022	Screw
27	240309-2	Worm Gear Bracket and Gear
28	4160474	Center Shaft & O-Ring
29	8533914	Washer, Lock
30	3400025	Screw, Machine
31	3400203	Screw, Set
32	9703903	Gear, Pinion
33	9706090	Washer
34	**	Planetary
35	240285	Ring, Planetary
36	89411	Screw, Adjusting
37	9703904	Gear, Internal
38	9702311	Lead, Filter Control Board
39	9705132	RFI Filter
40	3184086	Screw

**Refer to Pages 2 & 3
Color Variation Parts

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND CONTROL PARTS

For Models: 5KSM156PSA_0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND CONTROL PARTS


For Models: 5KSM156PSA__0

Illus. No.	Part No.	DESCRIPTION
1	110679	Screw, Pivot
2	116241	Washer, Spring
3		Control, Speed Assembly
	9709276	Black
4	3183680	Spring, Control Plate
5	9704324	Washer, Ball Bearing (Front)
6	9708316	Armature & Bearing
7	3180162	Washer
8	16998	Stud, Governor Dr
9	3180526	Bracket, Bearing Assembly
10	3184356	Seal, End
11	W10131078	Nut, 10-24
12	3180238	Washer, Felt
13	240769	Screw, Stator
14	W10068270	Washer
15	3184176	Speed Link & Cam
16	240205	Spring, Flat
17	9701670	Field Assembly
18	4162634	Sleeve, Motor
19	W10260958	Brush, Carbon
20	9707926	Screw
21	4162546	Brush Holder
22	3179908	Housing, Brush Holder
23	240680	Insert, Brush Hldr
24	116286	Cap, Spring Seat
25	116287	Spring, Cap
26		Cap, Brush Holder
	3184212	Black
27	W10068260	Screw
28	W10119326	Control Plate Assy
29	17830	Governor Assembly
30	W10217542	Phase Control Brd
31		Power Cord
	9702368	White
32	3184086	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BASE AND PEDESTAL UNIT

For Models: 5KSM156PSA_0



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	9709851	Use & Care Guide
	W10268967	Repair Parts List
2	9709923	Shield, Pouring
3	9708472	Beater, Flat
4	9706619	Bowl, 5 Qt.
5	3400020	Screw
6	W10191926	Screw Cap Kit
7	9709707	Foot, Base
8	9706446	Whip, Wire
9	9708471	Hook, Dough
10	9709055	Latch
11	3184200	Latch, Link Assy
12	110679	Screw, Pivot
13	116241	Washer, Spring
14	8533912	Washer
15	103993	Screw, Latch
16	24450	Link, Latch
17		Lever, Latch
	9709267	Black
18	16910	Pin, Hinge
19	**	Pedestal
20		Head Lock
	3184264	Black
21	3183690	Spring, Lock Lever

**REFER TO PAGES 2 & 3.

Literature Parts

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ACCESSORY PARTS

For Models: 5KSM156PSA__0

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
	4164839	Speed Disc (Service Tool)		4164775	Fruit/Vegetable Strainer Parts (Use With FG-A Model Only) (FVSP)		4164774	Fruit/Vegetable Strainer and Food Grinder (FVS-FG-A)
	4160588	Grease, Planetary					3180617	Cover, Decorative (Cotton Polyester)
	4164778	Mixer Attachment Pak (Includes Food Grinder (FG-A), Food Strainer (FVSP), And Vegetable Slicer, (RVS-A) (FPP-A)		4164750	Rotor Slicer/ Shredder(With 4 Standard Cones) Fine Shredder, Coarse Shredder, Thick Slicer, and Thin Slicer (RVS-A)		4162838	Food Tray (FT)
	4164749	Food Grinder (FG-A)		9704568	Pouring Shield (KPS2CL)		4164748	Juicer (JE)
	8211924	Grain Mill (KGMA)		4164824	Pasta Maker Plates (SNP-A)		4164747	Can Opener (CO)
	4164768	Pasta Maker And Food Grinder (Includes SNP Pasta Maker Plates) (SN/FG-A)					4164803	Sausage Stuffer Kit (SSA)
							8212632	Ice Cream Maker (5KICA)
							3177924	Bowl Cover, Plastic Non-Sealing
							4163337	Bowl, Stainless With Handle
							3180262	Bowl, 3 Qt.
							4162160	Bowl, Satin Stainless

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST