


This Owner's Manual is provided and hosted by Appliance Factory Parts.




KITCHENAID KSB3AC0 Owner's Manual

[Shop genuine replacement parts for KITCHENAID
KSB3AC0](#)



[Find Your KITCHENAID Small Appliance Parts - Select From 538 Models](#)

----- Manual continues below -----




| | | |
|---|---------|--------------------------|
| 1 | | Lid Assembly |
| | 4176341 | White |
| | 4176342 | Almond Creme |
| 2 | 3184399 | Jar |
| 4 | 9701672 | Seal, Lid |
| 5 | 9702184 | Blade, Insert Asm. |
| 6 | | Collar |
| | 3184360 | White |
| | 3184361 | Almond Creme |
| 7 | 3184397 | Seal, Cutter Insert Asm. |

Following Parts Not Illustrated
4176241 Carton, 4-Pack

LITERATURE PARTS

LIT3184604 Use and Care Guide
LIT4176940 Repair Parts List

UNIT PARTS
For Variations Of
Model KSB3



| | | |
|----|---------|---|
| 1 | 9703274 | Coupling, Drive |
| 2 | | Housing, Upper |
| | 3184302 | White |
| | 3184304 | Almond Creme (Also order item 12 in color that matches housing) |
| 3 | 9702354 | Board, Control |
| 4 | 3184398 | Seal, Motor |
| 5 | 9703244 | Motor |
| 6 | 9702592 | Fuse, 250V/8A (If Needed) |
| 7 | 9701027 | Barrier, Ventilation |
| 8 | 9701031 | Cord, Power |
| 9 | | Base |
| | 3184536 | White |
| | 3184537 | Almond Creme |
| 10 | 3184608 | Screw |
| 11 | 115792 | Foot, Rubber |
| 12 | | Overlay, Switch |
| | 9701905 | White |
| | 9701906 | Almond Creme |
| 13 | 3184601 | Button, Switch |
| 14 | 3184609 | Screw |
| 15 | | Ring, O |
| | 3184603 | White |
| | 9701904 | Almond Creme |
| 16 | 3184611 | Band, Trim |