


1		Lid Assembly
	4176341	White
	4176342	Almond Creme
2	3184399	Jar
4	9701672	Seal, Lid
5	9702184	Blade, Insert Asm.
6		Collar
	3184360	White
	3184361	Almond Creme
7	3184397	Seal, Cutter Insert Asm.

Following Parts Not Illustrated
4176241 Carton, 4-Pack

LITERATURE PARTS

LIT3184604 Use and Care Guide
LIT4176940 Repair Parts List

UNIT PARTS
For Variations Of
Model KSB3



1	9703274	Coupling, Drive
2		Housing, Upper
	3184302	White
	3184304	Almond Creme (Also order item 12 in color that matches housing)
3	9702354	Board, Control
4	3184398	Seal, Motor
5	9703244	Motor
6	9702592	Fuse, 250V/8A (If Needed)
7	9701027	Barrier, Ventilation
8	9701031	Cord, Power
9		Base
	3184536	White
	3184537	Almond Creme
10	3184608	Screw
11	115792	Foot, Rubber
12		Overlay, Switch
	9701905	White
	9701906	Almond Creme
13	3184601	Button, Switch
14	3184609	Screw
15		Ring, O
	3184603	White
	9701904	Almond Creme
16	3184611	Band, Trim