

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



KITCHENAID 4KCG200MC1 Owner's Manual

[Shop genuine replacement parts for KITCHENAID
4KCG200MC1](#)

KitchenAid®

[Find Your KITCHENAID Small Appliance Parts - Select From 538 Models](#)

----- Manual continues below -----

PARTS LIST

for

KitchenAid®

COFFEE MILL

MODELS:

KCG200WH1 (White)
KCG200BU1 (Cobalt Blue)
KCG200ER1 (Empire Red)
KCG200OB1 (Onyx Black)
KCG200MC1 (Metallic Chrome)
KCG200TG1 (Tangerine)
KCG200PK1 (Pink)
KCG200BW1 (Blue Willow)
KCG200GC1 (Gloss Cinnamon)
4KCG200WH1 (White)
4KCG200BU1 (Cobalt Blue)
4KCG200ER1 (Empire Red)
4KCG200OB1 (Onyx Black)
4KCG200MC1 (Metallic Chrome)
4KCG200PK1 (Pink)




FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS



UNIT PARTS

FOR MODELS: KCG200__1, 4KCG200__1



Literature Parts

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS


FOR MODELS: KCG200__1, 4KCG200__1

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts Use & Care Guide
	9707030	US
	8211956	Repair Parts List
2	9708807	Guard, Finger
3	9707037	Support, Jar Asm
4	9707092	Support & Burr Assembly
6	9707095	Screw, Finger Grd
8	9707018	Plunger Spring Asm
9		Housing, Motor
	9707008	White
	9707009	Cobalt Blue
	9707010	Empire Red
	9707011	Onyx Black
	9707040	Metallic Chrome
	9708164	Tangerine
	9708165	Pink
	9709844	Blue Willow
	9709845	Gloss Cinnamon
10	9707019	Door Hub
11	9707052	Switch, Toggle
13	9707023	Gasket, Motor
14	9707012	Motor
15		Cord, Power
	9707025	White
	9707034	Black
16	9707049	Plate, Bottom
17	9707022	Foot, Rubber
18	303921	Screw
19	9707096	Screw, Locking

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

JAR ASSEMBLY

FOR MODELS: KCG200__1, 4KCG200__1



Illus. No.	Part No.	DESCRIPTION
1	9707003	Lid
2	9707004	Jar
3	9707014	Gasket, Jar
5	9707006	Glass, Measuring
6	9707038	Jar Assembly Complete
7	9708809	Brush, Cleaning

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST