

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



KITCHENAID 4KFPW760WH0 Owner's Manual

[Shop genuine replacement parts for KITCHENAID
4KFPW760WH0](#)

KitchenAid®

[Find Your KITCHENAID Small Appliance Parts - Select From 538 Models](#)

----- Manual continues below -----

PARTS LIST

for

KitchenAid®

FOOD PROCESSOR

12 CUP – WIDE MOUTH

MODELS:

KFPW760WH0 (White)
KFPW760OB0 (Onyx Black)
KFPW760CWH0 (White)
KFPW760COB0 (Onyx Black)
KFPW760QWH0 (White)
KFPW760QOB0 (Onyx Black)
KFPW760QER0 (Empire Red)
KFPW760QBU0 (Cobalt Blue)
KFPW760QCR0 (Chrome)
4KFPW760WH0 (White)
4KFPW760OB0 (Onyx Black)




FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS



MOTOR AND HOUSING PARTS

For Models: KFPW760__0, 4KFPW760__0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND HOUSING PARTS


For Models: KFPW760__0, 4KFPW760__0

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8211864	Use & Care Guide
	8212026	Repair Parts List
2	8211849	Sleeve, Motor Shaft
3	8211828	Seal, Oil
4		Housing, Motor
	8211818	White
	8211821	Onyx Black
	8211819	Empire Red
	8211820	Cobalt Blue
	8211822	Chrome
5	8211610	Clamp, Cable
6	8211731	Screw, Clamp
7	8211837	Motor, Die Cast
8	8211843	Grommet, Motor
9		Base, Housing
	8212183	White
	8212190	Onyx Black
	8212187	Empire Red
	8212189	Cobalt Blue
10		Cover, Screw
	8211824	White
	8211827	Black
	8211825	Red
	8211826	Blue
11	8211829	Screw, Motor Locking
12	8211848	Bezel, Switch Panel
13		Overlay & Cover
	8211846	Black
	8211847	Silver
14	8211607	Clip, Capacitor
15	8211605	Terminal Block
16	8211852	Cover, Terminal
17	8211842	Nameplate
18	8211608	Capacitor
19	8212011	Relay & Switch Assembly
20		Foot
	8211844	White
	8211845	Black
21		Cord, Power
	8211855	Black
	8211856	White
	8211857	Black (Chrome Model only)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ATTACHMENT PARTS

For Models: KFPW760__0, 4KFPW760__0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ATTACHMENT PARTS

For Models: KFPW760__0, 4KFPW760__0

Illus. No.	Part No.	DESCRIPTION
1	8211760	Spatula
2		Disc, Slicing
	8211929	2 mm
	8211930	4 mm
3	8212012	Blade, Mini
4	8211858	Adapter, Shaft & Disc
5	8212014	Blade, Multipurpose
6	8212020	Pusher, Double
7		Cover, Work Bowl
	8212030	White
	8212024	Black
	8212241	Red
	8212240	Blue
8		Bowl, Work
	8212043	White
	8212019	Black
	8212017	Red
	8212018	Blue
9		Disc, Shredding
	8211933	4 mm
10	8211926	Bowl, Mini
11	8212016	Blade, Dough
12	8211928	Bowl, Chef's
13	8212025	Extractor, Citrus
14	8212033	Whip, Egg (12-cup)

OPTIONAL PARTS NOT ILLUSTRATED

8212034	Accessory Box
8211927	Lid, Mini Bowl
	Disc, Slicing
8211931	6 mm
	Disc, Shredding
8211932	2 mm
8211934	6 mm
8211935	Disc, Julienne
8211936	Disc, Grating Parmesan/Ice
8211937	Disc, Cutting French Fry
8211938	Rack, Disc

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST